

Model A-C3
(B079/B082)

PARTS CATALOG


First edition, January 2003

Ricoh Company, LTD.

Model A-C3 (B079/B082)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.



Adonis C3	(B079/B082)
DF76	(B541)
SR790	(B408)
SR880	(B545)
SR890	(B546)
PS530	(B542)
RT45	(B543)
PT330	(B544)
Bridge Unit Type 2045	(B538)




Model A-C3 (B079/B082)

Model A-C3 (B079/B082)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.



LOCATION OF UNIT	2	18.DEVELOPMENT UNIT 2 (B079/B082).....	42
1.EXTERIOR 1 (B079/B082)	8	19.OPC UNIT (B079/B082)	44
2.EXTERIOR 2 (B079/B082)	10	20.TRANSFER UNIT (B079/B082).....	46
3.EXTERIOR 3 (B079/B082)	12	21.FUSING UNIT 1 (B079/B082)	48
4.PLATEN COVER (B079/B082)	14	22.FUSING UNIT 2 (B079/B082)	50
5.OPERATION PANEL ASS'Y (B079/B082).....	16	23.PAPER SEPARATION UNIT 1 (B079/B082)	52
6.OPTICS UNIT 1 (B079/B082)	18	24.PAPER SEPARATION UNIT 2 (B079/B082)	54
7.OPTICS UNIT 2 (B079/B082)	20	25.DUPLEX UNIT 1 (B079/B082).....	56
8.OPTICS UNIT 3 (B079/B082)	22	26.DUPLEX UNIT 2 (B079/B082).....	58
9.LASER UNIT (B079/B082)	24	27.DUPLEX UNIT 3 (B079/B082).....	60
10.BY-PASS FEED UNIT 1 (B079/B082)	26	28.DRIVE SECTION 1 (B079/B082)	62
11.BY-PASS FEED UNIT 2 (B079/B082)	28	29.DRIVE SECTION 2 (B079/B082)	64
12.PAPER TRAY UNIT (B079/B082)	30	30.DRIVE SECTION 3 (B079/B082)	66
13.PAPER FEED SECTION (B079/B082)	32	31.ELECTRICAL SECTION 1 (B079/B082)	68
14.VERTICAL TRANSORT (B079/B082).....	34	32.ELECTRICAL SECTION 2 (B079/B082)	70
15.PAPER REGISTRATION (B079/B082)	36	33.FRAME SECTION 1 (B079/B082).....	72
16.TONER HOPPER UNIT (B079/B082)	38	34.FRAME SECTION 2 (B079/B082).....	74
17.DEVELOPMENT UNIT 1 (B079/B082)	40	35.EXPANSION BOX (B079/B082).....	76


January ,30 ' 2003

Model A-C3 (B079/B082)

PARTS CATALOG


This catalog gives the numbers and names of parts on this machine.

36.IOB BOARD (B079/B082)	78
37.BICU BOARD (B079/B082)	82
38.CONTROLLER BOARD (B079/B082)	86
39.DECAL AND DOCUMENT (B079/B082)	96
40.SPECIAL TOOLS (B079/B082)	98
PARTS INDEX	101




LOCATIONS OF UNITS

1. EXTERIOR 1 (B079/B082)




See Page 9

2. EXTERIOR 2 (B079/B082)




See Page 11

3. EXTERIOR 3 (B079/B082)




See Page 13

4. PLATEN COVER (B079/B082)




See Page 15

5. OPERATION PANEL ASS'Y



See Page 17


6. OPTICS UNIT 1 (B079/B082)



See Page 19


LOCATIONS OF UNITS

7. OPTICS UNIT 2 (B079/B082)




See Page 21

8. OPTICS UNIT 3 (B079/B082)




See Page 23

9. LASER UNIT (B079/B082)




See Page 25

10. BY-PASS FEED UNIT 1 (B079/B082)




See Page 27

11. BY-PASS FEED UNIT 2 (B079/B082)



See Page 29


12. PAPER TRAY UNIT (B079/B082)



See Page 31


LOCATIONS OF UNITS

13. PAPER FEED SECTION (B079/B082)




See Page 33

14. VERTICAL TRANSPORT (B079/B082)




See Page 35

15. PAPER REGISTRATION (B079/B082)




See Page 37

16. TONER HOPPER UNIT (B079/B082)




See Page 39

17. DEVELOPMENT UNIT 1 (B079/B082)



See Page 41


18. DEVELOPMENT UNIT 2 (B079/B082)



See Page 43


LOCATIONS OF UNITS

19. OPC UNIT (B079/B082)




See Page 45

20. TRANSFER UNIT (B079/B082)




See Page 47

21. FUSING UNIT 1 (B079/B082)




See Page 49

22. FUSING UNIT 2 (B079/B082)




See Page 51

23. PAPER SEPARATION UNIT 1



See Page 53


24. PAPER SEPARATION UNIT 2



See Page 55


LOCATIONS OF UNITS

25. DUPLEX UNIT 1 (B079/B082)




See Page 57

26. DUPLEX UNIT 2 (B079/B082)




See Page 59

27. DUPLEX UNIT 3 (B079/B082)




See Page 61

28. DRIVE SECTION 1 (B079/B082)




See Page 63

29. DRIVE SECTION 2 (B079/B082)



See Page 65


30. DRIVE SECTION 3 (B079/B082)



See Page 67


LOCATIONS OF UNITS

31. ELECTRICAL SECTION 1 (B079/B082)




See Page 69

32. ELECTRICAL SECTION 2 (B079/B082)




See Page 71

33. FRAME SECTION 1 (B079/B082)




See Page 73

34. FRAME SECTION 2 (B079/B082)




See Page 75

35. EXPANSION BOX (B079/B082)



See Page 77

1.EXTERIOR 1 (B079/B082)




1.EXTERIOR 1 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B077 1338	Cover:Lower:Operation Sub-unit (NA)	1
1	B077 6338	Cover:Lower:Operation Sub-unit:EU	1
2	AA14 3520	Shoulder Screw - M3	7
3	B077 1337	Cover:Left:Scanner (NA)	1
3	B077 6337	Cover:Left:Scanner:EU	1
4	G564 6521	Left Scale - NA	1
4	G564 6511	Left Scale - EU	1
5	AC01 2067	Exposure Glass	1
6	B077 1330	Cover:Upper Rear:Scanner (NA)	1
6	B077 6335	Cover:Upper Rear:Scanner:EU	1
7	G570 1245	Rear Scale	1
8	B077 1336	Cover:Right:Scanner (NA)	1
8	B077 6336	Cover:Right:Scanner:EU	1
9	B077 1276	Cover:Arm:Right	1
10	B077 1275	Cover:Arm:Scanner Unit	1
11	AA14 3523	Shoulder Screw - M3	1
12	B082 6400	Decal:Size Indication	1
13	B082 6506	Operating Instructions:Main:RIC:CHN: Chinese	1
13	B082 6508	Operating Instructions:Main:RIC:AA:English	1
13	B082 6509	Operating Instructions:Main:RIC:TWN: Taiwan	1
13	B082 6510	Operating Instructions:Main:RIC:GSA: English	1
13	B082 6606	Operating Instructions:Copy:RIC:CHN: Chinese	1
13	B082 6608	Operating Instructions:Copy:RIC:AA:English	1
13	B082 6609	Operating Instructions:Copy:RIC:TWN: Taiwan	1
13	B082 6610	Operating Instructions:Copy:RIC:GSA: English	1
14	C225 2866	Decal - Keytop Cover (REX)	1
14	C225 2867	Decal - Keytop Cover (NSA)	1
15	B065 1371	Cloth Holder	1
16	B065 1374	Cloth - DF Exposure Glass	1

Index No.	Part No.	Description	Q'ty Per Assembly
17	B387 6053	Original Scale Decal - A4	1
17	B387 6054	Original Scale Decal - LT	1
101	0451 3008H	Tapping Screw - M3x8	
102	0451 3012H	Tapping Screw - 3x12	
103	0451 3010H	Tapping Screw - 3x10	
104	0804 6075	Hexagonal Bolt - M3x8	

2.EXTERIOR 2 (B079/B082)




2.EXTERIOR 2 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B077 1264	Cover:Front Upper:Paper Feed Sub-UN	1
2	B079 6431	Decal EMBLEM (RIC)(B079)	1
2	B079 6433	Decal EMBLEM (GES NA)(B079)	1
2	B079 6434	Decal EMBLEM (GES EU)(B079)	1
2	B079 6435	Decal EMBLEM (NSA)(B079)	1
2	B079 6436	Decal EMBLEM (REX)(B079)	1
2	B079 6437	Decal EMBLEM (INF)(B079)	1
2	B079 6438	Decal EMBLEM (LAN)(B079)	1
2	B082 6431	Decal EMBLEM (RIC)(B082)	1
2	B082 6433	Decal EMBLEM (GES NA)(B082)	1
2	B082 6434	Decal EMBLEM (GES EU)(B082)	1
2	B082 6435	Decal EMBLEM (NSA)(B082)	1
2	B082 6436	Decal EMBLEM (REX)(B082)	1
2	B082 6437	Decal EMBLEM (INF)(B082)	1
2	B082 6438	Decal EMBLEM (LAN)(B082)	1
3	B077 1261	Cover:Front:Ass'y	1
3	B077 6316	Cover:Front:EU:Ass'y	1
4	G020 1332	Hinge - Front Cover	2
5	GA00 3035	Energy Decal	1
6	B082 6405	Sheet:Operation Instructions:RIC	1
7	B077 1286	Stopper:Left	1
8	B077 1285	Cover:Left:Paper Feed Sub-unit (NA)	1
8	B077 6324	Cover:Left:Eu	1
9	B077 2724	Cover:Knob	1
10	B077 2720	Bracket:Knob:Ass'y	1
11	AA04 3416	Timing Belt - 40S3M192	1
12	AB03 0584	Timing Pulley - 15T	1
13	A232 2722	Knob	1
14	AB03 0564	Pulley - M17	1
15	B077 2723	Supporting Plate:Knob	1
16	A232 1282	Cap - Switch	1
17	B082 6403	Decal:Power Source:Off:Exp	1
18	B077 6302	Cover:Left Front:NA	1
18	B077 6305	Cover:Left Front:EU	1
19	B077 1283	Cover:Left Rear (NA)	1

Index No.	Part No.	Description	Q'ty Per Assembly
19	B077 6325	Cover:Left Rear:EU	1
20	B082 1272	Cover:Right Rear:Duplex (NA)	1
20	B082 6319	Cover:Right Rear:Duplex:EU	1
21	A232 2862	Driven Roller	2
22	AA08 0275	Bushing:Pressure:Mm4	4
23	AA06 3662	Compression Spring	2
24	B077 2858	Supporting Plate:Upper	1
25	A232 2860	Entrance Seal	1
26	AA00 1392	Decal - A1	1
27	AG07 0019	Magnet Catch:Ass'y	1
28	B077 2857	Cover:Vertical Transport	1
28	B077 2861	Cover:Vertical Transport:Duplex:EU	1
29	A232 5838	Spring Plate - BICU	1
30	B077 2859	Supporting Plate:Lower	1
31	AA06 3564	Tension Spring	2
32	A232 2863	Stopper Band	1
33	5206 2686	Snap Ring	1
34	B077 2876	Cover:Vertical Transport:Lower	1
35	AA00 0204	Decal - Right Lower Cover	1
101	0451 3008H	Tapping Screw - M3x8	
102	0450 3008B	Tapping Screw - M3x8	
103	0450 3012B	Tapping Screw - 3x12	
104	0451 3006B	Tapping Screw - M3x6	
105	0720 0060E	Retaining Ring - M6	

3.EXTERIOR 3 (B079/B082)




3.EXTERIOR 3 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B077 4497	End Fence:Copy Tray:C3	1
2	B077 4436	Guide:Copy Tray:Auxiliary	1
3	B077 4435	Guide:Copy Tray	1
4	AA15 3070	Dehumidifier Sheet	1
5	B077 1382	Guide Plate:Scanner Unit:Peen	1
6	B077 1384	Supporting Plate:Arm:Scanner Unit	1
7	B077 1385	Arm:Scanner Unit	1
8	G065 1173	Sheet - Duct	1
9	G065 1174	Sheet - Duct - Upper	1
10	B077 1291	Cover:Rear (NA)	1
10	B077 6328	Cover:Rear:EU	1
11	A232 1257	Cap - Upper Cover	1
12	B082 1296	Cover:Rear:Paper Feed Sub-unit (NA)	1
12	B082 6332	Cover:Rear:EU	1
13	B004 4440	Middle Guide - Paper Exit	1
14	A232 4499	Copy Tray Mylar	2
15	A232 1284	Spring Holder	2
16	B077 1297	Cover:Rear:Paper Feed Sub-unit	1
16	B077 6330	Cover:Rear:Paper Feed Sub-unit:EU	1
17	B077 1373	Bracket:Scanner Unit:Rear:Peen	1
18	B077 1371	Bracket:Scanner Unit:Front:Peen	1
19	B082 1362	Spacer:Scanner Unit:Duplex (NA)	1
19	B082 6342	Spacer:Scanner Unit:Duplex:EU	1
20	B077 1363	Plate Nut:Spacer:Scanner Unit	2
21	B077 1364	Ground Plate:Spacer:Rear	1
22	B077 1365	Ground Plate:Spacer:Front	1
23	B082 1372	Inner Cover:Upper	1
24	AG07 1010	Magnet Catch	1
25	B004 1325	Cover - Shield Glass	1
26	A284 1376	Inner Cover-left	1
27	B077 1251	Cover:Connector:Scanner	1
28	AX31 0039	Total Counter	1
29	A232 1381	Decal - Total Counter	1
30	AA15 3390	Sponge - 202x3.5x4	1
31	A232 1251	Duct Cover - Lower Exhaust Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
32	AA15 0685	Seal - 215x10	1
33	B077 1252	Cover:Upper Right:Small (NA)	1
33	B077 6312	Cover:Upper Right:Small:EU	1
34	AA14 3501	Stepped Screw - M8	2
35	B077 1250	Cover:Upper (NA)	1
35	B077 6314	Cover:Upper:EU	1
36	B077 1253	Cap:34x55	2
37	B077 6308	Cover:Css:Exp	1
101	0451 3008H	Tapping Screw - M3x8	
102	0450 3006B	Tapping Screw - M3x6	
103	0354 0080B	Screw - M4X8	
104	0451 4010B	Tapping Screw - 4x10	
105	0451 3006B	Tapping Screw - M3x6	
106	1105 0487	Harness Clamp	
107	0450 3008H	Tapping Screw - M3x8	

4.PLATEN COVER (B079/B082)




4.PLATEN COVER (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
*	G329 1232	Pressure Plate:Ass'y	1
1	G329 1320	Platen Cover Sheet	2
2	G329 1330	Cushion - Platen Cover	1
3	B406 1387	Front Platen Cover	2
4	A053 1957	Flex Hinge - Platen Cover	1
5	B406 1397	Original Holder	1
6	G329 1383	Feeler - Platen Cover Sensor	1
7	B406 1392	Rear Platen Cover	1
8	A193 1248	Platen Cover Hinge Assembly	1
9	G329 1384	Bracket - Platen Cover	1
10	5215 1667	Platen Cover Stud	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 4012B	Tapping Screw - M4x12	

5. OPERATION PANEL ASS'Y (B079/B082)




5.OPERATION PANEL ASS'Y (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B082 6350	Operation Sub-unit:NA:Ass'y	1
1	B082 6360	Operation Sub-unit:EU:Ass'y	1
1	B082 6370	Operation Sub-unit:TW:Ass'y	1
1	B082 6375	Operation Sub-unit:CHN:Ass'y	1
1	B082 6380	Operation Sub-unit:KOR:Ass'y	1
1	B082 6385	Operation Sub-unit:AA:Ass'y	1
2	B004 1517	Earth Sheet - Touch Panel	1
3	B082 5219	Touch Panel:HVGA	1
4	B004 1525	Cushion:Touch Panel:Short	2
5	B004 1526	Cushion:Touch Panel:Long	2
6	B082 5218	LCD:H-VGA:HLM777:BI	1
7	B077 1520	Bracket:LCDC	1
8	B082 5203	PCB:LCDC:NA:Ass'y	1
8	B082 5204	PCB:LCDC:EU:Ass'y	1
8	B082 5205	PCB:LCDC:TW:Ass'y	1
8	B082 5206	PCB:LCDC:CHN:Ass'y	1
8	B082 5207	PCB:LCDC:KOR:Ass'y	1
9	B077 1521	Cover:LCDC	1
10	B077 1513	Dial:Contrast	1
11	B077 1511	Keytop:Counter	1
12	B004 1516	Sheet-preventfence Sheet-Left	1
13	B004 1519	Operation Panel Board - Left	1
14	B004 1503	Keytop - Clear/Stop	1
15	B077 1506	Keytop:Power Source	1
16	B077 1504	Keytop:Try Print	1
17	B004 1505	Keytop - Start	1
18	B077 1510	Keytop:Confirm	1
19	B077 1509	Keytop:Block Diagram	1
20	B077 6358	Keytop:Clear Modes	1
21	B077 1508	Keytop:Preheat	1
22	B077 1512	Keytop:Interrupt	1
23	B077 6355	Keytop:10key:NA	1
23	B077 1502	Keytop:10key (EU/TWN)	1
23	B077 6387	Keytop:10key:AA	1
24	B004 1515	Sheet - Prevent Fence Sheet - Right	1

Index No.	Part No.	Description	Q'ty Per Assembly
25	B004 1518	Operation Panel Board - Right	1
26	B077 1535	Cover:Basic	1
27	B077 1534	Cover:Application	1
28	B077 6354	Sheet:Caption:NA	1
28	B077 6372	Sheet:Caption:TW	1
28	B077 6377	Sheet:Caption:CHN	1
29	B077 6356	Keytop:Copy:1:NA	1
29	B077 6366	Keytop:Copy:1:EU	1
30	B077 6357	Keytop:Copy:2:NA	1
30	B077 6367	Keytop:Copy:2:EU	1
31	B077 6352	Sheet:Power Source:NA	1
31	B077 6362	Sheet:Power Source:EU	1
32	B077 6353	Case:Operation Sub-unit:NA	1
32	B077 6363	Case:Operation Sub-unit:EU	1

6.OPTICS UNIT 1 (B079/B082)




6.OPTICS UNIT 1 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B077 1678	Stay:Right	1
2	AX64 0128	Fan Motor - DC 24V 1.44W	1
3	B077 1742	Bracket:Fan	1
4	AW01 0056	Original Sensor - H=2-66	2
5	B082 1676	Bracket:Scale:Left	1
6	B351 6523	Seal - ADF Exposure Glass	1
7	B351 6522	ADF Exposure Glass	1
8	B077 1681	Inner Cover:Ass'y	1
9	B082 1831	Holder:Lens:Adonis-C3:Ass'y	1
10	AZ50 0062	Stabilizer:Xenon Lamp	1
11	B077 1739	Bracket:Hinge	1
12	AW02 0100	Photointerrupter - P1CH2MM	1
13	B077 1849	Bracket:Connector:ARDF	1
14	B082 5541	Harness:Scanner:ADF	1
15	B004 5542	Harness - Sbu-50wick 80mm	1
16	B082 5543	Harness:SIB	1
17	B004 1841	Scanner Interface Cable	1
18	B082 5387	PCB:SIB	1
19	B082 5538	Harness:OPU	1
20	B004 5397	Motor Drive Board	1
21	B077 1846	Bracket:MDB:Left	1
22	B077 1847	Bracket:MDB:Right	1
23	AA06 0702	Tension Spring	1
24	B077 1751	Stepper Motor:Scanner:Ass'y	1
25	AW01 0059	Original Sensor - H=1-66	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0060B	Philips Pan Head Screw - M3x6	
102	0802 5276	Tapping Screw With Washer - M3x6	
103	0451 3006B	Tapping Screw - M3x6	
104	0314 0120B	Philips Pan Head Screw - M4x12	
105	1105 0162	Locking Support	
106	0451 3008H	Tapping Screw - M3x8	
107	0314 0180B	Philips Pan Head Screw - M4x18	

7.OPTICS UNIT 2 (B079/B082)




7.OPTICS UNIT 2 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B077 1801	Carriage:No.2:Ass'y	1
2	A232 1808	Harness Guide	1
3	G404 2810	Spring Plate - 2nd Mirror	4
4	B004 1820	2nd Mirror Ass'y	2
5	B004 1809	Carriage Pulley - 22mm	2
6	AX50 0083	Xenon Lamp:Mm8.5	1
7	B082 1842	Flexible Board:Ass'y	1
8	B077 1792	Clamp:Wire:Rear	1
9	B077 1791	Clamp:Wire:Front	1
10	B077 1781	Carriage:No.1:Ass'y	1
11	A232 1789	1st Mirror Holder	2
12	AC03 0110	Scanner Mirror	1
13	AA15 0721	Shield:Side Plate:Left	2
14	A284 1674	Exposure Glass Holder	4
15	AA15 0722	Shield:Side Plate:Front Rear:Left Middle	1
16	AA15 0723	Sheet:Left	1
17	AA15 0724	Sheet:Left Middle	1
18	AA15 0725	Sheet:Right	1
19	AA16 1133	Cushion - 4x15x1	2
20	B082 1736	Side Plate:Front	1
21	B082 1738	Side Plate:Rear	1
22	AW02 0120	Photointerruptor - Flat	1
23	B077 1844	Bracket:Home Position Sensor	1
24	B077 1728	Base:Scanner:Rear	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0951 3006B	Philips Screw With Flat Washer-M3x6	
103	1005 0728	Rivet - NRP335	
104	1105 0516	Clamp	
105	1105 0508	Harness Clamp - LWS-0711	

8.OPTICS UNIT 3 (B079/B082)




8.OPTICS UNIT 3 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 1728	Bracket - Heater	2
2	AX40 0140	Heater - 120V 15W	1
2	AX40 0142	Heater - 240V 15W	1
3	B004 1741	Bracket:Power Supply Cord:Heater:Exp:Ass'y	1
4	B004 1742	Bracket:Power Supply Cord	1
5	A232 1728	Rail Supporter	2
6	A232 1731	Scanner Rail	2
7	A232 1707	Second Slide Rail	2
8	AA15 0711	Shield -base	1
9	B004 1726	Rail - Flexible Board	1
10	B004 1713	Pulley 2 - 22MM	2
11	AA05 0106	Carriage Drive Wire	2
12	AA06 0703	Tension Spring	2
13	B077 1722	Bracket:Tension:Wire:Rear	1
14	A232 1771	Drive Shaft	1
15	A232 3566	Ball Bearing - 8x16x5	1
16	AB03 2062	Rear Scanner Pulley	1
17	AB03 0572	Timing Pulley - Z61	1
18	AA04 3439	Timing Belt - S2M-224	1
19	B004 1714	Idler Bracket	2
20	A232 1713	Lens Block Supporter	2
21	AH01 0009	Rubber Pad - H5	4
22	AB03 2061	Front Scanner Pulley	1
23	B077 1712	Bracket:Tension:Wire:Front	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0802 5276	Tapping Screw With Washer - M3x6	
103	0450 3008B	Tapping Screw - M3x8	
104	0314 0060B	Philips Pan Head Screw - M4x6	
105	0801 0149	Philips Pan Head Screw - M4x6	
106	1105 0487	Harness Clamp	
107	1105 0292	Wire Saddle	
108	0575 0050E	Hexagon Headless Set Screw - M5x5	
109	0720 0060E	Retaining Ring - M6	

9.LASER UNIT (B079/B082)




9.LASER UNIT (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B082 1871	Imaging Unit:Na:Ass'y	1
1	B082 1870	Imaging Unit:Adonis-C3:Ass'y (EU)	1
2	G029 1980	Decal - LD	1
3	B077 1904	Cap:Cover:Optical Housing	1
4	B077 1907	Supporting Plate:Cover:Imaging Unit	1
5	A284 1904	Cover - Optical Housing	1
6	AC01 5025	Shield Glass	1
7	B082 5445	Harness:Imaging Unit	1
8	B082 1891	Laser Diode Unit:Adonis-C3:Ass'y	1
9	A232 1900	Housing - Laser Unit	1
10	AX06 0245	Polygon Scanner:27.20rpm:W	1
11	B002 1898	Heat Sink:Polygon Scanner:M:Ass'y	1
12	A232 1920	Seal - Heat Sink	1
13	A232 1927	Cylindrical Lens Holder	1
14	G020 1966	Cylindrical Lens	1
15	AC01 5024	Shield Glass - Polygon Motor	1
16	A232 1926	Mirror Holder	2
17	AC03 0115	Mirror	1
18	A232 1925	Middle Mirror Holder	1
19	A232 1923	Front Holder - BTL	1
20	G020 1969	BTL Lens	1
21	A232 1924	Rear Holder - BTL	1
22	A232 1921	Front Holder - F Theta Mirror	1
23	G020 1968	F Theta Mirror	1
24	A232 1922	Rear Holder - F Theta Mirror	1
25	GC03 0020	Sync. Detector Mirror	1
26	A232 1928	Holder - Sync. Detector Mirror	1
27	A293 5310	Sync Detector Board	1
28	G020 1917	Decal - LD	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3010B	Tapping Screw - M3x10	
102	0450 3008B	Tapping Screw - M3x8	
103	0951 3008B	Philips Screw With Flat Washer-M3x8	

10.BY-PASS FEED UNIT 1 (B079/B082)




10.BY-PASS FEED UNIT 1 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B077 6106	Cover:Holder:Middle	1
2	B082 6095	Frame:Holder:Ass'y	1
3	B077 6109	Cover:Manual Feed:Front	1
4	B077 6108	Cover:Manual Feed:Inner Back	1
5	B077 6107	Cover:Contact Point	1
6	B077 6090	Bracket:Support Stay	1
7	A232 6091	Positioning Pin	1
8	AA08 2070	Bushing - 8x16x7	1
9	AA06 6574	Torsion Spring	1
10	B077 6067	Manual Feed Table	1
11	B077 6068	Cover:Manual Feed Table	1
12	A232 6082	Front Rack	1
13	G011 3305	Gear - 16T	1
14	A232 6083	Rear Rack	1
15	A232 6080	Paper Size Detector	1
16	B082 6073	Decal:Manual Feed Direction	1
17	G060 2905	Paper Guide - Manual Feed Tabl	1
18	A232 6092	Roller - Holder	1
19	B077 6070	Side Fence:Inner Back	1
20	B077 6072	Side Fence:Auxiliary:Rear	1
21	B077 6069	Side Fence:Front	1
22	B077 6071	Side Fence:Auxiliary:Front	1
23	AF04 0559	Driven Roller - M9	1
24	B082 6009	By-pass Feed Table Ass'y	1
25	B004 6024	Supporting Plate:Contact Point	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008H	Tapping Screw - M3x8	
102	1105 0349	Edge Saddle	
103	0720 0060E	Retaining Ring - M6	
104	0451 3008B	Tapping Screw - M3x8	
105	0451 4010B	Tapping Screw - 4x10	
106	0450 3010B	Tapping Screw - M3x10	

11.BY-PASS FEED UNIT 2 (B079/B082)




11.BY-PASS FEED UNIT 2 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5447 2681	Snap Ring	2
2	AF03 2046	Separation Roller - Manual Feed	1
3	B004 2783	Torque Limiter	1
4	B082 6033	Shaft:Separator:Driven:Ass'y	1
5	AA06 3499	Pressure Spring	1
6	AF01 3016	Bottom Plate Pad	1
7	AB01 1389	Gear - 20Z	1
8	AB01 1388	Gear - Z16	1
9	A232 6035	Shaft - Drive Roller	1
10	B082 6028	Guide Plate:Separator:Ass'y	1
11	B077 6039	Cover:Gear	1
12	AF03 1046	Feed Roller - Manual Feed	1
13	B077 6022	Housing:Manual Feed	1
14	5216 4198	Stepped Screw - Guide Plate	4
15	A232 6023	Grounding Plate - Reverse	1
16	A232 6055	Paper End Feeler	1
17	A134 2661	Feeler Roller	1
18	AF04 0031	Driven Roller	2
19	AW02 0120	Photointerruptor - Flat	1
20	A232 6043	Arm Paper Pick Up	1
21	AA14 0753	Feed Shaft	1
22	AF03 0049	Pick-up Roller	1
23	AB01 1387	Gear - 23Z	1
24	B077 6044	Guide Plate:Feed	1
25	A232 6046	Grounding Plate - Feed	1
26	AA06 3568	Pressure Spring	1
27	A232 6051	Pickup Solenoid	1
28	B082 5427	Harness:Manual Feed Unit	1
29	AA06 3567	Tension Spring	1
30	AA08 3018	Roller Clutch - 6x14x10	1
31	AX20 0140	Electrical Clutch	1
32	AB01 7454	Gear - 24Z/30Z	1
33	B082 6059	Arm:Tightener:Ass'y	1
34	AB01 1390	Gear - 27Z	1
35	GA08 0002	Bushing - 6mm	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	AA06 3569	Spring	1
37	A232 6049	Solenoid Bracket	1
38	B082 6061	Bracket:Drive:Ass'y	1
39	B077 6065	Rail:Holder	1
40	A134 2843	Spacer 6x30x1.5	2
41	B004 6062	Pressure Plate - By-pass Feed	1
42	AF04 0575	Driven Roller	1
101	0451 3008B	Tapping Screw - M3x8	
102	0805 3480	Bushing - 6mm	
103	0720 0040E	Retaining Ring - M4	
104	1105 0267	Harness Clamp - YMC-10-0	
105	0353 0040B	Screw - M3X4	
106	0450 3008B	Tapping Screw - M3x8	

12.PAPER TRAY UNIT (B079/B082)




12.PAPER TRAY UNIT (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B082 2903	Paper Tray:Universal:Ass'y	1
2	B077 2940	Tray Bottom Plate:Ass'y	1
3	AF01 3006	Bottom Plate Pad	1
4	B082 2920	Side Fence:Front:Ass'y	1
5	B077 2921	Side Fence:Front	1
6	B004 2922	Release Lever - Side Fence	1
7	B004 2923	Spring Plate - Release Lever	1
8	B082 2925	Shield:Side Fence:Ass'y	2
9	B082 2965	Decal:Paper Set Direction	1
10	B077 2988	Cover:Grip:C3	1
11	AF01 7026	End Fence	1
12	B077 2952	Shoe:Left	1
13	A232 2987	Roller - Paper Tray	2
14	B004 2936	Gear - 16Z	1
15	B082 2930	Side Fence:Rear:Ass'y	1
16	B077 2931	Side Fence:Rear	1
17	B004 2933	Rear Stopper	1
18	B004 2932	Rear Stopper Lever	1
19	B004 2934	Spring Plate - Lock Lever	1
20	B082 2937	Paper Stopper:Side Fence	1
21	B082 2955	Dial:Paper Size Sensor:Printing	1
22	B004 2948	Paper Size Sensor	1
23	B004 2947	Spring Plate-paper Size Sensor	1
24	B004 2943	Grounding Plate - Paper Tray	1
25	B004 2915	Bottom Lift Shaft	1
26	A235 2979	Feeler - Paper Height Sensor	1
27	B077 2951	Stopper:Right:Paper Tray	1
28	B077 2975	Lever:Rise	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0353 0060B	Philips Pan Head Screw - M3x6	
103	0452 3008B	Tapping Screw - M3x8	
104	0450 3008B	Tapping Screw - M3x8	
105	0720 0060E	Retaining Ring - M6	

13.PAPER FEED SECTION (B079/B082)




13.PAPER FEED SECTION (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AB01 4090	Gear - 18Z	1
2	B077 2780	Stay:Feed	1
3	A232 2785	Vertical Guide	1
4	B082 2750	Paper Feed Unit:Ass'y	1
5	B077 2781	Bracket:Sensor	1
5	B082 2781	Bracket:Sensor (1st Tray)	1
6	AW01 0084	Photo Refiection Sensor:Paper Feed (1st Tray)	1
6	AW02 0096	Photointerruptor	1
7	AF03 0049	Pick-up Roller	1
8	AB01 1188	Gear - 21Z	1
9	5447 2681	Snap Ring	2
10	AF03 1049	Feed Roller	1
11	AB01 1189	Gear - 18Z	1
12	AA08 2070	Bushing - 8x16x7	1
13	A232 2763	Pick-up Arm	1
14	AA06 0691	Tension Spring	1
15	A232 2765	Front Grounding Plate	1
16	B082 2760	Housing:Paper Feed Unit	1
17	A232 2766	Feed Mylar	1
18	A232 2762	Paper End Feeler	1
19	AA08 2072	Bushing - M6	3
20	B082 2784	Shaft:Separate:Drive:Ass'y	1
21	AF03 2049	Separation Roller	1
22	B004 2783	Torque Limiter	1
23	B004 2777	Shaft - Paper Separation	1
24	B004 2782	Rear Feed Mylar	1
25	G065 2776	Release Lever	1
26	5206 2686	Snap Ring	2
27	AA06 0693	Tension Spring	1
28	G065 2774	Pressure Lever	1
29	AB01 0157	Gear:Separate:Driven	1
30	AB01 0156	Gear:Separate:Drive	1
31	B077 2770	Stay:Separate:Ass'y	1
32	G065 2775	Link Lever	1

Index No.	Part No.	Description	Q'ty Per Assembly
33	AA06 0908	Release Spring	1
34	A232 2764	Rear Grounding Plate	1
35	AA14 0655	Shaft - Paper Feed	1
36	G065 2767	Lever - Feed	1
37	AW02 0120	Photointerruptor - Flat	2
38	B082 5428	Harness:Paper Feed Unit	1
38	B082 5430	Harness:Paper Feed Unit:No.1	1
39	AF02 0404	Transport Roller	1
101	0451 3008B	Tapping Screw - M3x8	
102	0450 3008B	Tapping Screw - M3x8	
103	0451 3006B	Tapping Screw - M3x6	
104	0720 0060E	Retaining Ring - M6	
105	0720 0040E	Retaining Ring - M4	
106	0805 0089	Retaining Ring - M4	
107	0805 3480	Bushing - 6mm	
108	1105 0283	Clamp	

14.VERTICAL TRANSPORT (B079/B082)




14.VERTICAL TRANSPORT (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5447 2681	Snap Ring	2
2	AA15 3393	Frame Seal - Rear Vertical	1
3	B082 5470	Harness:Connecting:Right Rear	1
4	AA15 3391	Frame Seal - Rear Right	1
5	A232 3950	Hook Lever	1
6	A232 3962	Spring Plate - Band Stopper	1
7	A232 3963	Band Stopper	1
8	B082 3992	Decal:Drum:Belt	1
9	B077 1305	Inner Cover:Right	1
9	B077 6322	Inner Cover:Right:EU	1
10	B077 3999	Lever:Handle:C3	1
11	B004 4330	Screw - 4.5MM	1
12	AF04 0571	Guide Roller	3
13	B082 4322	Guide Plate:Exit:Entrance	1
14	B004 4329	Grounding Plate - Exit Sensor	1
15	B082 5466	Harness:Sensor:Fusing:Used Toner Sensor	1
16	B077 4323	Bracket:Paper Feed Sensor	1
17	A232 3998	Upper Entrance Guide	1
18	A232 3999	Lower Entrance Guide	1
19	AW01 0061	Paper Feed Sensor:Fusing Exit	1
20	A232 3948	Rear Hook - Right Cover	1
21	AA06 6576	Torsion Spring	1
22	AA14 0666	Shaft - Hook	1
23	AA06 6575	Torsion Spring	1
24	A232 3945	Front Hook - Right Cover	1
25	AA15 3392	Sponge - 24x6x5	1
26	B082 3943	Cover:Right:EU	1
27	AA08 2079	Bushing - 6x8x5.8	1
28	A232 3942	Stopper - Right Cover	1
29	B082 3956	Cover:Fan	1
30	AX64 0143	Fan:Sirocco:DC24V:3350rpm	1
31	B082 3945	Shaft:Contact Point:Cover:Right	1
32	B082 3951	Duct:Cooling:Fusing:Right	1
33	B082 3952	Bracket:Fan	1
34	B082 4199	Shielding Plate:Cover:Right	1

Index No.	Part No.	Description	Q'ty Per Assembly
35	B082 5466	Harness:Sensor:Fusing:Used Toner Sensor	1
36	B004 4328	Roller:Driven:Ass'y	1
37	B004 4327	Bushing - 4mm	2
38	AA06 3855	Spring - 3.5n	2
101	0802 5276	Tapping Screw With Washer - M3x6	
102	0450 3008B	Tapping Screw - M3x8	
103	0451 3006B	Tapping Screw - M3x6	
104	0453 3025B	Binding Self-Tapping Screw:M3x25	
105	0720 0060E	Retaining Ring - M6	
106	1105 0165	Flat Cable Clamp	

15.PAPER REGISTRATION (B079/B082)




15.PAPER REGISTRATION (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AG05 0085	Registration Roller Knob	1
2	AB01 3485	Gear - 20Z	1
3	AA08 2080	Bushing - M8	2
4	AB01 4051	Gear - 16Z	1
5	AA08 0229	Front Bushing - M6	1
6	AA06 2304	Pressure Spring	2
7	A232 2578	Stopper - Guide Plate	2
8	AA06 6577	Torsion Spring	1
9	B077 3985	Link:Cover:Ass'y	1
10	AA14 9291	Pin - Link	1
11	B077 2596	Link:Guide Plate:Open And Close	1
12	5206 2686	Snap Ring	1
13	B082 2575	Grip:Guide Plate	1
14	AA00 1393	Decal - A2	1
15	B082 2614	Bracket:Registration Roller	1
16	B082 2611	Case:Registration Roller:Ass'y	1
17	B077 2583	Guide Plate:Entrance:Lower:Adhesion	1
18	B077 2594	Bracket:Registration Sensor	1
19	AW01 0048	Photosensor - GP2A28N1	1
20	B082 5420	Harness:Registration Sensor	1
21	B082 2574	Guide Plate:Entrance:Upper:Peen	1
22	AA06 2305	Tension Spring	1
23	AF02 1059	Driven Registration Roller	1
24	AF02 0410	Registration Roller	1
25	A232 1074	Guide - Transfer Entrance	1
26	B082 1073	Stay:Drum:Lower	1
27	AA15 3442	Shield - Stay - PCU	1
28	B082 2603	Cleaner:Registration Roller:Ass'y	1
29	B082 2602	Case:Cleaner:Registration Roller	1
30	B004 2310	Spur	8
31	B082 2403	Supporter:PCU	1
32	A232 2366	Holder - ID Sensor	1
33	A232 2367	ID Sensor	1
34	A232 1284	Spring Holder	1
35	AD02 1127	Receptacle	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	AA06 3304	Terminal Spring	2
37	AX20 0138	Electrical Clutch - Mice-13	1
38	AA08 0230	Rear Bushing - M6	1
101	0450 3008B	Tapping Screw - M3x8	
102	0802 5276	Tapping Screw With Washer - M3x6	
103	0451 3006B	Tapping Screw - M3x6	
104	0720 0040E	Retaining Ring - M4	
105	0720 0020E	Retaining Ring - M2	
106	0313 0060B	Philips Pan Head Screw - M3x6	
107	0720 0060E	Retaining Ring - M6	
108	1102 6246	Relay Connector - 4P	
109	1105 0283	Clamp	
110	0353 0060B	Philips Pan Head Screw - M3x6	

16.TONER HOPPER UNIT (B079/B082)




16.TONER HOPPER UNIT (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B082 3208	Toner Supply Unit:C3:Ass'y	1
2	A232 3266	Seal - Slide Rail	2
3	B077 3262	Slide Rail:Toner Supply Unit	1
4	AA14 5810	Slide Shaft	1
5	A232 3261	Handle - Toner Supply	1
6	A232 3263	Spring Plate - Toner Bottle	1
7	A232 3230	Case - Toner Supply Ass'y	1
8	AA15 3083	Seal - Toner Supply Unit Cover	1
9	B082 3265	Decal:Caution Chart	1
10	AA06 3566	Pressure Spring	1
11	A232 3251	Chuck Shaft	1
12	A232 3252	Slider Ass'y	1
13	A134 3180	Bottle Chuck	1
14	A232 3240	Cover- Toner Bottle Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 3010B	Tapping Bind Screw - M3x10	
102	0450 3008B	Tapping Screw - M3x8	

17.DEVELOPMENT UNIT 1 (B079/B082)




17.DEVELOPMENT UNIT 1 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B082 3010	Development Unit:Ass'y	1
2	5206 2686	Snap Ring	2
3	A232 3150	Entrance Seal Ass'y	1
4	B082 3100	Development Sleeve:Ass'y	1
5	B082 3121	Shield:Development Sleeve:Front:C3	1
6	B082 3122	Shield:Development Sleeve:Rear:C3	1
7	AB01 1386	Development Sleeve Gear	1
8	AB01 1446	Gear - 29Z	1
9	AA14 3219	Stepped Screw	2
10	A232 3155	Front Cover - Development Unit	1
11	AB01 4061	Gear - 13Z	1
12	A232 3077	Spacer - M5	1
13	AB01 4060	Gear - 21Z	1
14	AA08 0234	Bushing - 12x18x6	1
15	AB01 4062	Gear - 17Z/25Z	1
16	G065 3066	Entrance Shield - Toner Supply	1
17	AA15 3054	Sponge - 17x7x5	2
18	AA15 3095	Shield - Development - Center	2
19	AA15 3053	Sponge - 317x5x5	1
20	AA01 2102	Development Filter	1
21	G065 3067	Coupling Shield	1
22	A232 3069	Rear Bias Terminal - Development	1
23	B004 3078	Joint - Paddle	1
24	B082 3123	Shield:Case:Development:Front Rear:C3	2
25	A232 3067	Tape - TD Sensor	1
26	B082 3065	Density Sensor:Development	1
27	A232 3068	Front Bias Terminal - Development	1
28	B004 3062	Ground Plate- Doctor Blade	1
29	G012 3897	Film - Toner End Sensor Harnes	1
30	AA15 3443	Mylar -development Unit-right	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3014B	Tapping Screw - M3x14	
102	0450 3010B	Tapping Screw - M3x10	
103	0450 3008B	Tapping Screw - M3x8	
104	0720 0030E	Retaining Ring - M3	
105	0725 0110E	C Ring - M11	
106	0720 0040E	Retaining Ring - M4	
107	0805 0097	Ring Separator	

18.DEVELOPMENT UNIT 2 (B079/B082)




18.DEVELOPMENT UNIT 2 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B082 2202	PCU:Adonis-C3:Ass'y	1
2	G065 2259	Handle - PCU	1
3	G065 2251	Cover:PCU:Upper:Ass'y	1
4	G065 2328	Cap - Toner Supply	1
5	B082 2217	Stopper:PCU:C3	1
6	AA06 3646	Pressure Spring - PCU Stopper	1
7	AA06 2316	Tension Spring - Shutter	1
8	G065 2241	Shutter - Toner Supply	1
9	G065 2270	Receptacle - Charge Roller	1
10	B082 2220	Frame:PCU:Upper:Ass'y	1
11	A232 1284	Spring Holder	1
12	A232 2280	Tape - Entrance Seal	1
13	AD04 7023	Cleaning Entrance Seal	1
14	A232 3267	Front Entrance Seal - Toner Supply	2
15	AA15 0671	Shield - Collection Coil	1
16	B004 2215	Entrance Seal - Toner Supply	1
17	B082 2292	Toner Collection Coil:Ass'y	1
18	A232 2292	Bushing - Toner Collection Coil	1
19	AB01 1377	Gear - 14Z	1
20	A232 2289	Front Bushing - Collection Mylar	1
21	A232 2288	Shaft - Toner Collection Mylar	1
22	B082 2288	Collection Coil:Ass'y	1
23	A232 2290	Bushing - Collection Mylar	1
24	AB01 1378	Gear - 19Z	1
25	B082 2290	Bracket:Idler:Ass'y	1
26	AB01 1380	Cam - Cleaning Blade	1
27	AB01 1379	Gear - 19Z	1
28	B004 2212	Front Seal - Cleaning Cover	1
29	G065 2279	Entrance Seal - Toner Supply	1
30	B082 3256	Shield:Developer:Cartridge:Upper Right	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0720 0040E	Retaining Ring - M4	

19.OPC UNIT (B079/B082)




19.OPC UNIT (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B082 2316	Stud:Contact Point:Cleaning:Ass'y	1
2	G065 2282	Shield:PCU:Rail	1
3	AA14 3533	Screw:10:M3x18	1
4	A232 2340	Holder - Pick-off Pawl	2
5	AA06 2310	Pressure Spring	2
6	A232 2339	Spur	2
7	AD02 5021	Pick-off Pawl	2
8	B082 2302	Frame:PCU:Lower:Ass'y	1
9	AA00 3206	Decal:PCU:Spring:Caution Chart	1
10	5447 2681	Snap Ring	3
11	G065 2321	Front Arm - Charge Unit	1
12	AA06 3648	Pressure Spring	2
13	A232 2315	Front Bushing - Cleaning Bracket	1
14	AA06 2299	Pressure Spring	1
15	AA06 2300	Tension Spring	1
16	B082 2312	Second Cleaning Blade	1
17	A232 2318	Collar - Cleaning	1
18	G065 2326	Rear Arm - Charge Unity	1
19	A232 2308	Rear Terminal - Charge Roller	1
20	B082 2333	Terminale:Brush Roller	1
21	A232 3553	Ball Bearing - 8x16x5	1
22	A230 9510	OPC DRUM	1
23	B082 2353	Cleaning Blade:Ass'y	1
24	AA06 2255	Spring:Cleaning Blade	2
25	AD04 1095	Cleaning Blade:Ass'y	1
26	5203 1852	Bushing - 6x8x4mm	1
27	A232 2354	Front Terminal - Charge Roller	1
28	B082 2329	Brush Roller:Cleaner:Charge:Ass'y	1
29	A232 2421	Bushing - 6x10x3	2
30	AD02 7012	Roller:Charge:Apply	1



Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0451 3008B	Tapping Screw - M3x8	
103	0450 3006B	Tapping Screw - M3x6	
104	0720 0040E	Retaining Ring - M4	
105	0451 3006B	Tapping Screw - M3x6	

20.TRANSFER UNIT (B079/B082)




20.TRANSFER UNIT (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 3914	Mylar - Belt Drive Roller	1
2	A232 3907	Seal - Transfer Exit	1
3	A232 3906	Seal - Rear Transfer Exit	1
4	A232 3905	Seal - Shield Plate	1
5	A232 3927	Shield - Transfer Belt - Exit	2
6	A232 3830	Cleaning Blade - Transfer Belt	1
7	B082 3923	Bracket:Cleaning Blade:0.6	1
8	A232 3909	Seal - Front Case	1
9	A232 3908	Seal - Rear Case	1
10	A232 3880	Transfer Belt	1
11	B082 3867	Shield:Remove Paper Dust	1
12	B077 3917	Lever:Release:Pressure:Peen	1
13	A232 3924	Rear Bushing - Cleaning Holder	1
14	AB01 4189	Gear - 27Z	1
15	AA06 0927	Springcleaning Blade:5.1n	2
16	AA15 0401	Seal - 70x20	2
17	AA06 3305	Torsion Spring	2
18	A232 3921	Spring Anchor	2
19	A232 3935	Shaft - Transfer Unit Stopper	1
20	A232 3925	Front Bushing - Cleaning Holder	1
21	B004 3900	Case - Transfer Unit	1
22	A232 3916	Pressure Lever - Transfer Belt	2
23	B077 3914	Lever:Front	1
24	B077 3913	Lever:Rear	1
25	A232 3883	Spring Plate - Transfer Unit	1
26	A232 3885	Driven Roller - Transfer Unit	1
27	A232 3887	Rear Terminal - Transfer Belt	1
28	AA08 2054	Bushing - M4	1
29	AA06 0712	Torsion Spring	2
30	A232 3889	Bias Roller	1
31	AA08 0246	Bushing - Bias Roller	1
32	A232 3926	Transfer Belt Roller	2
33	A232 3882	Flange - Transfer Unit	1
34	A232 3891	Bias Terminal	1
35	A232 3893	Arm - Transfer Belt	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A232 3894	Drive Roller - Transfer Belt	1
37	AB01 1190	Gear - 25Z	1
38	AW31 0006	Toner Overflow Sensor	1
	 		
101	0450 3008B	Tapping Screw - M3x8	
102	0951 3006B	Philips Screw With Flat Washer-M3x6	
103	0451 3006B	Tapping Screw - M3x6	

21.FUSING UNIT 1 (B079/B082)




21.FUSING UNIT 1 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B082 7320	Fusing Unit:NA:Ass'y	1
1	B082 7720	Fusing Unit:EU:Ass'y	1
2	B004 4133	Cap- Fusing Cover	1
3	B004 4135	Guide Plate-fusing Exit	1
4	AA14 3520	Shoulder Screw - M3	3
5	B082 4131	Fusing Cover:Printing	1
6	B082 4144	Shield:Fusing Cover	1
7	B082 4148	Shield:Cover:Upper	1
8	B082 4147	Cover:Duct:Fusing:Front	1
9	B082 4149	Shield:Cover:Lower	1
10	B082 4142	Duct:Fusing:Front	1
11	B082 4145	Shield:Duct:Front Lower	1
12	B082 4152	Duct:Fusing:Front Lower	1
13	B082 4153	Shield:Duct:Fusing:Front Lower:Long	1
14	B077 4092	Bracket:Drawer:Fusing:Welding	1
15	B004 4095	Terminal Plate - Fusing Unit	1
16	G065 4117	Harness - Fusing Unit(120V)	1
16	G065 4127	Harness - Fusing Unit(230V)	1
17	AE04 2054	Fusing Cleaning Roller:Ass'y	1
18	AA08 2073	Roller Busing	2
19	AA06 3664	Spring:Fusing Cleaning Roller:5n	2
20	B082 4123	Fusing Entrance Guide Plate:Upper	1
21	B004 4126	Lower Entrance Guide Plate	1
22	AA14 0140	Screw - M3X4.5	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0804 6075	Hexagonal Bolt - M3x8	
102	0451 3006B	Tapping Screw - M3x6	
103	0451 3008B	Tapping Screw - M3x8	
104	0801 0149	Philips Pan Head Screw - M4x6	
105	0957 3012B	Double Sems Screw - M3 x 12	

22.FUSING UNIT 2 (B079/B082)




22.FUSING UNIT 2 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G065 4106	Thermostat	2
2	G065 4105	Housing - Thermostat	2
3	B004 4087	Plate- Thermistor	2
4	AW10 0052	Thermistor - Center	1
5	AW10 0053	Thermistor - Rear	1
6	B077 4055	Stay:Fusing:Thermostat	1
7	B082 4111	Socket:Heater:Front	1
8	B077 4081	Frame:Fusing:Upper	1
9	AA06 0879	Tension Spring	7
10	AE04 4030	Hot Rollerstripper	7
11	B077 4115	Socket:Heater:Rear	1
12	A232 4064	C Ring - Hot Roller	2
13	AB01 3882	Gear - 40Z	1
14	AE03 0047	Ball Bearing - 30x42x7	2
15	AE01 1071	Hot Roller - 39.8mm T0.4	1
16	AX43 0090	Heater:120V:550W:215mm	1
16	AX43 0091	Heater:230V:550W:215mm	1
17	AX44 0173	Heater:120V:650W:335mm	1
17	AX44 0174	Heater:230V:650W:335mm	1
18	AG05 0094	Knob:Fusing	1
19	AE03 0048	Ball Bearing - 8x22x7	2
20	AE02 0123	Pressure Roller:Mm32:Ass'y	1
21	B082 4054	Positioning Plate Front	1
22	A232 4057	Front Collar - Pressure Lever	1
23	B077 4056	Lever:Pressure	2
24	AA06 0840	Pressure Spring - 29n	2
25	B082 4051	Frame:Fusing:Assy	1
26	AB01 4046	Gear - 25Z	1
27	A232 4058	Rear Collar - Pressure Lever	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0801 0149	Philips Pan Head Screw - M4x6	
102	0453 3006B	Tapping Screw - M3x6	
103	0451 3006B	Tapping Screw - M3x6	
104	0804 6075	Hexagonal Bolt - M3x8	
105	0720 0040E	Retaining Ring - M4	
106	0720 0030E	Retaining Ring - M3	
107	0954 3012B	Screw - M3X12	

23.PAPER SEPARATION UNIT 1 (B079/B082)




23.PAPER SEPARATION UNIT 1 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G012 3897	Film - Toner End Sensor Harnes	1
2	B082 5459	Harness:DC:Exit	1
3	B077 4494	Bracket:Paper Feed Sensor	1
4	B004 4434	Harness Guide	2
5	B077 4493	Joint:Machine Or Copier	1
6	AF04 0571	Guide Roller	7
7	B004 4453	Lower Guide Plate	1
8	AF04 0599	Pressure Roller:15	2
9	B004 4460	Shaft-pressure Roller	4
10	B004 4458	Pressure Arm - Exit	2
11	AA06 3854	Pressure Spring	2
12	B077 4463	Arm:Pressure:Entrance	2
13	B082 4466	Bracket:Contact Point:Assy	2
14	AF04 0601	Pressure Roller:Entrance	2
15	AA06 2312	Pressure Spring	2
16	AA16 1629	Pad-guide Plate	2
17	B077 4437	Supporting Plate:Frame:Left Lower	1
18	B077 4455	Frame:Left Lower	1
19	AF04 0575	Driven Roller	2
20	B004 4469	Spring Plate - Exit Roller	2
21	B077 4490	Supporting Plate:Frame:Right	1
22	AW01 0049	Photo Reflection Sensor	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0450 3006B	Tapping Screw - M3x6	
103	0353 0040B	Screw - M3X4	
104	1105 0511	Harness Clamp - LWS-0306ZC	
105	0720 0030E	Retaining Ring - M3	

24.PAPER SEPARATION UNIT 2 (B079/B082)




24.PAPER SEPARATION UNIT 2 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 4438	Bushing	2
2	B004 4478	Entrance Junction Gate	1
3	AF02 0514	Exit Roller	1
4	AA12 0115	Discharge Brush:Exit	2
5	B004 4477	Upper Guide Plate	1
6	A232 4484	Solenoid - Exit Gate	1
7	AA06 0716	Tension Spring	1
8	AA08 2058	Bushing - 6x10x9mm	4
9	AA16 1628	Link Cushion - 10x5x2	3
10	B077 4471	Side Plate:Front	1
11	AF04 0574	Guide Roller	3
12	B004 4481	Exit Junction Gate	1
13	5447 2681	Snap Ring	1
14	B077 4439	Bracket:Protect:Middle	1
15	AF02 0515	Transport Roller	1
16	AB03 0568	Pulley - 23T	1
17	B082 4472	Side Plate:Rear:Ass'y	1
18	B004 4486	DC Solenoid	1
19	AA06 0855	Return Spring	1
20	AA06 2313	Gate Pawl Spring 1.5n	1
21	B004 4479	Lever - Entrance Junction Gate	1
22	AB03 0672	Idler Pulley	1
23	AA04 3555	Timing Belt - S2M234	1
24	AB01 7458	Gear Pulley - 18Z/22T	1
25	AB01 4049	Gear - 24Z	1
26	B004 4497	Ground Plate - Discharge Brush	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0450 3006B	Tapping Screw - M3x6	
103	0353 0040B	Screw - M3X4	
104	0720 0040E	Retaining Ring - M4	

25.DUPLEX UNIT 1 (B079/B082)




25.DUPLEX UNIT 1 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B077 4720	Inner Cover:Duplex Unit:Front	1
2	B082 4852	Decal:Duplex	1
3	AF02 0511	Reverse Roller - Driven	1
4	B004 4645	Guide Plate - Middle	1
5	5447 2681	Snap Ring	1
6	B077 4730	Inner Cover:Duplex Unit:Rear	1
7	B077 4810	Cover:Harness:Duplex	1
8	B077 4793	Bracket:Link:Machine Or Copier:Ass'y	1
9	A232 4653	Pressure Plate - Guide Plate	2
10	AA08 0034	Bushing - 4x5x7	4
11	B077 4711	Cover:Duplex Unit:Right	1
12	B004 4851	Decal - Jam Removal	1
13	A232 4647	Driven Guide Plate	1
14	AF02 5036	Duplex Junction Gate	1
15	AA06 0709	Tension Spring	1
16	AA06 3303	Pressure Spring	4
17	AF02 0512	Driven Roller - Duplex	2
18	B077 4701	Cover:Duplex Unit	1
19	A680 1181	Magnetic Catch	2
20	B077 4716	Guide Plate:Right	1
21	B082 4853	Decal:Duplex Unit:Upper	1
22	AA06 0839	Pressure Spring - Driven	2
23	AA08 0307	Bushing - M4	2
24	B004 5843	Shoulder Screw	1
25	B004 5842	Gasket - Duplex Unit	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008H	Tapping Screw - M3x8	
102	0451 3006B	Tapping Screw - M3x6	
103	0450 3008H	Tapping Screw M3x8	

26.DUPLEX UNIT 2 (B079/B082)




26.DUPLEX UNIT 2 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA08 2074	Bushing - M8	4
2	B077 4684	Grip:Un Lock	1
3	AW01 0048	Photosensor - GP2A28N1	1
4	AA06 6152	Tension Spring	1
5	A232 4685	Hook - Unit Release	1
6	B077 4763	Bracket:Entrance Sensor	1
7	AA16 2046	Cushion - 347x10x5	1
8	B077 4634	Guide Plate:Reverse:Rear	1
9	AF02 0511	Reverse Roller - Driven	1
10	AA08 0307	Bushing - M4	2
11	AA06 0839	Pressure Spring - Driven	2
12	AF02 0509	Reverse Roller - Duplex	2
13	B077 4642	Side Plate:Rear:Ass'y	1
14	B077 4800	Bracket:Base	1
15	B004 5140	Main Board - Duplex	1
16	B082 5460	Harness:Duplex Unit	1
17	B082 5461	Harness:Duplex Unit:Sensor	1
18	AB03 0670	Gear - 24Z	1
19	AB01 4162	Gear - 46Z	1
20	AA04 3443	Timing Belt - S2M 140	1
21	B077 4666	Bracket:Stepper Motor:Ass'y	1
22	B004 4664	DC Motor - 28W	1
23	AB01 4161	Reverse Roller Gear	2
24	B004 4690	Link Solenoid Ass'y	1
25	B077 4638	Side Plate:Front:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0802 5276	Tapping Screw With Washer - M3x6	
103	1105 0460	Clamp	
104	0451 3006B	Tapping Screw - M3x6	
105	0720 0030E	Retaining Ring - M3	
106	1204 2466	Micro Switch - V-16506-1c25	
107	0353 0120B	Bind Screw - M3x12	
108	1105 0328	Harness Clamp - ES-0505	

27.DUPLEX UNIT 3 (B079/B082)




27.DUPLEX UNIT 3 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA04 3444	Timing Belt - S2M 350	1
2	AB03 0474	Pulley - 24T	2
3	AA08 2075	Bushing - M6	2
4	AF02 0510	Exit Transport Roller	1
5	B004 4622	Guide Plate - Right Lower	1
6	AF02 0513	Transport Roller	1
7	B077 4630	Stay:Lower	1
8	B077 4757	Bracket:Sensor:Paper Feed	1
9	AW02 0126	Photointerruptor	1
10	AA04 3443	Timing Belt - S2M 140	1
11	AB03 0671	Gear Pulley - Rransport	1
12	B077 4678	Bracket:Stepper Motor	1
13	AB01 1088	Gear - 30Z	1
14	B004 4664	DC Motor - 28W	1
15	AW01 0048	Photosensor - GP2A28N1	1
16	B077 4795	Bracket:Sensor	1
17	AA06 6335	Torsion Spring	1
18	B077 4697	Bracket:Micro Switch:Ass'y	1
19	AA14 3461	Stepped Screw - M2.5	1
20	B077 4790	Link:Duplex:Peen	1
21	B077 4796	Stay:Middle	1
22	B082 5462	Harness:Duplex Unit:Sensor	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0805 3480	Bushing - 6mm	
102	0451 3006B	Tapping Screw - M3x6	
103	1105 0291	Harness Clamp - LWS-3S	
104	1105 0328	Harness Clamp - ES-0505	
105	0802 5276	Tapping Screw With Washer - M3x6	
106	0720 0040E	Retaining Ring - M4	
107	1105 0283	Clamp	
108	1204 2466	Micro Switch - V-16506-1c25	
109	0313 0060B	Philips Pan Head Screw - M3x6	

28.DRIVE SECTION 1 (B079/B082)




28.DRIVE SECTION 1 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B082 1158	Bracket:Belt:Plate	1
2	AB03 0716	Gear - 32Z/29T	1
3	AA04 3571	Timing Belt - S3M - 180	1
4	AB03 0717	Gear - 30Z/18T	1
5	B077 1156	Bracket:Belt:Positioning:Ass'y	1
6	A232 2372	Lock Lever - Transfer Unit	1
7	AA06 2317	Tension Spring	1
8	G065 1143	Bushing - M34	1
9	AX21 0081	Transfer Unit Clutch	1
10	AW02 0097	Photointerrupter	1
11	B077 1153	Bracket:Transfer Drive:Ass'y	1
12	AA04 3570	Timing Belt - B60S2M240	1
13	AB03 0715	Timing Pulley - Transfer Unit	1
14	AB01 4222	Gear - 33Z/30T	1
15	AB01 4223	Gear - 30Z	1
16	G020 1189	Fly Wheel	2
17	G065 1128	Flange - Fly Wheel	1
18	G065 1122	Timing Pulley - 58Z/79T	1
19	AA04 3553	Timing Belt-B60S2M316	1
20	B077 1135	Bracket:Holder:OPC Drum	1
21	AB03 0714	Timing Pulley - 32Z/52T	1
22	B082 1133	Holder:OPC Drum:C3:Ass'y	1
23	G065 1118	Drum Shaft	1
24	A232 2380	Terminal Plate - Change Roller	1
25	A232 2383	Harness - Development Bias	1
26	A232 2381	Harness - Charge Roller	1
27	A232 2382	Terminal Plate - Development Bias	1
28	AA06 3371	Spring	1
29	AB01 4237	Gear:Fusing Drive Sub-unit:No.1	1
30	AB01 4238	Gear:Fusing Drive Sub-unit:No.2	1
31	B082 1160	Bracket:Fusing Drive Sub-unit:Ass'y	1
32	B077 1140	Supporting Plate:Developmen:Unit	1
33	AA04 3551	Timing Belt - B50S3M213UG (B079)	1
33	AA04 3569	Timing Belt - B50S3M228 (B082)	1
34	B079 1144	Timing Pulley:Paddle (B079)	1

Index No.	Part No.	Description	Q'ty Per Assembly
34	B082 1144	Timing Pulley:Paddle (B082)	1
35	B082 1142	Development Drive Unit:Ass'y	1
36	B077 1130	Bracket:OPC Drum:Plate	1
37	AX06 0239	Brushless Motor:Main:Ass'y	1
38	AX05 0195	DC Motor:Toner Bottle:Ass'y	1
39	B082 5437	Harness:Sensor:On-off:Connecting	1
101	0802 5276	Tapping Screw With Washer - M3x6	
102	0802 5279	Tapping Screw With Washer - M3x8	
103	0451 3008B	Tapping Screw - M3x8	
104	0451 3006B	Tapping Screw - M3x6	
105	0451 3014B	Tapping Screw - M3-14	
106	0534 0050E	Headless Screw - M4x5	
107	0633 0140G	Parallel Pin - 3x14	
108	0450 3008B	Tapping Screw - M3x8	
109	1105 0511	Harness Clamp - LWS-0306ZC	

29.DRIVE SECTION 2 (B079/B082)




29.DRIVE SECTION 2 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B082 5839	Bracket:Harness:Paper Feed	1
2	B082 5837	Bracket:I/O Board:Right Lower	1
3	B082 1084	Bracket:BICU:Right Lower	1
4	AA14 3432	Stepped Screw - M3	2
5	B082 5453	Harness:DC:Development:Drawer	1
6	AX06 0240	Brushless Motor:DCZ30W:Ass'y	1
7	B082 5836	Bracket:I/O Board:Right Upper	1
8	B082 5832	Bracket:I/O Board:Left Upper	1
9	B082 5155	PCB:IOB	1
10	B082 5468	Harness:DC:Machine Or Copier:Lower	1
11	B082 5426	Harness:Paper Feed>Main	1
12	B082 5469	Harness:DC:Upper Front	1
13	B082 5467	Harness:DC:Upper	1
14	B082 5465	Harness:Paper Feed:Sensor	1
15	B082 5833	Bracket:I/O Board:Left Lower	1
16	AX04 0078	DC Motor - 3W	1
17	A232 2996	Rear Positioning Guide	2
18	B077 1053	Bracket:Stay:Lengthwise:Rear	1
19	B004 1322	Shield Plate - DC Motor	1
20	B004 1321	Shield Plate - BICU	1
21	B082 5871	Bracket:PCB:MLB	1
22	G020 2620	Push Switch - Paper Size	2
23	B082 5455	Harness:Paper Size Sensor	1
24	B004 1939	Holder - Optical Housing Unit	1
25	B004 1936	Plate - Optical Housing Unit	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0802 5276	Tapping Screw With Washer - M3x6	
103	0451 3008B	Tapping Screw - M3x8	
104	1105 0511	Harness Clamp - LWS-0306ZC	
105	1105 0192	Locking Support	
106	1105 0487	Harness Clamp	
107	1105 0488	Harness Clamp	
108	1105 0349	Edge Saddle	

30.DRIVE SECTION 3 (B079/B082)




30.DRIVE SECTION 3 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA04 3445	Timing Belt - S3M-360	1
2	AB03 0625	Timing Pulley - 20Z	2
3	GA08 0002	Bushing - 6mm	2
4	AX20 0231	Magnetic Clutch - 0.5N M-28Z	2
5	AB01 4219	Gear - 24Z	2
6	B077 1185	Bracket:Timing Pulley	1
7	AB03 0669	Timing Pulley - Registration	2
8	AA04 3554	Timing Belt - B60S3M-22	1
9	B004 1167	Flange - 24mm	2
10	A232 2692	Cover - Paper Drive	2
11	B004 1938	Holder - Optical Housing Unit	1
12	AA04 3446	Timing Belt - S3M-312	1
13	AB03 0561	Timing Pulley - 31Z/20T	2
14	AB01 4038	Gear - 22Z	2
15	AB01 4160	Idler Gear-registration	1
16	AA06 0695	Tension Spring	1
17	B077 1170	Tightener:Paper Feed:Ass'y	1
18	B004 1177	Spacer - By-pass Feed	1
19	AB03 0567	Timing Pulley - 18T	1
20	AB03 0562	Timing Pulley - 31Z/20T	1
21	AB01 4039	Gear - 31Z	1
22	B077 1172	Guide Plate:Upper	1
23	B077 1182	Guide Plate:Lower	1
24	B077 1178	Bracket:Protect:Ass'y	1
25	A232 3552	Ball Bearing - 8x22x7	2
26	AX20 0138	Electrical Clutch - Mice-13	1
27	AA14 9515	Gear Shaft	1
28	AB01 4164	Gear - 28T	1
29	AB03 0566	Timing Pulley - 20T	1
30	B077 1174	Bracket:Middle	1
31	B082 1177	Pulley:Mm17	1
32	AA06 0694	Tension Spring	1
33	B077 1175	Tightener:Middle:Ass'y	1
34	AB03 0634	Pulley	1
35	B004 1320	Base Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	AB01 4040	Gear - 29Z	1
37	B077 2882	Bracket:Micro Switch	1
38	AB01 4159	Gear - 49Z	1
101	0802 5279	Tapping Screw With Washer - M3x8	
102	0451 3006B	Tapping Screw - M3x6	
103	0451 3008H	Tapping Screw - M3x8	
104	0801 0149	Philips Pan Head Screw - M4x6	
105	1102 8504	Connector	
106	0451 3014B	Tapping Screw - M3-14	
107	1204 2529	Switch - V-5F912DN	
108	0720 0060E	Retaining Ring - M6	
109	1105 0511	Harness Clamp - LWS-0306ZC	

31.ELECTRICAL SECTION 1 (B079/B082)




31.ELECTRICAL SECTION 1 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AX64 0113	Fan Motor - 80mm - DC 2.4W	2
2	A232 1172	Duct - Cooling Fan	1
3	G065 1171	Upper Dust	1
4	G065 1170	Lower Dust	1
5	AZ32 0124	Power Pack:CBT	1
6	B077 5812	Bracket:Power Pack:Right	1
7	B077 5811	Bracket:Power Pack:Left	1
8	B077 5898	Bracket:Power Supply Cord	1
9	B077 7757	Bracket:Circuit Breaker	1
10	B082 5897	Bracket:Connector	1
11	B077 1055	Guide Plate:Arm:Scanner Unit	1
12	B082 5601	Power Supply Cord:Stopper:NA:Ass'y	1
12	B004 5528	Power Supply Cord:Stopper:EU:RPL:Ass'y	1
12	A232 5527	Power Supply Cord-230V	1
12	A232 5528	Power Supply Cord - 230V (CHN)	1
13	AZ23 0109	Power Supply Unit:283W:DOM/NA	1
13	AZ23 0110	Power Supply Unit:283W:EU/AA	1
13	AZ23 0111	Power Supply Unit:283W:CHN	1
14	B082 5457	Harness:DC:Safety Switch	1
15	B082 5606	Harness:AC:Switch	1
16	B082 5521	Harness:DC:DC Power Supply	1
17	B004 5611	Harness - Heater	1
18	B004 5470	Outlet:Ground Wire:Ass'y	1
19	A232 7756	Harness - Circuit Breaker	1
20	G034 5820	Spring Plate - Power Supply Unit	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 4035B	Philips Tapping Screw - M4x35	
102	0451 3006B	Tapping Screw - M3x6	
103	0801 0149	Philips Pan Head Screw - M4x6	
104	1105 0192	Locking Support	
105	1105 0310	Harness Clamp - LWS-1S	
106	1105 0488	Harness Clamp	
107	0451 3008H	Tapping Screw - M3x8	
108	1102 8502	Connector - 54679-1615	
109	1107 0472	Circuit Breaker - W28XQ1A 8A 25V	
110	1107 0392	Fuse - 6.3A 125V	
110	1107 0753	Fuse (glass Case) - 6.3A - 250V	
111	1107 0652	Fuse (glass Case) - 10A - 125V	
111	1107 0899	Fuse:5A:250V	
112	1107 0629	Fuse (Ceramic Case) - 15A - 125V	
113	1107 0388	Fuse (Glass Case) - 2A - 125V	
113	1107 0745	Fuse - 1A 250V	

32.ELECTRICAL SECTION 2 (B079/B082)




32.ELECTRICAL SECTION 2 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B077 1126	Bracket:Harness	1
2	B082 5864	Bracket:Harness:Joint Unit	1
3	AX06 0241	Brushless Motor:DC13W:Ass'y	1
4	B082 1087	Bracket:Fan:Front	1
5	AX64 0142	Fan:Sirocco:DC24V:3350Rpm	1
6	B004 5609	Main Harness - Fusing Unit (NA)	1
6	B004 5608	Main Harness - Fusing Unit (EU)	1
7	AA14 3301	Stepped Screw - M3x4	2
8	B077 5861	Lever:Safety Switch	1
9	B077 5862	Cover:Lever	1
10	B077 5860	Bracket:Safety Switch	1
11	AA14 3512	Stepped Screw - M2.5	4
12	AA06 0713	Tension Spring	1
13	B077 5865	Lever:Safety Switch:Front	1
14	B077 5866	Bracket:Safety Switch	1
15	B077 5825	Bracket:Connector:Harness	1
16	B082 5425	Harness:BICU:IOB	1
17	B082 5291	Harness:Laser Diode Control	1
18	B082 5065	PCB:BICU:Ass'y	1
19	B082 1083	Bracket:Bicu:Right Upper	1
20	B082 5881	Bracket:Rack:Application	1
21	G065 5841	Gasket:Bracket:I/O Control Board	1
22	B082 5878	Gasket:Bracket:Rack	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0802 5276	Tapping Screw With Washer - M3x6	
103	0801 0149	Philips Pan Head Screw - M4x6	
104	1105 0487	Harness Clamp	
105	1105 0516	Clamp	
106	1105 0511	Harness Clamp - LWS-0306ZC	
107	0453 4030B	Binding Self Tapping Screw:4x30	
108	1204 2521	Micro Switch	
109	1204 2529	Switch - V-5F912DN	
110	1204 2608	Rocker Switch:SDDJE33900	
111	1607 0747	FPC Core - FPC-25-12	
112	1102 6246	Relay Connector - 4P	
113	1102 6263	Connector - 6P	
114	1102 6260	Relay Connector - 3P	
115	1102 6245	Relay Connector - 2P	
116	1102 6943	Relay Connector -10p	
117	1102 6266	Relay Connector - 9P	
118	1102 6256	Relay Connector - 13P	

33.FRAME SECTION 1 (B079/B082)




33.FRAME SECTION 1 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B077 1066	Stay:Paper Exit Sub-unit:Left	1
2	B077 1067	Bracket:Plate:Joint Unit	1
3	A232 1089	Upper Plate - Laser Unit	1
4	B077 1069	Frame:Middle	1
5	AA15 0684	Shield Plate	1
6	B077 1054	Bracket:Connector:Fusing	1
7	B077 3210	Guide:Toner Supply Unit:Ass'y	1
8	A232 3264	Stopper - Slide Rail	1
9	B077 1051	Bracket:Shaft:Stopper:Ass'y	1
10	B082 2362	Stay:Around The Photoconductor	1
11	B082 2363	Magnet - Discharge Lamp	1
12	AX50 0046	Quenching Lamp	1
13	B077 1071	Supporter:Fusing Unit:Welding	1
14	A232 4201	Stopper - Fusing Unit	1
15	B004 4122	Decal - Warning	1
16	B077 1078	Supporter:Development Unit	1
17	A232 1937	Positioning Pin - Laser Unit Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0802 5276	Tapping Screw With Washer - M3x6	
103	0451 3008B	Tapping Screw - M3x8	
104	0451 3005W	Tapping Screw - 3x5	
105	1105 0516	Clamp	
106	1105 0522	Edge Saddle - Les0510	
107	1105 0487	Harness Clamp	
108	1105 0267	Harness Clamp - YMC-10-0	
109	1105 0511	Harness Clamp - LWS-0306ZC	
110	1105 0508	Harness Clamp - LWS-0711	

34.FRAME SECTION 2 (B079/B082)




34.FRAME SECTION 2 (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A230 2520	Heat Sink - Heater	1
2	AX40 0137	Heater - 120V 9W	1
2	AX40 0138	Heater - 230V 9W	1
3	B004 2597	Sheet - Separation Plate	1
4	B082 1076	Stay:Machine Or Copier:Rear	1
5	B004 1091	Grip:Rear	2
6	B004 1093	Rear Stay	1
7	AW02 0120	Photointerruptor - Flat	4
8	B077 1267	Bracket:Hinge:Right	1
9	AH01 0009	Rubber Pad - H5	4
10	B004 2995	Cap - Positioning	1
11	B077 2990	Supporter:Paper Tray:Ass'y	2
12	A232 2995	Front Positioning Guide	2
13	B077 1021	Grip:Adhesion	1
14	B077 1023	Stopper:Grip	2
15	A230 2688	Film - Stay - Upper Front	2
16	B077 1082	Base:Fix:Development	1
17	B082 1081	Bracket:Fix:Development	1
18	B077 1266	Bracket:Hinge:Left	1
19	B077 1968	Shadeing Plate:Ass'y	1
20	A230 2525	Heater Stopper	1
21	B004 5611	Harness - Heater	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0451 4016B	Tapping Screw - M4-16	
103	1105 0488	Harness Clamp	
104	1105 0511	Harness Clamp - LWS-0306ZC	
105	1105 0489	Harness Clamp - LWS 1316	
106	1105 0516	Clamp	

35.EXPANSION BOX (B079/B082)



35.EXPANSION BOX (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B082 5194	PCB:Mother Board	1
2	B077 5856	Supporter:Control Board	1
3	B082 5101	PCB:Adonis-C3:Main:35:Sub-ass'y	1
3	B082 5102	PCB:Adonis-C3:Main:45:Sub-ass'y	1
4	B077 5871	Rack:Application:Ass'y	1
5	B077 5876	Stay:Rack	1
6	B004 5887	Eeehion:Panel:Rack	2
7	B082 5886	Panel:Rack	1
8	A285 5842	Gasket - Rack	1
9	B082 5855	Cover:Connector:Centronics	1
10	B082 5856	Cover:Gwphy	1
11	G065 5893	Card Cover	1
12	B082 5850	Bracket:Control Board:Ass'y	1
13	B004 5853	Bracket Grip	1
14	G065 5858	Option Cover	1
15	B082 5476	Harness:HDD:Power Source	1
16	B082 5475	Harness:HDD	1
17	B548 5863	HDD:ATA:ST320014A	1
18	B082 5891	Bracket:HDD	1
19	AA16 1125	Rubber Cushion	4
20	AA14 3499	Stepped Screw	4
21	B082 5892	Spring Plate:HDD	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0353 0080Z	Philips Trass Head Screw - M3x8	

36.IOB BOARD (B079/B082)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C101	150	C111	177	C121	180	C131	175	C141	148	C151	177	C161	179
C102	151	C112	180	C122	179	C132	175	C142	179	C152	179	C162	179
C103	149	C113	178	C123	179	C133	175	C143	148	C153	179	C163	179
C104	149	C114	180	C124	179	C134	175	C144	175	C154	179	C164	179
C105	179	C115	177	C125	175	C135	175	C145	148	C155	179	C165	179
C106	179	C116	178	C126	180	C136	175	C146	148	C156	179	C166	179
C107	177	C117	177	C127	175	C137	175	C147	175	C157	179	C167	179
C108	151	C118	179	C128	175	C138	179	C148	175	C158	179	C168	179
C109	177	C119	180	C129	175	C139	175	C149	179	C159	179	C169	179
C110	179	C120	179	C130	175	C140	175	C150	179	C160	179	C170	148

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C171	179	C181	179	C191	179	C201	179	C211	179	C221	180	CN201	103
C172	179	C182	176	C192	179	C202	179	C212	179	C222	177	CN202	119
C173	148	C183	179	C193	179	C203	179	C213	179	C223	179	CN203	106
C174	148	C184	179	C194	179	C204	179	C214	179	C224	179	CN204	117
C175	179	C185	179	C195	180	C205	179	C215	179	C225	179	CN205	118
C176	179	C186	179	C196	179	C206	179	C216	179	C226	179	CN206	121
C177	148	C187	176	C197	179	C207	179	C217	179			CN207	104
C178	179	C188	179	C198	179	C208	179	C218	179			CN208	108
C179	179	C189	179	C199	179	C209	178	C219	179			CN209	107
C180	179	C190	179	C200	179	C210	180	C220	179			CN210	101

CONNECTOR

36.IOB BOARD (B079/B082)

CONNECTOR

SYMBOL NO.	INDEX NO.
CN211	111
CN212	102
CN213	114
CN214	106
CN215	110
CN216	120
CN217	116
CN218	115
CN219	103
CN220	112

CONNECTOR

SYMBOL NO.	INDEX NO.
CN221	110
CN222	113
CN223	109
CN224	116
CN225	115
CN226	105
---	---
---	---
CN299	111

SYMBOL NO.	INDEX NO.
D101	128
D102	128
D103	128
D104	128
D105	128
D106	128
D107	128
D108	128
D109	128
D110	128

SYMBOL NO.	INDEX NO.
D111	128
D112	128

DA

SYMBOL NO.	INDEX NO.
DA101	127
DA102	127
DA103	129
DA104	129
DA105	129

IC

SYMBOL NO.	INDEX NO.
IC101	136
IC102	136
IC103	134
IC104	1
IC105	134
IC106	135
IC107	136
IC108	142
IC109	140
IC110	142

SYMBOL NO.	INDEX NO.
IC111	139
IC112	138
IC113	136
IC114	141
IC115	141

OSC

SYMBOL NO.	INDEX NO.
OSC101	143

Q

SYMBOL NO.	INDEX NO.
Q101	123
Q102	125
Q103	123
Q104	123
Q105	137
Q106	137
Q107	137
Q108	137
Q109	133
Q110	124

SYMBOL NO.	INDEX NO.
Q111	126

RESISTOR

SYMBOL NO.	INDEX NO.
R101	152
R102	152
R103	152
R104	152
R105	152
R106	152
R107	152
R108	152
R109	154
R110	156

SYMBOL NO.	INDEX NO.
R111	161
R112	155
R113	153
R114	155
R115	156
R116	155
R117	155
R118	156
R119	155
R120	158

SYMBOL NO.	INDEX NO.
R121	165
R122	161
R123	153
R124	156
R125	156
R126	156
R127	159
R128	164
R129	156
R130	155

SYMBOL NO.	INDEX NO.
R131	156
R132	155
R133	161
R134	163
R135	155
R136	163
R137	163
R138	162
R139	144
R140	144

36.IOB BOARD (B079/B082)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R141	155	R151	153	R161	168	R171	163	R181	156	R191	163	R201	164
R142	160	R152	156	R162	172	R172	159	R182	156	R192	167	R202	161
R143	161	R153	156	R163	155	R173	163	R183	155	R193	170	R203	159
R144	169	R154	155	R164	163	R174	164	R184	155	R194	171	R204	163
R145	161	R155	153	R165	162	R175	162	R185	155	R195	170	R205	155
R146	168	R156	155	R166	156	R176	163	R186	155	R196	163	R206	161
R147	166	R157	169	R167	155	R177	161	R187	156	R197	171	R207	169
R148	168	R158	163	R168	155	R178	155	R188	155	R198	170	R208	173
R149	174	R159	172	R169	156	R179	155	R189	156	R199	170	R209	168
R150	152	R160	168	R170	164	R180	155	R190	155	R200	155	R210	168

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R211	160	R221	155	RN101	145	RN111	146	RN121	147	RN131	147
R212	155	R222	155	RN102	145	RN112	145	RN122	145	RN132	145
R213	155	R223	156	RN103	146	RN113	147	RN123	145	RN133	145
R214	155	R224	155	RN104	146	RN114	147	RN124	147	RN134	145
R215	162	R225	156	RN105	145	RN115	147	RN125	147	RN135	145
R216	163	R226	157	RN106	146	RN116	145	RN126	145	RN136	145
R217	155	R227	163	RN107	146	RN117	147	RN127	145	RN137	147
R218	163	R228	155	RN108	145	RN118	145	RN128	147	RN138	145
R219	162			RN109	146	RN119	145	RN129	147	RN139	147
R220	155			RN110	145	RN120	147	RN130	145	RN140	147

SW

SYMBOL NO.	INDEX NO.
SW101	122

36.IOB BOARD (B079/B082)

TH

SYMBOL NO.	INDEX NO.
TH101	132

CONNECTOR

SYMBOL NO.	INDEX NO.
ZD101	130
ZD102	131
ZD103	131
ZD104	131
ZD105	131
ZD106	131



36.IOB BOARD (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
* 1	B082 5155 A232 5355	PCB:IOB IC - GATEX	1 1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1102 3822	Connector - 20P	
102	1102 5306	Connector - 7P	
103	1102 6295	Connector - 2P	
104	1102 6297	Connector - 4P	
105	1102 6301	Connector - 8P	
106	1102 6302	Connector - 9P	
107	1102 6303	Connector - 10P	
108	1102 6305	Connector - 12P	
109	1102 6308	Connector - 15P	
110	1102 6309	Connector - 2P	
111	1102 6311	Connector - 4P	
112	1102 6316	Connector - 9P	
113	1102 6321	Connector	
114	1102 6394	Connector - 12P	
115	1102 6396	Connector - 1P	
116	1102 6397	Box Header	
117	1102 6398	Connector - 2P	
118	1102 6401	Connector - 26P	
119	1102 6402	Connector - 2P	
120	1102 7244	Connector	
121	1102 7389	Connector - FH12-50S-0.5SV	
122	1204 4837	DIP Switch	
123	1400 0167	Transistor:DTA114EUA	
124	1400 0775	Transistor - 2SC4081	
125	1400 0810	Transistor:DTC114EUA	
126	1400 0902	Transistor - DTA113ZUA	
127	1402 1322	Diode Array - DAN202U	
128	1402 1336	Diode - 1SS355	
129	1402 1584	Diode - DAN217U	
130	1402 1662	Diode:PTZ6.2b	
131	1402 1663	Diode - ZTP12B	
132	1404 0360	Thermistor - 103HT	
133	1407 1535	IC - TD62308AP	
134	1407 1596	TTLIC - SN74LS14NS	
135	1407 1880	TTLIC - SN74LS04NS	

Index No.	Part No.	Description	Q'ty Per Assembly
136	1407 2187	TTLIC - SN74LS07NS	
137	1407 2219	IC - TD62003AP	
138	1407 5344	IC - SN74LV02APW	
139	1407 5594	IC:CD4066BPW	
140	1408 0877	Comparator - LM339NS	
141	1408 1095	IC - BA10324AF	
142	1408 1204	IC - TA8083P	
143	1503 0946	Crystal Oscillator - 9.8304Mhz	
144	1600 1340	Resistor:330Ω±5%:1W	
145	1601 7752	Resistor Array - 10K Ω ±5%	
146	1601 7760	Resistor Array	
147	1601 7791	Resistor Array - 1K Ω ±5%	
148	1605 1124	Capacitor - 4.7μF+80 -20% 50V	
149	1640 2470	Capacitor - 47μF±20% 25V	
150	1640 2471	Capacitor - 470μF±20% 25V	
151	1640 5101	Capacitor - 100μF±20% 50V	
152	1650 2221	Resistor:220Ω±5%:1/4W	
153	1650 4100	Resistor - 10Ω ±5% 1/10W	
154	1650 4101	Resistor - 100Ω±5%1/10W	
155	1650 4102	Resistor - 1KΩ ±5% 1/10W	
156	1650 4103	Resistor - 10KΩ ±5% 1/10W	
157	1650 4104	Resistor - 100KΩ±5%1/10W	
158	1650 4105	Resistor - 1MΩ ±5% 1/10W	
159	1650 4161	Resistor - 160Ω ±5% 1/10W	
160	1650 4204	Resistor - 200KΩ±5%1/10W	
161	1650 4222	Resistor - 2.2KΩ±5%1/10W	
162	1650 4223	Resistor - 22KΩ±5%1/10W	
163	1650 4472	Resistor - 4.7KΩ ±5% 1/10W	
164	1650 4562	Resistor - 5.6KΩ ±5% 1/10W	
165	1650 4681	Resistor - 680Ω ±5% 1/10W	
166	1652 1000	Chip Resistor:100Ω:±1%:1/4W	
167	1654 1002	Resistor - 10KΩ±5%1/10W	
168	1654 1003	Resistor - 100KΩ±1%1/10W	
169	1654 1403	Resistor:140kΩ:±1%:1/10W	
170	1654 2002	Resistor - 20KΩ±1%1/10W	

Index No.	Part No.	Description	Q'ty Per Assembly
171	1654 2401	Resistor - 2.4KΩ ±1% 1/10W	
172	1654 2402	Chip Resistor:24kΩ:±1%:1/10W	
173	1654 4641	Resistor:4.64kΩ:±1%:1/10W	
174	1654 5621	Resistor:5.62kΩ:±1%:1/10W	
175	1660 2101	Capacitor - 100pF - ±10% - 50V	
176	1660 2270	Capacitor - 27pF ±20% 35V	
177	1660 2471	Capacitor - 470pF - ±5% - 50V	
178	1660 4472	Capacitor - 4700pF±10% 50V	
179	1660 6103	Capacitor - 10000pF - +80%-20%50V	
180	1660 8104	Capacitor - 0.1μF+80-20% 25V	

37.BICU BOARD (B079/B082)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
---	---	C111	159	C121	187	C131	182	C141	182	C151	187
C102	190	C112	190	C122	181	C132	182	C142	182	C152	186
C103	190	C113	153	C123	181	C133	182	C143	182	C153	186
C104	186	C114	152	C124	186	C134	190	C144	182	C154	190
C105	187	C115	190	C125	190	C135	182	C145	187	C155	186
C106	182	C116	159	C126	159	C136	182	C146	187	C156	190
C107	190	C117	154	C127	159	C137	182	C147	190	C157	182
C108	186	C118	190	C128	182	C138	182	C148	190	C158	182
C109	190	C119	190	C129	182	C139	182	C149	186	C159	186
C110	154	C120	190	C130	190	C140	189	C150	190	C160	186
										C161	182
										C162	182
										C163	157
										C164	182
										C165	182
										C166	182
										C167	157
										C168	188
										C169	186
										C170	182

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C171	157	C181	182	C191	186	C201	190	C211	186	C221	184
C172	190	C182	190	C192	186	C202	155	C212	190	C222	190
C173	186	C183	182	C193	190	C203	186	C213	190	C223	186
C174	156	C184	186	C194	190	C204	155	C214	189	C224	186
C175	190	C185	190	C195	186	C205	186	C215	190	C225	183
C176	186	C186	186	C196	190	---	---	C216	186	C226	190
C177	182	C187	190	C197	190	C207	190	C217	186	C227	186
C178	157	C188	190	C198	187	C208	186	C218	185	C228	186
C179	186	C189	190	C199	186	C209	190	C219	190	C229	190
C180	182	C190	190	C200	190	C210	186	C220	186	C230	190
										C231	190
										C232	186
										C233	186
										C234	186
										C235	186
										C236	182
										C237	182
										C238	182
										C239	182
										C240	182

37.BICU BOARD (B079/B082)

CAPACITOR

SYMBOL NO.	INDEX NO.
C241	186
C242	182
C243	182
C244	190
C245	182
C246	182
C247	182
C248	190
C249	182
C250	190

CONNECTOR

SYMBOL NO.	INDEX NO.
CN301	106
CN302	110
CN303	109
---	---
CN305	103
---	---
CN307	107
CN308	107
---	---
CN310	102
---	---

SYMBOL NO.	INDEX NO.
CN312	104
CN313	103
CN314	105
CN315	111
SYMBOL NO.	INDEX NO.
D101	114
D102	114

IC

SYMBOL NO.	INDEX NO.
IC101	133
IC102	127
IC103	125
IC104	127
IC105	128
IC106	128
IC107	3
IC108	130
IC109	126
IC110	132

FUSE

SYMBOL NO.	INDEX NO.
IC111	129
IC112	131
IC113	2
IC114	191
IC115	131
IC116	124
IC117	123
IC118	1
IC119	135
IC120	126

SYMBOL NO.	INDEX NO.
IC121	120
IC122	137
IC123	121
IC124	122
IC125	134

JP

SYMBOL NO.	INDEX NO.
JP102	158

LED

SYMBOL NO.	INDEX NO.
LED101	118
LED102	117
LED103	119

OSC

SYMBOL NO.	INDEX NO.
OSC101	141
OSC102	140
OSC103	139

Q

SYMBOL NO.	INDEX NO.
Q101	113
---	---
Q103	113
Q104	113
Q105	112
Q106	113
Q107	113

RESISTOR

SYMBOL NO.	INDEX NO.
R101	162
R102	178
R103	178
R104	174
R105	162
R106	162
R107	161
R108	161
R109	161
R110	161

SYMBOL NO.	INDEX NO.
R111	174
R112	174
R113	170
R114	170
R115	163
R116	174
---	---
R118	163
R119	175
R120	175

SYMBOL NO.	INDEX NO.
R121	162
R122	174
R123	168
R124	162
R125	173
R126	163
R127	162
R128	162
R129	162
R130	162

SYMBOL NO.	INDEX NO.
R131	165
R132	175
R133	162
R134	170
R135	162
R136	163
R137	163
R138	162
R139	163
R140	163

SYMBOL NO.	INDEX NO.
R141	163
R142	163
R143	163
R144	162
R145	162
R146	174
R147	168
R148	164
R149	164
R150	164

SYMBOL NO.	INDEX NO.
R151	164
R152	162
R153	160
R154	176
R155	172
R156	163
R157	172
R158	174
R159	175
R160	176

37.BICU BOARD (B079/B082)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R161	162	R171	177	R181	162	R191	168	R201	162	R210	175	R220	162
R162	162	R172	162	R182	162	R192	162	R202	163	R211	170	R221	169
R163	163	R173	180	R183	162	R193	162	R203	175	R212	170	R222	174
R164	160	R174	179	R184	162	R194	163	R204	175	R213	166	R223	162
R165	162	R175	163	R185	163	R195	164	R205	162	R214	171	R224	162
										R215	170	R225	168
R166	162	R176	174	R186	164	R196	163	R206	175				
R167	163	R177	162	R187	175	R197	162	R206	162	R216	163	R226	162
R168	163	R178	162	R188	162	R198	162	R207	162	R217	170	R227	163
R169	170	R179	163	R189	163	R199	168	—	—	R218	174	R228	162
R170	167	R180	162	R190	173	R200	162	R209	174	R219	162	R229	163

RESISTOR

RN

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R230	162	RN101	145	RN111	145	RN121	144	RN131	145	RN141	144	RN151	149
R231	170	RN102	144	RN112	145	RN122	144	RN132	145	RN142	145	RN152	145
R232	161	RN103	142	RN113	145	RN123	144	RN133	145	RN143	145	RN153	149
		RN104	145	RN114	145	RN124	144	RN134	145	RN144	145	RN154	145
		RN105	144	RN115	145	RN125	148	RN135	145	RN145	144	RN155	149
		RN106	144	RN116	147	RN126	145	RN136	145	RN146	144	RN156	145
		RN107	144	RN117	145	RN127	144	RN137	145	RN147	144	RN157	144
		RN108	144	RN118	144	RN128	144	RN138	144	RN148	145	RN158	145
		RN109	144	RN119	144	RN129	145	RN139	147	RN149	145	RN159	144
		RN110	145	RN120	147	RN130	145	RN140	144	RN150	144	RN160	149

REG

SYMBOL NO.	INDEX NO.
REG101	136
REG102	138
REG103	136

37.BICU BOARD (B079/B082)

RN

SYMBOL NO.	INDEX NO.
RN161	145
RN162	145
RN163	149
RN164	145
RN165	145
RN166	145
RN167	145
RN168	145
RN169	145
RN170	149

SYMBOL NO.	INDEX NO.
RN171	149
RN172	149
RN173	149
RN174	149
RN175	149
RN176	145
RN177	145
RN178	145
RN179	145
RN180	143

SYMBOL NO.	INDEX NO.
RN181	145
RN182	143
RN183	145
RN184	143
RN185	145
RN186	143
RN187	144
RN188	144
RN189	144
RN190	144

SYMBOL NO.	INDEX NO.
RN191	144
RN192	145
RN193	151
RN194	144
RN195	145
RN196	145
RN197	145
RN198	144
RN199	145
RN200	146

SYMBOL NO.	INDEX NO.
RN201	144
RN202	144
RN203	144
RN204	145
RN205	150

ZD

SYMBOL NO.	INDEX NO.
ZD101	115
ZD102	116
ZD103	116

Best Solution

37.BICU BOARD (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B082 5065	PCB:BICU:Ass'y	1
1	B004 5120	IC - HG71C114FL	1
2	B082 5130	IC:CDICA:RL5C481A	1
3	B082 5136	IC:RI1001:230MHZ	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1005 0967	Heatsink	
102	1102 4204	CT Header - 5P	
103	1102 5305	Connector - 6P	
104	1102 6297	Connector - 4P	
105	1102 6303	Connector - 10P	
106	1102 6595	Connector - 11P	
107	1102 7389	Connector - FH12-50S-0.5SV	
108	1102 7729	Connector - DX10G1M-50SE	
109	1102 8243	Connector - FH12-33S-0.5SV	
110	1102 8272	Connector - TX25-100P-12ST-H1	
111	1102 8357	Connector - 52777-0809	
112	1400 0775	Transistor - 2SC4081	
113	1400 0810	Transistor:DTC114EUA	
114	1402 1336	Diode - 1SS355	
115	1402 1647	Diode - UDZS3.6B	
116	1402 1662	Diode:PTZ6.2B	
117	1403 0907	Diode - SML-310LT	
118	1403 0953	LED - SML-310MT	
119	1403 0978	LED - SML-310DT	
120	1407 1596	TTLIC - SN74LS14NS	
121	1407 2187	TTLIC - SN74LS07NS	
122	1407 2218	TTLIC - SN74LS06NS	
123	1407 4171	IC - MC68334GFC16	
124	1407 5078	Flash Memory - MBM29F800BA-70pFTN	
125	1407 5090	IC - DS90CF364MTD	
126	1407 5346	IC - SN74LS74ANS	
127	1407 5351	IC - SN74LV14APW	
128	1407 5353	IC - SN74LV244APW	
129	1407 5376	IC - SN74LV32APW	
130	1407 5435	IC - SN74AHC1G04HDCK	
131	1407 5469	IC - SN74LV07APW	
132	1407 5567	IC:SN74IVCC3245APW	
133	1407 5713	IC:SN74IV06APW	
134	1407 5793	Clock Generator:HD151TS304RP	
135	1408 1486	IC:PST9330U	

Index No.	Part No.	Description	Q'ty Per Assembly
136	1408 1555	Regulator - L1087MP-3.3	
137	1408 1730	IC - MM1096BF	
138	1408 1794	Series Regulator:LM1085IT-ADJ	
139	1503 0460	Oscillator - 32.768KHZ	
140	1503 1004	Oscillator - 19.6608Mhz	
141	1503 1106	Crystal Oscillator:40.97Mhz	
142	1601 7877	Resistor Array 4.7k Ω \pm 5% 1/32W	
143	1601 7886	Resistor Array 3.3k Ω \pm 5% 1/32W	
144	1601 7887	Resistor Array - 10K Ω \pm 5% 1/32W	
145	1601 7896	Resistor Array - 56 Ω \pm 5% 1/32W	
146	1601 7959	Resistor	
147	1601 7960	Resistor Array - 100 Ω \pm 5% 1/16W	
148	1601 7961	Resistor Array:120 Ω \pm 5% 1/16W	
149	1601 7981	Resistor Array - 100K Ω \pm 5% 1/16W	
150	1601 7983	Resistor Array:2.2k Ω : \pm 5%:1/16W	
151	1601 7996	Resistor Array:1.2k Ω : \pm 5%:1/16W	
152	1604 4942	Capacitor - 33UF \pm 20%	
153	1604 5147	Capacitor:330uf: \pm 20%:6.3V	
154	1605 1160	Capacitor:0.22uf:+80-20%:16V	
155	1605 1167	Capacitor - 0.22 μ F \pm 10% 10V	
156	1605 1187	Ceramic Capacitor 0.047 μ F \pm 10% 50V	
157	1605 1371	Capacitor:4.7uf:+80-20%:6.3V	
158	1634 0000	Resistor - 0 Ω 1/16W	
159	1644 1470	Capacitor - 47 μ F \pm 20% 16V	
160	1650 4100	Resistor - 10 Ω \pm 5% 1/10W	
161	1650 4101	Resistor - 100 Ω \pm 5%1/10W	
162	1650 4102	Resistor - 1K Ω \pm 5% 1/10W	
163	1650 4103	Resistor - 10K Ω \pm 5% 1/10W	
164	1650 4104	Resistor - 100K Ω \pm 5%1/10W	
165	1650 4105	Resistor - 1M Ω \pm 5% 1/10W	
166	1650 4106	Resistor - 10M Ω \pm 5%1/10W	
167	1650 4202	Resistor - 2K Ω \pm 5%1/10W	
168	1650 4222	Resistor - 2.2K Ω \pm 5%1/10W	
169	1650 4223	Resistor - 22K Ω \pm 5%1/10W	
170	1650 4330	Chip Resistor - 33 Ω \pm 5% 1/10W	

Index No.	Part No.	Description	Q'ty Per Assembly
171	1650 4334	Resistor - 330K Ω \pm 5%1/10W	
172	1650 4391	Resistor - 390 Ω \pm 5% 1/10W	
173	1650 4470	Resistor - 47 Ω \pm 5%1/10W	
174	1650 4472	Resistor - 4.7K Ω \pm 5% 1/10W	
175	1650 4560	Chip Resistor - 56 Ω \pm 5% 1/10W	
176	1650 4562	Resistor - 5.6K Ω \pm 5% 1/10W	
177	1650 4680	Resistor - 68 Ω \pm 5%1/10W	
178	1650 4751	Resistor - 750 Ω \pm 5% 1/10W	
179	1654 1000	Resistor - 100 Ω \pm 1% 1/10W	
180	1654 5609	Resistor:56 Ω : \pm 1%:1/10W	
181	1660 0100	Capacitor - 10PF \pm 0.5pF 50V	
182	1660 2101	Capacitor - 100pF - \pm 10% - 50V	
183	1660 2150	Capacitor - 15pF \pm 5% 50V	
184	1660 2220	Capacitor - 22pF \pm 20% 35V	
185	1660 2330	Capacitor - 33pF - \pm 5% - 50V	
186	1660 2471	Capacitor - 470pF - \pm 5% - 50V	
187	1660 4102	Capacitor - 1000pF \pm 10% 50V	
188	1660 4472	Capacitor - 4700pF \pm 10% 50V	
189	1660 6103	Capacitor - 10000pF - +80%-20%50V	
190	1660 8104	Capacitor - 0.1 μ F+80-20% 25V	
191	1902 0042	RAM-1M X8 70ns TSOP G2	

38.CONTROLLER BOARD (B079/B082)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C1	212	---	---	C51	208	C89	212	C101	211	C111	208	C121	204
C2	208	---	---	C59	208	C90	208	C102	211	C112	159	C122	204
C3	208	---	---	C60	212	C91	212	C103	211	---	---	---	---
C4	212	---	---	---	---	---	---	C104	201	C114	212	C124	206
---	---	C15	212	C72	212	C95	211	C105	199	C115	208	---	---
C6	208	C16	208	C73	208	C96	199	C106	199	C116	202	C126	204
C7	212	C17	212	---	---	C97	211	C107	211	C117	212	---	---
C8	155	C18	208	C81	201	C98	201	C108	159	C118	208	---	---
C9	152	---	---	---	---	C99	211	C109	204	C119	212	C129	208
---	---	C50	212	C85	201	C100	199	C110	207	C120	212	C130	212

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
---	---	C141	212	C151	208	C161	212	C171	208	C181	211	C191	208
---	---	C142	208	C152	208	C162	208	C172	202	C182	208	C192	211
---	---	C143	208	C153	212	C163	208	C173	208	C183	202	C193	202
C134	212	---	---	C154	208	C164	212	C174	211	C184	211	C194	208
---	---	---	---	---	---	C165	212	C175	202	C185	208	C195	211
---	---	---	---	---	---	C166	208	C176	208	C186	202	C196	212
C137	212	C147	153	C157	212	---	---	C177	211	C187	211	C197	208
C138	208	C148	212	C158	208	---	---	C178	202	C188	208	C198	208
C139	152	C149	212	C159	212	C169	212	C179	208	C189	202	C199	212
C140	208	C150	208	C160	208	C170	202	C180	202	C190	211	C200	208

38.CONTROLLER BOARD (B079/B082)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C201	212	C211	212	C221	208	C231	208	---	---	C251	212	C261	208
C202	208	C212	202	C222	161	C232	202	---	---	C252	208	C262	208
C203	212	C213	202	C223	161	C233	212	C243	161	C253	212	C263	212
C204	208	C214	212	C224	161	---	---	C244	161	C254	212	C264	212
---	---	C215	203	C225	161	---	---	C245	212	C255	211	---	---
C206	212	C216	202	C226	161	---	---	C246	208	C256	211	---	---
---	---	C217	212	C227	161	---	---	C247	208	C257	211	---	---
C208	212	C218	212	C228	208	---	---	C248	212	C258	212	---	---
C209	212	C219	202	C229	208	---	---	C249	208	C259	212	---	---
C210	208	C220	208	C230	212	---	---	C250	212	---	---	---	---

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
---	---	C281	208	---	---	C301	206	C311	212	C321	202	C331	212
C272	211	C282	212	---	---	C302	200	C312	208	C322	208	C332	157
C273	212	---	---	---	---	C303	212	C313	208	C323	202	C333	202
C274	212	---	---	---	---	C304	208	C314	162	C324	212	C334	202
C275	202	---	---	---	---	C305	202	C315	212	C325	202	C335	208
C276	202	---	---	---	---	C306	212	C316	208	C326	162	C336	202
C277	202	C287	212	---	---	C307	212	C317	208	C327	212	C337	208
C278	202	---	---	C298	212	C308	202	---	---	C328	162	C338	162
---	---	---	---	C299	208	C309	162	C319	162	C329	162	C339	212
---	---	---	---	C300	200	C310	162	C320	157	C330	208	---	---

38.CONTROLLER BOARD (B079/B082)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C341	161	C351	199	C361	156	C371	158	CN501	102	---	---	D6	117
C342	161	C352	212	C362	205	C372	160	---	---	---	---	D7	119
C343	161	C353	161	C363	210	C373	203	CN503	107	CN513	106	D8	118
C344	161	C354	161	C364	158	C374	209	---	---	CN514	101	D9	118
C345	161	C355	204	C365	212	C375	156	CN505	105	CN515	103	D10	118
C346	161	C356	163	C366	201	C376	160	CN506	110	---	---		
C347	201	C357	207	C367	161	C377	156	---	---	CN517	109		
C348	201	C358	208	C368	164	C378	212	CN508	108	CN518	104		
C349	199	C359	154	C369	161	---	---	CN509	108				
C350	199	C360	160	C370	161	C380	206	---	---				

DIODE

FILTER

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
FIL5	165	---	---	---	---	IC21	215	---	---	IC41	138	IC51	121
---	---	---	---	---	---	IC22	126	IC32	130	IC42	137	IC52	141
---	---	IC3	125	IC13	122	---	---	---	---	IC43	139	IC53	134
---	---	---	---	IC14	215	---	---	---	---	---	---	IC54	141
FIL9	166	IC5	122	IC15	215	---	---	IC35	126	IC45	140	IC55	141
		---	---	IC16	2	---	---	---	---	IC46	126	IC56	136
		IC7	129	IC17	124	IC26	123	IC37	111	IC47	132	---	---
		IC8	127	IC18	126	IC27	133	IC38	111	---	---	IC58	213
		IC9	215	---	---	IC29	127	---	---	IC49	134	IC59	214
		IC10	122	---	---	---	---	IC40	131	IC50	135	IC60	128

38.CONTROLLER BOARD (B079/B082)

JP

SYMBOL NO.	INDEX NO.
JP10	174
JP16	174
JP19	174
---	---
JP39	174
JP40	174
JP41	174
---	---
---	---
JP49	174

CONNECTOR L

SYMBOL NO.	INDEX NO.
JP50	174
JP51	174
JP54	174
JP55	174
JP60	173
JP61	174
JP62	174
JP63	174
JP72	174
JP73	174

SYMBOL NO.	INDEX NO.
L1	168
L2	167
L3	167
SYMBOL NO.	INDEX NO.
LED1	120
LED2	120

OSC

SYMBOL NO.	INDEX NO.
OSC3	142

Q

SYMBOL NO.	INDEX NO.
---	---
Q2	114
Q3	114
Q4	116
Q5	115
Q6	116
Q7	115
Q8	115
Q9	116
---	---

RESISTOR

SYMBOL NO.	INDEX NO.
R1	190
R2	190
R3	183
R4	183
---	---
---	---
---	---
---	---
---	---
---	---

SYMBOL NO.	INDEX NO.
---	---
---	---
R13	178
R14	178
R15	178
R16	178
---	---
R18	184
R19	184
---	---

RESISTOR

SYMBOL NO.	INDEX NO.
---	---
---	---
---	---
---	---
R25	186
R26	187
R27	195
R28	195
---	---
---	---

SYMBOL NO.	INDEX NO.
R31	186
---	---
---	---
R34	184
---	---
---	---
R37	195
---	---
---	---
R40	186

SYMBOL NO.	INDEX NO.
R41	188
R42	188
R43	188
R44	188
R45	175
R46	178
R47	178
---	---
R49	182
R50	182

SYMBOL NO.	INDEX NO.
R51	182
R52	182
R53	182
R54	182
R55	178
---	---
R57	178
R58	184
R59	186
R60	186

SYMBOL NO.	INDEX NO.
R61	186
R62	186
R63	186
R64	186
R65	184
R66	184
---	---
R68	184
R69	184
R70	184

SYMBOL NO.	INDEX NO.
---	---
---	---
---	---
---	---
R75	184
R76	186
R77	185
R78	185
---	---
---	---

SYMBOL NO.	INDEX NO.
R81	178
R82	178
R83	184
R84	184
R85	184
R86	184
R87	184
R88	186
R89	186
R90	184

38.CONTROLLER BOARD (B079/B082)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R91	184	R101	184	R111	184	R121	177	R131	184	R141	178	R151	178
R92	184	R102	184	R112	184	R122	178	R132	184	R142	178	R152	178
R93	186	R103	186	R113	184	R123	186	R133	184	R143	178	R153	194
R94	186	R104	184	R114	184	---	---	R134	178	R144	193	---	---
R95	184	---	---	R115	186	R125	184	R135	184	R145	186	R155	193
R96	184	R106	186	R116	177	R126	184	---	---	R146	186	R156	191
R97	184	R107	184	R117	186	R127	184	---	---	R147	193	R157	178
R98	184	R108	184	R118	177	R128	184	R138	184	R148	186	R158	186
R99	184	---	---	R119	186	R129	184	R139	184	R149	177	R159	194
R100	184	R110	184	R120	186	R130	184	---	---	R150	186	---	---

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R161	178	R171	186	R181	188	R191	184	---	---	R211	184	R221	184
R162	186	R172	186	R182	188	R192	188	R202	184	R212	186	R222	184
R163	186	R173	188	R183	188	R193	188	---	---	R213	184	R223	184
R164	178	R174	188	R184	188	---	---	R204	184	---	---	R224	184
R165	178	R175	178	R185	188	---	---	R205	184	---	---	R225	184
R166	188	R176	188	---	---	---	---	R206	184	R216	178	R226	186
R167	186	R177	188	---	---	R197	178	R207	184	---	---	R227	187
R168	186	R178	188	R188	178	R198	188	R208	184	---	---	R228	187
R169	178	R179	188	R189	188	R199	188	R209	186	---	---	R229	187
R170	178	R180	188	R190	188	---	---	R210	186	---	---	R230	184

38.CONTROLLER BOARD (B079/B082)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R231	184	---	---	---	---	R271	184	---	---	R291	181	---	---
R232	184	R242	184	---	---	---	---	R282	188	R292	193	---	---
R233	184	R243	186	---	---	---	---	R283	188	R293	184	---	---
R234	187	R244	186	---	---	---	---	R284	183	R294	184	---	---
R235	184	R245	183	R255	188	---	---	R285	188	---	---	---	---
R236	184	R246	186	---	---	R276	188	R286	188	R296	184	R306	186
R237	184	R247	186	---	---	R277	188	R287	178	---	---	---	---
R238	184	R248	186	R258	188	---	---	R288	193	R298	180	---	---
R239	184	R249	186	---	---	---	---	R289	193	---	---	R309	176
---	---	R250	181	---	---	---	---	R290	193	---	---	---	---

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
---	---	R321	186	R331	186	R341	178	R351	179	R361	178	R371	186
---	---	R322	186	R332	178	---	---	R352	179	---	---	R372	184
---	---	R323	186	R333	178	---	---	R353	178	R363	184	R373	184
---	---	R324	186	R334	178	---	---	R354	188	---	---	R374	171
---	---	R325	186	R335	178	---	---	R355	178	---	---	R375	198
---	---	R326	186	R336	178	R346	178	R356	178	---	---	R376	169
---	---	R327	178	---	---	---	---	R357	178	R367	186	R377	169
R318	186	R328	178	---	---	R348	186	R358	178	---	---	R378	172
R319	186	R329	178	R339	184	R349	178	R359	178	---	---	R379	189
R320	186	R330	186	R340	184	R350	178	R360	178	---	---	R380	196

38.CONTROLLER BOARD (B079/B082)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R381	192	R391	189	R401	178	RN1	145	RN11	148	---	---
R382	170	---	---	R402	178	RN2	145	RN12	148	---	---
R383	189	R393	178	R403	186	RN3	144	RN13	148	---	---
R384	197	R394	175	R404	188	RN4	144	RN14	144	RN24	144
R385	175	R395	175	R405	188	---	---	---	---	---	---
R386	186	R396	175	---	---	---	---	---	---	---	---
R387	169	R397	178	---	---	---	---	---	---	RN27	144
R388	192	R398	178	---	---	---	---	---	---	---	---
R389	175	R399	178	---	---	RN9	146	RN19	149	---	---
R390	192	R400	178	---	---	RN10	146	---	---	---	---

RN

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
---	---	RN51	148	RN61	148	RN71	151
---	---	RN52	148	RN62	148	RN72	151
---	---	RN53	151	RN63	144	RN73	148
RN44	146	RN54	151	RN64	144	RN74	151
RN45	146	RN55	151	RN65	151	RN75	151
---	---	RN56	151	RN66	151	RN76	150
---	---	RN57	147	RN67	151	RN77	150
RN48	148	RN58	144	RN68	151		
RN49	148	RN59	143	RN69	151		
RN50	144	RN60	148	RN70	151		

SW

SYMBOL NO.	INDEX NO.
SW1	112
SW2	113

38.CONTROLLER BOARD (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B082 5101	PCB:Adonis-C3:Main:35:Sub-Ass'y	1
1	B082 5102	PCB:Adonis-C3:Main:45:Sub-Ass'y	1
2	B065 5210	IC:ASIC:MARIMBA4	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1102 2391	Connector - HIF3FB-40PA-2.54DSA	
102	1102 6789	Connector - 100P	
103	1102 6815	Connector - 53258-0410	
104	1102 7615	Connector - B8B-XH-A	
105	1102 8153	Connector - FCN-568P068-G/05A-V4	
106	1102 8189	DIMM Connector - 54534-1440	
107	1102 8567	Connector - 52775-0800	
108	1102 8829	Connector - DM-1D4-N3210	
109	1102 8988	Connector	
110	1102 9180	Connector:leee	
111	1104 0588	DIP Socket - 28p	
112	1204 1385	Push Switch	
113	1204 1542	DIP Switch	
114	1400 0801	Transistor - DTC113ZUA	
115	1401 1205	Fet:HAT1044M	
116	1401 1206	Fet:HAT2054M	
117	1402 1265	Diode - RB411D	
118	1402 1343	Diode - RB106L-40	
119	1402 1664	Diode - HSU83	
120	1403 0907	Diode - SML-310LT	
121	1407 5047	CMOS Logic:TC7SH32FU	
122	1407 5275	CMOS Logic - 74LVCHR16245A TSSOP	
123	1407 5300	CMOS Logic - 74LVC16244A TSSOP	
124	1407 5321	CMOS Logic - 74LVCH16374A TSSOP	
125	1407 5322	IC - CMOS LOGIC SN74LVC161284DGG	
126	1407 5334	IC - CMOS LOGIC 74LVC244A TSSOP	
127	1407 5364	IC - SN74AHCT244PW	
128	1407 5366	IC - 74LVC08A TSSOP	
129	1407 5523	ROM - I2C SOP 3V	
130	1407 5528	IC - SN74LVC126APW	
131	1407 5529	IC - SN74LVC374ANS	
132	1407 5602	IC - SN74AHCT174PW	
133	1407 5604	IC - SN74LVC16245ADGG	
134	1407 5666	CMOS IC - NC7WZ17P6	
135	1407 5717	IC - ICS960001AF	

Index No.	Part No.	Description	Q'ty Per Assembly
136	1407 5809	CPC:RM7065A-300T-REV1.4	
137	1408 1273	IC - RN5VD28A	
138	1408 1398	Detector - RN5VD42A	
139	1408 1565	IC - RN5VD21A	
140	1408 1639	IC - RN5VD14A	
141	1408 1827	DC/DC Converter:SP6121CN	
142	1503 0842	Oscillator - 14.31818MHZ	
143	1601 7752	Resistor Array - 10K Ω \pm 5%	
144	1601 7867	Resistor - 33 Ω \pm 5% 1/16W	
145	1601 7871	Resistor - 68 Ω \pm 5% 1/16W	
146	1601 7879	Resistor - 22 Ω \pm 5% 1/16W	
147	1601 7899	Resistor Array - 56 Ω \pm 5% 1/16W	
148	1601 7915	Resistor Array - 33 Ω \pm 5% 1/16W	
149	1601 7916	Resistor - 47 Ω \pm 5% 1/16W	
150	1601 7919	Resistor - 10K Ω \pm 5% 1/16W 8	
151	1601 7926	Resistor - 68 Ω \pm 5% 1/16W 8	
152	1604 4729	Capacitor - 47 μ F \pm 20% 16V	
153	1604 4848	Capacitor - 100 μ F \pm 20% 10V	
154	1604 4918	Capacitor - 150 μ F \pm 20% 6.3V	
155	1604 4970	Capacitor - 33UF \pm 20% 50V	
156	1604 4992	Capacitor - 100 μ F \pm 20% 10V	
157	1604 4994	Capacitor - 100 μ F \pm 20% 6.3V	
158	1604 5153	Capacitor:220UF: \pm 20%:6.3V	
159	1605 0832	Capacitor - 8PF \pm 0.5pF 50V	
160	1605 0976	Capacitor - 1 μ F+80% -20% 10V	
161	1605 1124	Capacitor - 4.7 μ F+80 -20% 10V	
162	1605 1132	Capacitor - 2.2 μ F+80-20% 16V	
163	1605 1162	Capacitor - 10 μ F+80 -20% 10V	
164	1605 1354	Capacitor:1200pF: \pm 5%:50V	
165	1607 1206	Filter - Acc2012I-250	
166	1607 1225	Filter - Acc4516I-700	
167	1607 1228	Inductor - SLF7045-4R7M2R0	
168	1607 1422	Inductor:Slf12555-6r0n3r6	
169	1610 1353	Resistor:10k Ω : \pm 0.5%:1/16W	
170	1610 1355	Resistor:33k Ω : \pm 0.5%:1/16W	


Index No.	Part No.	Description	Q'ty Per Assembly
171	1610 1405	Resistor:20k Ω : \pm 0.5%:1/16W	
172	1610 1514	Resistor:3.3k Ω : \pm 0.5%:1/16W	
173	1633 0000	Resistor - 0 Ω 1/10W	
174	1634 0000	Resistor - 0 Ω 1/16W	
175	1650 4100	Resistor - 10 Ω \pm 5% 1/10W	
176	1650 4101	Resistor - 100 Ω \pm 5%1/10W	
177	1650 4102	Resistor - 1K Ω \pm 5% 1/10W	
178	1650 4103	Resistor - 10K Ω \pm 5% 1/10W	
179	1650 4109	Resistor - 1 Ω \pm 5% 1/10W	
180	1650 4121	Resistor - 120 Ω \pm 5%1/10W	
181	1650 4122	Resistor - 1.2K Ω \pm 5% 1/10W	
182	1650 4150	Resistor - 15 Ω \pm 5% 1/10W	
183	1650 4152	Resistor - 1.5K Ω \pm 5% 1/10W	
184	1650 4220	Chip Resistor - 22 Ω \pm 5% 1/10W	
185	1650 4229	Resistor - 2.2 Ω \pm 5% 1/10W	
186	1650 4330	Chip Resistor - 33 Ω \pm 5% 1/10W	
187	1650 4470	Resistor - 47 Ω \pm 5%1/10W	
188	1650 4472	Resistor - 4.7K Ω \pm 5% 1/10W	
189	1650 4519	Resistor:5.1 Ω : \pm 5%:1/10W	
190	1650 4561	Resistor - 560 Ω \pm 5% 1/10W	
191	1650 4562	Resistor - 5.6K Ω \pm 5% 1/10W	
192	1650 4622	Resistor:6.2k Ω : \pm 5%:1/10W	
193	1650 4680	Resistor - 68 Ω \pm 5%1/10W	
194	1650 4683	Resistor - 68K Ω \pm 5% 1/10W	
195	1650 4820	Resistor - 82 Ω \pm 5% 1/10W	
196	1654 1432	Resistor:14.3k Ω : \pm 1%:1/10W	
197	1654 2432	Resistor:24.3k Ω : \pm 1%:1/10W	
198	1654 9531	Resistor:9.53k Ω : \pm 1%:1/10W	
199	1660 2101	Capacitor - 100pF - \pm 10% - 50V	
200	1660 2121	Capacitor - 120pF \pm 5% 50V	
201	1660 2150	Capacitor - 15pF \pm 5% 50V	
202	1660 2221	Capacitor - 220pF +80-20% 50V	
203	1660 2270	Capacitor - 27pF \pm 20% 35V	
204	1660 2330	Capacitor - 33pF - \pm 5% - 50V	
205	1660 2390	Ceramic Capacitor - 39pF 50V	

39.DECAL AND DOCUMENT (B079/B082)


<p>1</p> <div>Rex-Rotary</div> <div>Gestetner</div> <div>nashuatec</div>	<p>6</p> <div>1 类激光产品</div>	<p>7</p> <div>레이저 제품 1등급 (CLASS 1 LASER PRODUCT)</div>	<p>8</p> <div>A1</div>	<p>9</p> <div>A2</div>
<p>2</p> <div>>PS<</div>	<p>10</p> <div> </div> <p>11</p> <div> <p>Caution When Turning Off the Main Power</p> </div> <p>12</p> <div> <p>CAUTION ATTENTION ACHTUNG ATTENZIONE ATTENCIÓN</p> </div> <p>14</p> <div> </div>			
<p>3</p> <div>开</div>	<p>4</p> <div>待机</div>	<p>13</p> <div> </div>	<p>16</p> <div> </div>	
<p>5</p> <div> <p>CAUTION</p> <p>注意 CAUTION ATTENTION</p> </div>		<p>15</p> <div> </div>		

39.DECAL AND DOCUMENT (B079/B082)


17




18




20




19




21




22




23



24



25













39.DECAL AND DOCUMENT (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A153 6409	Decal - Keytop Cover (GES)	1
1	C225 2866	Decal - Keytop Cover (REX)	1
1	C225 2867	Decal - Keytop Cover (NSA)	1
2	A232 1381	Decal - Total Counter	1
3	A232 6780	Decal - On (CHN)	1
4	A232 6781	Decal - Stand-by (CHN)	1
5	AA00 0204	Decal - Right Lower Cover	1
5	B004 7621	Decal (KOR)	1
6	AA00 0546	Decal:Laserclass1:CHN	1
7	AA00 0547	Decal:Laserclass1:KOR	1
8	AA00 1392	Decal - A1	1
9	AA00 1393	Decal - A2	1
10	AA00 3206	Decal:PCU:Spring:Caution Chart	1
11	B004 1383	Decal - Power Off - EXP	1
12	B004 4122	Decal - Warning	1
13	B004 4851	Decal - Jam Removal	1
14	B082 2965	Decal:Paper Set Direction	1
15	B082 3265	Decal:Caution Chart	1
16	B082 3992	Decal:Drum:Belt	1
17	B082 4852	Decal:Duplex	1
18	B082 4853	Decal:Duplex Unit:Upper	1
19	B082 6073	Decal:Manual Feed Direction	1
20	B082 6400	Decal:Size Indication	1
21	B082 6403	Decal:Power Source:Off:Exp	1
22	B387 6053	Original Scale Decal - A4	1
22	B387 6054	Original Scale Decal - LT	1
23	G020 1917	Decal - LD	1
24	G020 1920	Decal - Laser Diode	1
25	G029 1980	Decal - LD	1
26	GA00 3035	Energy Decal	1

Index No.	Part No.	Description	Q'ty Per Assembly


40.SPECIAL TOOLS (B079/B082)

1	2	3	4	5
				
6	7	8	9	10
				

40.SPECIAL TOOLS (B079/B082)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A230 9004	Positioning Pin Laser Unit	1
2	A230 9003	Adjusting Cam - Laser Unit	1
3	N803 6701	Flash Memory Card-4MB	1
4	A230 9354	Floppy Disk Kit - Memory Card Explo	1
5	A006 9104	Adjusting Scanner Pin (4pcs/set)	1
6	A292 9500	Test Chart - S5s (10 Pcs/set)	1
7	A029 9387	Digital Multimeter - Fluke87	1
8	A257 9300	GREASE - BARRIER A S552R	1
9	5203 9502	Grease 501	1
10	G021 9350	Loopback Connector - Parallel	1

Index No.	Part No.	Description	Q'ty Per Assembly



KASUN

Parts Index

Best Solution

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.
BY-PASS FEED UNIT 2 (B079/B082)	AF03 2046	Separation	Separation Roller - Manual Feed	1	29- 2
	AF03 1046	Paper Feed Roller	Feed Roller - Manual Feed	1	29- 12
	AF03 0049	Pick-up Roller	Pick-up Roller	1	29- 22
PAPER FEED SECTION (B079/B082))	AF03 0049	Pick-up Roller	Pick-up Roller	1	33- 7
	AF03 1049	Paper Feed Roller	Feed Roller	1	33- 10
	AF03 2049	Separation Roller	Separation Roller	1	33- 21
DEVELOPMENT UNIT 1 (B079/B082)	AA01 2102	Development Filter	Development Filter	1	41- 20
OPC UNIT (B079/B082)	AD02 5021	Pick-off Pawls	Pick-off Pawl	2	45- 7
	B082 2053	Drum Cleaning Blade 1	Cleaning Blade:Ass'y	1	45- 23
	AD04 1095	Drum Cleaning Blade 2	Cleaning Blade:Ass'y	1	45- 25
	B082 2029	Charge Roller Cleaning Roller	Brush Roller:Cleaner:Charge:Ass'y	1	45- 28
	AD02 7012	Charge Roller	Roller:Charge:Apply	1	45- 30
	A232 3330	Transfer Belt Cleaning Blade	Cleaning Blade - Transfer Belt	1	47- 6
	A232 3880	Transfer Belt	Transfer Belt	1	47- 10
TRANSFER UNIT (B079/B082)	AE04 2054	Cleaning Roller	Fusing Cleaning Roller:Ass'y	1	49- 17
FUSING UNIT 1 (B079/B082)	AW10 0052	Fusing Thermistor	Thermistor - Center	1	51- 4
FUSING UNIT 2 (B079/B082)	AW10 0053	Fusing Thermistor	Thermistor - Rear	1	51- 5
	AE04 4030	Hot Roller Stripper	Hot Rollerstripper	7	51- 10
	AE01 1071	Hot Roller	Hot Roller - 39.8mm T0.4	1	51- 15
	AE02 0123	Pressure Roller	Pressure Roller:Mm32:Ass'y	1	51- 20

Parts Index

Part No.	Description	Page and Index No.
B079 1144	Timing Pulley:Paddle (B079)	63 - 34
B079 6431	Decal EMBLEM (RIC)(B079)	11 - 2
B079 6433	Decal EMBLEM (GES NA)(B079)	11 - 2
B079 6434	Decal EMBLEM (GES EU)(B079)	11 - 2
B079 6435	Decal EMBLEM (NSA)(B079)	11 - 2
B079 6436	Decal EMBLEM (REX)(B079)	11 - 2
B079 6437	Decal EMBLEM (INF)(B079)	11 - 2
B079 6438	Decal EMBLEM (LAN)(B079)	11 - 2
B082 1073	Stay:Drum:Lower	37 - 26
B082 1076	Stay:Machine Or Copier:Rear	75 - 4
B082 1081	Bracket:Fix:Development	75 - 17
B082 1083	Bracket:Bicu:Right Upper	71 - 19
B082 1084	Bracket:BICU:Right Lower	65 - 3
B082 1087	Bracket:Fan:Front	71 - 4
B082 1133	Holder:OPC Drum:C3:Ass'y	63 - 22
B082 1142	Development Drive Unit:Ass'y	63 - 35
B082 1144	Timing Pulley:Paddle (B082)	63 - 34
B082 1158	Bracket:Belt:Plate	63 - 1
B082 1160	Bracket:Fusing Drive Sub-unit:Ass'y	63 - 31
B082 1177	Pulley:Mm17	67 - 31
B082 1272	Cover:Right Rear:Duplex (NA)	11 - 20
B082 1296	Cover:Rear:Paper Feed Sub-unit (NA)	13 - 12
B082 1362	Spacer:Scanner Unit:Duplex (NA)	13 - 19
B082 1372	Inner Cover:Upper	13 - 23
B082 1676	Bracket:Scale:Left	19 - 5
B082 1736	Side Plate:Front	21 - 20
B082 1738	Side Plate:Rear	21 - 21
B082 1831	Holder:Lens:Adonis-C3:Ass'y	19 - 9
B082 1842	Flexible Board:Ass'y	21 - 7
B082 1870	Imaging Unit:Adonis-C3:Ass'y (EU)	25 - 1
B082 1871	Imaging Unit:Na:Ass'y	25 - 1
B082 1891	Laser Diode Unit:Adonis-C3:Ass'y	25 - 8
B082 2202	PCU:Adonis-C3:Ass'y	43 - 1
B082 2217	Stopper:PCU:C3	43 - 5
B082 2220	Frame:PCU:Upper:Ass'y	43 - 10

Part No.	Description	Page and Index No.
B082 2288	Collection Coil:Ass'y	43 - 22
B082 2290	Bracket:Idler:Ass'y	43 - 25
B082 2292	Toner Collection Coil:Ass'y	43 - 17
B082 2302	Frame:PCU:Lower:Ass'y	45 - 8
B082 2312	Second Cleaning Blade	45 - 16
B082 2316	Stud:Contact Point:Cleaning:Ass'y	45 - 1
B082 2329	Brush Roller:Cleaner:Charge:Ass'y	45 - 28
B082 2333	Terminale:Brush Roller	45 - 20
B082 2353	Cleaning Blade:Ass'y	45 - 23
B082 2362	Stay:Around The Photoconductor	73 - 10
B082 2363	Magnet - Discharge Lamp	73 - 11
B082 2403	Supporter:PCU	37 - 31
B082 2574	Guide Plate:Entrance:Upper:Peen	37 - 21
B082 2575	Grip:Guide Plate	37 - 13
B082 2602	Case:Cleaner:Registration Roller	37 - 29
B082 2603	Cleaner:Registration Roller:Ass'y	37 - 28
B082 2611	Case:Registration Roller:Ass'y	37 - 16
B082 2614	Bracket:Registration Roller	37 - 15
B082 2750	Paper Feed Unit:Ass'y	33 - 4
B082 2760	Housing:Paper Feed Unit	33 - 16
B082 2781	Bracket:Sensor (1st Tray)	33 - 5
B082 2784	Shaft:Separate:Drive:Ass'y	33 - 20
B082 2903	Paper Tray:Universal:Ass'y	31 - 1
B082 2920	Side Fence:Front:Ass'y	31 - 4
B082 2925	Shield:Side Fence:Ass'y	31 - 8
B082 2930	Side Fence:Rear:Ass'y	31 - 15
B082 2937	Paper Stopper:Side Fence	31 - 20
B082 2955	Dial:Paper Size Sensor:Printing	31 - 21
B082 2965	Decal:Paper Set Direction	31 - 9
B082 2965	Decal:Paper Set Direction	97 - 14
B082 3010	Development Unit:Ass'y	41 - 1
B082 3065	Density Sensor:Development	41 - 26
B082 3100	Development Sleeve:Ass'y	41 - 4
B082 3121	Shield:Development Sleeve:Front:C3	41 - 5
B082 3122	Shield:Development Sleeve:Rear:C3	41 - 6

Part No.	Description	Page and Index No.
B082 3123	Shield:Case:Development:Front Rear:C3	41 - 24
B082 3208	Toner Supply Unit:C3:Ass'y	39 - 1
B082 3256	Shield:Developer:Cartridge:Upper Right	43 - 30
B082 3265	Decal:Caution Chart	39 - 9
B082 3265	Decal:Caution Chart	97 - 15
B082 3867	Shield:Remove Paper Dust	47 - 11
B082 3923	Bracket:Cleaning Blade:0.6	47 - 7
B082 3943	Cover:Right:EU	35 - 26
B082 3945	Shaft:Contact Point:Cover:Right	35 - 31
B082 3951	Duct:Cooling:Fusing:Right	35 - 32
B082 3952	Bracket:Fan	35 - 33
B082 3956	Cover:Fan	35 - 29
B082 3992	Decal:Drum:Belt	97 - 16
B082 3992	Decal:Drum:Belt	35 - 8
B082 4051	Frame:Fusing:Assy	51 - 25
B082 4054	Positioning Plate Front	51 - 21
B082 4111	Socket:Heater:Front	51 - 7
B082 4123	Fusing Entrance Guide Plate:Upper	49 - 20
B082 4131	Fusing Cover:Printing	49 - 5
B082 4142	Duct:Fusing:Front	49 - 10
B082 4144	Shield:Fusing Cover	49 - 6
B082 4145	Shield:Duct:Front Lower	49 - 11
B082 4147	Cover:Duct:Fusing:Front	49 - 8
B082 4148	Shield:Cover:Upper	49 - 7
B082 4149	Shield:Cover:Lower	49 - 9
B082 4152	Duct:Fusing:Front Lower	49 - 12
B082 4153	Shield:Duct:Fusing:Front Lower:Long	49 - 13
B082 4199	Shielding Plate:Cover:Right	35 - 34
B082 4322	Guide Plate:Exit:Entrance	35 - 13
B082 4466	Bracket:Contact Point:Ass'y	53 - 13
B082 4472	Side Plate:Rear:Ass'y	55 - 17
B082 4852	Decal:Duplex	57 - 2
B082 4852	Decal:Duplex	97 - 17
B082 4853	Decal:Duplex Unit:Upper	57 - 21
B082 4853	Decal:Duplex Unit:Upper	97 - 18

Part No.	Description	Page and Index No.
B082 5065	PCB:BICU:Ass'y	85 - *
B082 5065	PCB:BICU:Ass'y	71 - 18
B082 5101	PCB:Adonis-C3:Main:35:Sub-Ass'y	93 - *
B082 5101	PCB:Adonis-C3:Main:35:Sub-ass'y	77 - 3
B082 5102	PCB:Adonis-C3:Main:45:Sub-Ass'y	93 - 1
B082 5102	PCB:Adonis-C3:Main:45:Sub-ass'y	77 - 3
B082 5130	IC:CDICA:RL5C481A	85 - 2
B082 5136	IC:RI1001:230MHZ	85 - 3
B082 5155	PCB:IOB	65 - 9
B082 5155	PCB:IOB	81 - *
B082 5194	PCB:Mother Board	77 - 1
B082 5203	PCB:LCDC:NA:Ass'y	17 - 8
B082 5204	PCB:LCDC:EU:Ass'y	17 - 8
B082 5205	PCB:LCDC:TWN:Ass'y	17 - 8
B082 5206	PCB:LCDC:CHN:Ass'y	17 - 8
B082 5207	PCB:LCDC:KOR:Ass'y	17 - 8
B082 5218	LCD:H-VGA:HLM7701:BI	17 - 6
B082 5219	Touch Panel:HVGA	17 - 3
B082 5291	Harness:Laser Diode Control	71 - 17
B082 5387	PCB:SIB	19 - 18
B082 5420	Harness:Registration Sensor	37 - 20
B082 5425	Harness:BICU:IOB	71 - 16
B082 5426	Harness:Paper Feed:Main	65 - 11
B082 5427	Harness:Manual Feed Unit	29 - 28
B082 5428	Harness:Paper Feed Unit	33 - 38
B082 5430	Harness:Paper Feed Unit:No.1	33 - 38
B082 5437	Harness:Sensor:On-off:Connecting	63 - 39
B082 5445	Harness:Imaging Unit	25 - 7
B082 5453	Harness:DC:Development:Drawer	65 - 5
B082 5455	Harness:Paper Size Sensor	65 - 23
B082 5457	Harness:DC:Safety Switch	69 - 14
B082 5459	Harness:DC:Exit	53 - 2
B082 5460	Harness:Duplex Unit	59 - 16
B082 5461	Harness:Duplex Unit:Sensor	59 - 17
B082 5462	Harness:Duplex Unit:Sensor	61 - 22

Part No.	Description	Page and Index No.
B082 5465	Harness:Paper Feed:Sensor	65 - 14
B082 5466	Harness:Sensor:Fusing:Used Toner Sensor	35 - 35
B082 5466	Harness:Sensor:Fusing:Used Toner Sensor	35 - 15
B082 5467	Harness:DC:Upper	65 - 13
B082 5468	Harness:DC:Machine Or Copier:Lower	65 - 10
B082 5469	Harness:DC:Upper Front	65 - 12
B082 5470	Harness:Connecting:Right Rear	35 - 3
B082 5475	Harness:HDD	77 - 16
B082 5476	Harness:HDD:Power Source	77 - 15
B082 5521	Harness:DC:DC Power Supply	69 - 16
B082 5538	Harness:OPU	19 - 19
B082 5541	Harness:Scanner:ADF	19 - 14
B082 5543	Harness:SIB	19 - 16
B082 5601	Power Supply Cord:Stopper:NA:Ass'y	69 - 12
B082 5606	Harness:AC:Switch	69 - 15
B082 5832	Bracket:I/O Board:Left Upper	65 - 8
B082 5833	Bracket:I/O Board:Left Lower	65 - 15
B082 5836	Bracket:I/O Board:Right Upper	65 - 7
B082 5837	Bracket:I/O Board:Right Lower	65 - 2
B082 5839	Bracket:Harness:Paper Feed	65 - 1
B082 5850	Bracket:Control Board:Ass'y	77 - 12
B082 5855	Cover:Connector:Centronics	77 - 9
B082 5856	Cover:Gwphy	77 - 10
B082 5864	Bracket:Harness:Joint Unit	71 - 2
B082 5871	Bracket:PCB:MLB	65 - 21
B082 5878	Gasket:Bracket:Rack	71 - 22
B082 5881	Bracket:Rack:Application	71 - 20
B082 5886	Panel:Rack	77 - 7
B082 5891	Bracket:HDD	77 - 18
B082 5892	Spring Plate:HDD	77 - 21
B082 5897	Bracket:Connector	69 - 10
B082 6009	By-pass Feed Table Ass'y	27 - 24
B082 6028	Guide Plate:Separator:Ass'y	29 - 10
B082 6033	Shaft:Separator:Driven:Ass'y	29 - 4
B082 6059	Arm:Tightener:Ass'y	29 - 33

Part No.	Description	Page and Index No.
B082 6061	Bracket:Drive:Ass'y	29 - 38
B082 6073	Decal:Manual Feed Direction	27 - 16
B082 6073	Decal:Manual Feed Direction	97 - 19
B082 6095	Frame:Holder:Ass'y	27 - 2
B082 6319	Cover:Right Rear:Duplex:EU	11 - 20
B082 6332	Cover:Rear:EU	13 - 12
B082 6342	Spacer:Scanner Unit:Duplex:EU	13 - 19
B082 6350	Operation Sub-unit:NA:Ass'y	17 - 1
B082 6360	Operation Sub-unit:EU:Ass'y	17 - 1
B082 6370	Operation Sub-unit:TW:Ass'y	17 - 1
B082 6375	Operation Sub-unit:CHN:Ass'y	17 - 1
B082 6380	Operation Sub-unit:KOR:Ass'y	17 - 1
B082 6385	Operation Sub-unit:AA:Ass'y	17 - 1
B082 6400	Decal:Size Indication	97 - 20
B082 6400	Decal:Size Indication	9 - 12
B082 6403	Decal:Power Source:Off:Exp	97 - 21
B082 6403	Decal:Power Source:Off:Exp	11 - 17
B082 6405	Sheet:Operation Instructions:RIC	11 - 6
B082 6431	Decal EMBLEM (RIC)(B082)	11 - 2
B082 6433	Decal EMBLEM (GES NA)(B082)	11 - 2
B082 6434	Decal EMBLEM (GES EU)(B082)	11 - 2
B082 6435	Decal EMBLEM (NSA)(B082)	11 - 2
B082 6436	Decal EMBLEM (REX)(B082)	11 - 2
B082 6437	Decal EMBLEM (INF)(B082)	11 - 2
B082 6438	Decal EMBLEM (LAN)(B082)	11 - 2
B082 6506	Operating Instructions:Main:RIC:CHN:Chinese	9 - 13
B082 6508	Operating Instructions:Main:RIC:AA:English	9 - 13
B082 6509	Operating Instructions:Main:RIC:TWN:Taiwan	9 - 13
B082 6510	Operating Instructions:Main:RIC:GSA:English	9 - 13
B082 6606	Operating Instructions:Copy:RIC:CHN:Chinese	9 - 13
B082 6608	Operating Instructions:Copy:RIC:AA:English	9 - 13
B082 6609	Operating Instructions:Copy:RIC:TWN:Taiwan	9 - 13
B082 6610	Operating Instructions:Copy:RIC:GSA:English	9 - 13
B082 7320	Fusing Unit:NA:Ass'y	49 - 1
B082 7720	Fusing Unit:EU:Ass'y	49 - 1

Part No.	Description	Page and Index No.
A006 9104	Adjusting Scanner Pin (4pcs/set)	99 - 5
A029 9387	Digital Multimeter - Fluke87	99 - 7
A053 1957	Flex Hinge - Platen Cover	15 - 4
A134 2661	Feeler Roller	29 - 17
A134 2843	Spacer 6x30x1.5	29 - 40
A134 3180	Bottle Chuck	39 - 13
A153 6409	Decal - Keytop Cover (GES)	97 - 1
A193 1248	Platen Cover Hinge Assembly	15 - 8
A230 2520	Heat Sink - Heater	75 - 1
A230 2525	Heater Stopper	75 - 20
A230 2688	Film - Stay - Upper Front	75 - 15
A230 9003	Adjusting Cam - Laser Unit	99 - 2
A230 9004	Positioning Pin Laser Unit	99 - 1
A230 9354	Floppy Disk Kit - Memory Card Explo	99 - 4
A230 9510	OPC DRUM	45 - 22
A232 1074	Guide - Transfer Entrance	37 - 25
A232 1089	Upper Plate - Laser Unit	73 - 3
A232 1172	Duct - Cooling Fan	69 - 2
A232 1251	Duct Cover - Lower Exhaust Ass'y	13 - 31
A232 1257	Cap - Upper Cover	13 - 11
A232 1282	Cap - Switch	11 - 16
A232 1284	Spring Holder	37 - 34
A232 1284	Spring Holder	13 - 15
A232 1284	Spring Holder	43 - 11
A232 1381	Decal - Total Counter	97 - 2
A232 1381	Decal - Total Counter	13 - 29
A232 1707	Second Slide Rail	23 - 7
A232 1713	Lens Block Supporter	23 - 20
A232 1728	Rail Supporter	23 - 5
A232 1731	Scanner Rail	23 - 6
A232 1771	Drive Shaft	23 - 14
A232 1789	1st Mirror Holder	21 - 11
A232 1808	Harness Guide	21 - 2
A232 1900	Housing - Laser Unit	25 - 9
A232 1920	Seal - Heat Sink	25 - 12

Part No.	Description	Page and Index No.
A232 1921	Front Holder - F Theta Mirror	25 - 22
A232 1922	Rear Holder - F Theta Mirror	25 - 24
A232 1923	Front Holder - BTL	25 - 19
A232 1924	Rear Holder - BTL	25 - 21
A232 1925	Middle Mirror Holder	25 - 18
A232 1926	Mirror Holder	25 - 16
A232 1927	Cylindrical Lens Holder	25 - 13
A232 1928	Holder - Sync. Detector Mirror	25 - 26
A232 1937	Positioning Pin - Laser Unit Ass'y	73 - 17
A232 2280	Tape - Entrance Seal	43 - 12
A232 2288	Shaft - Toner Collection Mylar	43 - 21
A232 2289	Front Bushing - Collection Mylar	43 - 20
A232 2290	Bushing - Collection Mylar	43 - 23
A232 2292	Bushing - Toner Collection Coil	43 - 18
A232 2308	Rear Terminal - Charge Roller	45 - 19
A232 2315	Front Bushing - Cleaning Bracket	45 - 13
A232 2318	Collar - Cleaning	45 - 17
A232 2339	Spur	45 - 6
A232 2340	Holder - Pick-off Pawl	45 - 4
A232 2354	Front Terminal - Charge Roller	45 - 27
A232 2366	Holder - ID Sensor	37 - 32
A232 2367	ID Sensor	37 - 33
A232 2372	Lock Lever - Transfer Unit	63 - 6
A232 2380	Terminal Plate - Charge Roller	63 - 24
A232 2381	Harness - Charge Roller	63 - 26
A232 2382	Terminal Plate - Development Bias	63 - 27
A232 2383	Harness - Development Bias	63 - 25
A232 2421	Bushing - 6x10x3	45 - 29
A232 2578	Stopper - Guide Plate	37 - 7
A232 2692	Cover - Paper Drive	67 - 10
A232 2722	Knob	11 - 13
A232 2762	Paper End Feeler	33 - 18
A232 2763	Pick-up Arm	33 - 13
A232 2764	Rear Grounding Plate	33 - 34
A232 2765	Front Grounding Plate	33 - 15

Part No.	Description	Page and Index No.
A232 2766	Feed Mylar	33 - 17
A232 2785	Vertical Guide	33 - 3
A232 2860	Entrance Seal	11 - 25
A232 2862	Driven Roller	11 - 21
A232 2863	Stopper Band	11 - 32
A232 2987	Roller - Paper Tray	31 - 13
A232 2995	Front Positioning Guide	75 - 12
A232 2996	Rear Positioning Guide	65 - 17
A232 3067	Tape - TD Sensor	41 - 25
A232 3068	Front Bias Terminal - Development	41 - 27
A232 3069	Rear Bias Terminal - Development	41 - 22
A232 3077	Spacer - M5	41 - 12
A232 3150	Entrance Seal Ass'y	41 - 3
A232 3155	Front Cover - Development Unit	41 - 10
A232 3230	Case - Toner Supply Ass'y	39 - 7
A232 3240	Cover- Toner Bottle Ass'y	39 - 14
A232 3251	Chuck Shaft	39 - 11
A232 3252	Slider Ass'y	39 - 12
A232 3261	Handle - Toner Supply	39 - 5
A232 3263	Spring Plate - Toner Bottle	39 - 6
A232 3264	Stopper - Slide Rail	73 - 8
A232 3266	Seal - Slide Rail	39 - 2
A232 3267	Front Entrance Seal - Toner Supply	43 - 14
A232 3552	Ball Bearing - 8x22x7	67 - 25
A232 3553	Ball Bearing - 8x16x5	45 - 21
A232 3566	Ball Bearing - 8x16x5	23 - 15
A232 3830	Cleaning Blade - Transfer Belt	47 - 6
A232 3880	Transfer Belt	47 - 10
A232 3882	Flange - Transfer Unit	47 - 33
A232 3883	Spring Plate - Transfer Unit	47 - 25
A232 3885	Driven Roller - Transfer Unit	47 - 26
A232 3887	Rear Terminal - Transfer Belt	47 - 27
A232 3889	Bias Roller	47 - 30
A232 3891	Bias Terminal	47 - 34
A232 3893	Arm - Transfer Belt	47 - 35

Part No.	Description	Page and Index No.
A232 3894	Drive Roller - Transfer Belt	47 - 36
A232 3905	Seal - Shield Plate	47 - 4
A232 3906	Seal - Rear Transfer Exit	47 - 3
A232 3907	Seal - Transfer Exit	47 - 2
A232 3908	Seal - Rear Case	47 - 9
A232 3909	Seal - Front Case	47 - 8
A232 3916	Pressure Lever - Transfer Belt	47 - 22
A232 3921	Spring Anchor	47 - 18
A232 3924	Rear Bushing - Cleaning Holder	47 - 13
A232 3925	Front Bushing - Cleaning Holder	47 - 20
A232 3926	Transfer Belt Roller	47 - 32
A232 3927	Shield - Transfer Belt - Exit	47 - 5
A232 3935	Shaft - Transfer Unit Stopper	47 - 19
A232 3942	Stopper - Right Cover	35 - 28
A232 3945	Front Hook - Right Cover	35 - 24
A232 3948	Rear Hook - Right Cover	35 - 20
A232 3950	Hook Lever	35 - 5
A232 3962	Spring Plate - Band Stopper	35 - 6
A232 3963	Band Stopper	35 - 7
A232 3998	Upper Entrance Guide	35 - 17
A232 3999	Lower Entrance Guide	35 - 18
A232 4057	Front Collar - Pressure Lever	51 - 22
A232 4058	Rear Collar - Pressure Lever	51 - 27
A232 4064	C Ring - Hot Roller	51 - 12
A232 4201	Stopper - Fusing Unit	73 - 14
A232 4484	Solenoid - Exit Gate	55 - 6
A232 4499	Copy Tray Mylar	13 - 14
A232 4647	Driven Guide Plate	57 - 13
A232 4653	Pressure Plate - Guide Plate	57 - 9
A232 4685	Hook - Unit Release	59 - 5
A232 5355	IC - GATEX	81 - 1
A232 5527	Power Supply Cord-230V	69 - 12
A232 5528	Power Supply Cord - 230V (CHN)	69 - 12
A232 5838	Spring Plate - BICU	11 - 29
A232 6023	Grounding Plate - Reverse	29 - 15

Part No.	Description	Page and Index No.
A232 6035	Shaft - Drive Roller	29 - 9
A232 6043	Arm Paper Pick Up	29 - 20
A232 6046	Grounding Plate - Feed	29 - 25
A232 6049	Solenoid Bracket	29 - 37
A232 6051	Pickup Solenoid	29 - 27
A232 6055	Paper End Feeler	29 - 16
A232 6080	Paper Size Detector	27 - 15
A232 6082	Front Rack	27 - 12
A232 6083	Rear Rack	27 - 14
A232 6091	Positioning Pin	27 - 7
A232 6092	Roller - Holder	27 - 18
A232 6780	Decal - On (CHN)	97 - 3
A232 6781	Decal - Stand-by (CHN)	97 - 4
A232 7756	Harness - Circuit Breaker	69 - 19
A235 2979	Feeler - Paper Height Sensor	31 - 26
A257 9300	GREASE - BARRIERTA S552R	99 - 8
A284 1376	Inner Cover-left	13 - 26
A284 1674	Exposure Glass Holder	21 - 14
A284 1904	Cover - Optical Housing	25 - 5
A285 5842	Gasket - Rack	77 - 8
A292 9500	Test Chart - S5s (10 Pcs/set)	99 - 6
A293 5310	Sync Detector Board	25 - 27
A680 1181	Magnetic Catch	57 - 19
B002 1898	Heat Sink:Polygon Scanner:M:Ass'y	25 - 11
B004 1091	Grip:Rear	75 - 5
B004 1093	Rear Stay	75 - 6
B004 1167	Flange - 24mm	67 - 9
B004 1177	Spacer - By-pass Feed	67 - 18
B004 1320	Base Cover	67 - 35
B004 1321	Shield Plate - BICU	65 - 20
B004 1322	Shield Plate - DC Motor	65 - 19
B004 1325	Cover - Shield Glass	13 - 25
B004 1383	Decal - Power Off - EXP	97 - 11
B004 1503	Keytop - Clear/Stop	17 - 14
B004 1505	Keytop - Start	17 - 17

Part No.	Description	Page and Index No.
B004 1515	Sheet - Prevent Fence Sheet - Right	17 - 24
B004 1516	Sheet-preventfence Sheet-Left	17 - 12
B004 1517	Earth Sheet - Touch Panel	17 - 2
B004 1518	Operation Panel Board - Right	17 - 25
B004 1519	Operation Panel Board - Left	17 - 13
B004 1525	Cushion:Touch Panel:Short	17 - 4
B004 1526	Cushion:Touch Panel:Long	17 - 5
B004 1713	Pulley 2 - 22MM	23 - 10
B004 1714	Idler Bracket	23 - 19
B004 1726	Rail - Flexible Board	23 - 9
B004 1728	Bracket - Heater	23 - 1
B004 1741	Bracket:Power Supply Cord:Heater:Exp:Ass'y	23 - 3
B004 1742	Bracket:Power Supply Cord	23 - 4
B004 1809	Carriage Pulley - 22mm	21 - 5
B004 1820	2nd Mirror Ass'y	21 - 4
B004 1841	Scanner Interface Cable	19 - 17
B004 1936	Plate - Optical Housing Unit	65 - 25
B004 1938	Holder - Optical Housing Unit	67 - 11
B004 1939	Holder - Optical Housing Unit	65 - 24
B004 2212	Front Seal - Cleaning Cover	43 - 28
B004 2215	Entrance Seal - Toner Supply	43 - 16
B004 2319	Spur	37 - 30
B004 2597	Sheet - Separation Plate	75 - 3
B004 2777	Shaft - Paper Separation	33 - 23
B004 2782	Rear Feed Mylar	33 - 24
B004 2783	Torque Limiter	29 - 3
B004 2783	Torque Limiter	33 - 22
B004 2915	Bottom Lift Shaft	31 - 25
B004 2922	Release Lever - Side Fence	31 - 6
B004 2923	Spring Plate - Release Lever	31 - 7
B004 2932	Rear Stopper Lever	31 - 18
B004 2933	Rear Stopper	31 - 17
B004 2934	Spring Plate - Lock Lever	31 - 19
B004 2936	Gear - 16Z	31 - 14
B004 2943	Grounding Plate - Paper Tray	31 - 24

Part No.	Description	Page and Index No.
B004 2947	Spring Plate-paper Size Sensor	31 - 23
B004 2948	Paper Size Sensor	31 - 22
B004 2995	Cap - Positioning	75 - 10
B004 3062	Ground Plate- Doctor Blade	41 - 28
B004 3078	Joint - Paddle	41 - 23
B004 3900	Case - Transfer Unit	47 - 21
B004 3914	Mylar - Belt Drive Roller	47 - 1
B004 4087	Plate- Thermistor	51 - 3
B004 4095	Terminal Plate - Fusing Unit	49 - 15
B004 4122	Decal - Warning	73 - 15
B004 4122	Decal - Warning	97 - 12
B004 4126	Lower Entrance Guide Plate	49 - 21
B004 4133	Cap- Fusing Cover	49 - 2
B004 4135	Guide Plate-fusing Exit	49 - 3
B004 4327	Bushing - 4mm	35 - 37
B004 4328	Roller:Driven:Ass'y	35 - 36
B004 4329	Grounding Plate - Exit Sensor	35 - 14
B004 4330	Screw - 4.5MM	35 - 11
B004 4434	Harness Guide	53 - 4
B004 4438	Bushing	55 - 1
B004 4440	Middle Guide - Paper Exit	13 - 13
B004 4453	Lower Guide Plate	53 - 7
B004 4458	Pressure Arm - Exit	53 - 10
B004 4460	Shaft-pressure Roller	53 - 9
B004 4469	Spring Plate - Exit Roller	53 - 20
B004 4477	Upper Guide Plate	55 - 5
B004 4478	Entrance Junction Gate	55 - 2
B004 4479	Lever - Entrance Junction Gate	55 - 21
B004 4481	Exit Junction Gate	55 - 12
B004 4486	DC Solenoid	55 - 18
B004 4497	Ground Plate - Discharge Brush	55 - 26
B004 4622	Guide Plate - Right Lower	61 - 5
B004 4645	Guide Plate - Middle	57 - 4
B004 4664	DC Motor - 28W	61 - 14
B004 4664	DC Motor - 28W	59 - 22

Part No.	Description	Page and Index No.
B004 4690	Link Solenoid Ass'y	59 - 24
B004 4851	Decal - Jam Removal	57 - 12
B004 4851	Decal - Jam Removal	97 - 13
B004 5120	IC - HG71C114FL	85 - 1
B004 5140	Main Board - Duplex	59 - 15
B004 5397	Motor Drive Board	19 - 20
B004 5470	Outlet:Ground Wire:Ass'y	69 - 18
B004 5528	Power Supply Cord:Stopper:EU:RPL:Ass'y	69 - 12
B004 5542	Harness - Sbu-50wick 80mm	19 - 15
B004 5608	Main Harness - Fusing Unit (EU)	71 - 6
B004 5609	Main Harness - Fusing Unit (NA)	71 - 6
B004 5611	Harness - Heater	75 - 21
B004 5611	Harness - Heater	69 - 17
B004 5842	Gasket - Duplex Unit	57 - 25
B004 5843	Shoulder Screw	57 - 24
B004 5853	Bracket Grip	77 - 13
B004 5887	Eeehion:Panel:Rack	77 - 6
B004 6024	Supporting Plate:Contact Point	27 - 25
B004 6062	Pressure Plate - By-pass Feed	29 - 41
B004 7621	Decal (KOR)	97 - 5
B065 1371	Cloth Holder	9 - 15
B065 1371	Cloth - DF Exposure Glass	9 - 16
B065 5210	IC:ASIC:MARIMBA4	93 - 2
B077 1021	Grip:Adhesion	75 - 13
B077 1023	Stopper:Grip	75 - 14
B077 1051	Bracket:Shaft:Stopper:Ass'y	73 - 9
B077 1053	Bracket:Stay:Lengthwise:Rear	65 - 18
B077 1054	Bracket:Connector:Fusing	73 - 6
B077 1055	Guide Plate:Arm:Scanner Unit	69 - 11
B077 1066	Stay:Paper Exit Sub-unit:Left	73 - 1
B077 1067	Bracket:Plate:Joint Unit	73 - 2
B077 1069	Frame:Middle	73 - 4
B077 1071	Supporter:Fusing Unit:Welding	73 - 13
B077 1078	Supporter:Development Unit	73 - 16
B077 1082	Base:Fix:Development	75 - 16

Part No.	Description	Page and Index No.
B077 1126	Bracket:Harness	71 - 1
B077 1130	Bracket:OPC Drum:Plate	63 - 36
B077 1135	Bracket:Holder:OPC Drum	63 - 20
B077 1140	Supporting Plate:Developmen:Unit	63 - 32
B077 1153	Bracket:Transfer Drive:Ass'y	63 - 11
B077 1156	Bracket:Belt:Positioning:Ass'y	63 - 5
B077 1170	Tightener:Paper Feed:Ass'y	67 - 17
B077 1172	Guide Plate:Upper	67 - 22
B077 1174	Bracket:Middle	67 - 30
B077 1175	Tightener:Middle:Ass'y	67 - 33
B077 1178	Bracket:Protect:Ass'y	67 - 24
B077 1182	Guide Plate:Lower	67 - 23
B077 1185	Bracket:Timing Pulley	67 - 6
B077 1250	Cover:Upper (NA)	13 - 35
B077 1251	Cover:Connector:Scanner	13 - 27
B077 1252	Cover:Upper Right:Small (NA)	13 - 33
B077 1253	Cap:34x55	13 - 36
B077 1261	Cover:Front:Ass'y	11 - 5
B077 1264	Cover:Front Upper:Paper Feed Sub-UN	11 - 1
B077 1266	Bracket:Hinge:Left	75 - 18
B077 1267	Bracket:Hinge:Right	75 - 8
B077 1275	Cover:Arm:Scanner Unit	9 - 10
B077 1276	Cover:Arm:Right	9 - 9
B077 1283	Cover:Left Rear (NA)	11 - 19
B077 1285	Cover:Left:Paper Feed Sub-unit (NA)	11 - 8
B077 1286	Stopper:Left	11 - 7
B077 1291	Cover:Rear (NA)	13 - 10
B077 1297	Cover:Rear:Paper Feed Sub-unit	13 - 16
B077 1305	Inner Cover:Right	35 - 9
B077 1330	Cover:Upper Rear:Scanner (NA)	9 - 6
B077 1336	Cover:Right:Scanner (NA)	9 - 8
B077 1337	Cover:Left:Scanner (NA)	9 - 3
B077 1338	Cover:Lower:Operation Sub-unit (NA)	9 - 1
B077 1363	Plate Nut:Spacer:Scanner Unit	13 - 20
B077 1364	Ground Plate:Spacer:Rear	13 - 21

Part No.	Description	Page and Index No.
B077 1365	Ground Plate:Spacer:Front	13 - 22
B077 1371	Bracket:Scanner Unit:Front:Peen	13 - 18
B077 1373	Bracket:Scanner Unit:Rear:Peen	13 - 17
B077 1382	Guide Plate:Scanner Unit:Peen	13 - 5
B077 1384	Supporting Plate:Arm:Scanner Unit	13 - 6
B077 1385	Arm:Scanner Unit	13 - 7
B077 1502	Keytop:10key (EU/TWN)	17 - 23
B077 1504	Keytop:Try Print	17 - 16
B077 1506	Keytop:Power Source	17 - 15
B077 1508	Keytop:Preheat	17 - 21
B077 1509	Keytop:Block Diagram	17 - 19
B077 1510	Keytop:Confirm	17 - 18
B077 1511	Keytop:Counter	17 - 11
B077 1512	Keytop:Interrupt	17 - 22
B077 1513	Dial:Contrast	17 - 10
B077 1520	Bracket:LCDC	17 - 7
B077 1521	Cover:LCDC	17 - 9
B077 1534	Cover:Application	17 - 27
B077 1535	Cover:Basic	17 - 26
B077 1678	Stay:Right	19 - 1
B077 1681	Inner Cover:Ass'y	19 - 8
B077 1712	Bracket:Tension:Wire:Front	23 - 23
B077 1722	Bracket:Tension:Wire:Rear	23 - 13
B077 1728	Base:Scanner:Rear	21 - 24
B077 1739	Bracket:Hinge	19 - 11
B077 1742	Bracket:Fan	19 - 3
B077 1751	Stepper Motor:Scanner:Ass'y	19 - 24
B077 1781	Carriage:No.1:Ass'y	21 - 10
B077 1791	Clamp:Wire:Front	21 - 9
B077 1792	Clamp:Wire:Rear	21 - 8
B077 1801	Carriage:No.2:Ass'y	21 - 1
B077 1844	Bracket:Home Position Sensor	21 - 23
B077 1846	Bracket:MDB:Left	19 - 21
B077 1847	Bracket:MDB:Right	19 - 22
B077 1849	Bracket:Connector:ARDF	19 - 13

Part No.	Description	Page and Index No.
B077 1904	Cap:Cover:Optical Housing	25 - 3
B077 1907	Supporting Plate:Cover:Imaging Unit	25 - 4
B077 1968	Shadeing Plate:Ass'y	75 - 19
B077 2583	Guide Plate:Entrance:Lower:Adhesion	37 - 17
B077 2594	Bracket:Registration Sensor	37 - 18
B077 2596	Link:Guide Plate:Open And Close	37 - 11
B077 2720	Bracket:Knob:Ass'y	11 - 10
B077 2723	Supporting Plate:Knob	11 - 15
B077 2724	Cover:Knob	11 - 9
B077 2770	Stay:Separate:Ass'y	33 - 31
B077 2780	Stay:Feed	33 - 2
B077 2781	Bracket:Sensor	33 - 5
B077 2857	Cover:Vertical Transport	11 - 28
B077 2858	Supporting Plate:Upper	11 - 24
B077 2859	Supporting Plate:Lower	11 - 30
B077 2861	Cover:Vertical Transport:Duplex:EU	11 - 28
B077 2876	Cover:Vertical Transport:Lower	11 - 34
B077 2882	Bracket:Micro Switch	67 - 37
B077 2921	Side Fence:Front	31 - 5
B077 2931	Side Fence:Rear	31 - 16
B077 2940	Tray Bottom Plate:Ass'y	31 - 2
B077 2951	Stopper:Right:Paper Tray	31 - 27
B077 2952	Shoe:Left	31 - 12
B077 2975	Lever:Rise	31 - 28
B077 2988	Cover:Grip:C3	31 - 10
B077 2990	Supporter:Paper Tray:Ass'y	75 - 11
B077 3210	Guide:Toner Supply Unit:Ass'y	73 - 7
B077 3262	Slide Rail:Toner Supply Unit	39 - 3
B077 3913	Lever:Rear	47 - 24
B077 3914	Lever:Front	47 - 23
B077 3917	Lever:Release:Pressure:Peen	47 - 12
B077 3985	Link:Cover:Ass'y	37 - 9
B077 3999	Lever:Handle:C3	35 - 10
B077 4055	Stay:Fusing:Thermostat	51 - 6
B077 4056	Lever:Pressure	51 - 23

Part No.	Description	Page and Index No.
B077 4081	Frame:Fusing:Upper	51 - 8
B077 4092	Bracket:Drawer:Fusing:Welding	49 - 14
B077 4115	Socket:Heater:Rear	51 - 11
B077 4323	Bracket:Paper Feed Sensor	35 - 16
B077 4435	Guide:Copy Tray	13 - 3
B077 4436	Guide:Copy Tray:Auxiliary	13 - 2
B077 4437	Supporting Plate:Frame:Left Lower	53 - 17
B077 4439	Bracket:Protect:Middle	55 - 14
B077 4455	Frame:Left Lower	53 - 18
B077 4463	Arm:Pressure:Entrance	53 - 12
B077 4471	Side Plate:Front	55 - 10
B077 4490	Supporting Plate:Frame:Right	53 - 21
B077 4493	Joint:Machine Or Copier	53 - 5
B077 4494	Bracket:Paper Feed Sensor	53 - 3
B077 4497	End Fence:Copy Tray:C3	13 - 1
B077 4630	Stay:Lower	61 - 7
B077 4634	Guide Plate:Reverse:Peen	59 - 8
B077 4638	Side Plate:Front:Ass'y	59 - 25
B077 4642	Side Plate:Rear:Ass'y	59 - 13
B077 4666	Bracket:Stepper Motor:Ass'y	59 - 21
B077 4678	Bracket:Stepper Motor	61 - 12
B077 4684	Grip:Un Lock	59 - 2
B077 4697	Bracket:Micro Switch:Ass'y	61 - 18
B077 4701	Cover:Duplex Unit	57 - 18
B077 4711	Cover:Duplex Unit:Right	57 - 11
B077 4716	Guide Plate:Right	57 - 20
B077 4720	Inner Cover:Duplex Unit:Front	57 - 1
B077 4730	Inner Cover:Duplex Unit:Rear	57 - 6
B077 4757	Bracket:Sensor:Paper Feed	61 - 8
B077 4763	Bracket:Entrance Sensor	59 - 6
B077 4790	Link:Duplex:Peen	61 - 20
B077 4793	Bracket:Link:Machine Or Copier:Ass'y	57 - 8
B077 4795	Bracket:Sensor	61 - 16
B077 4796	Stay:Middle	61 - 21
B077 4800	Bracket:Base	59 - 14

Part No.	Description	Page and Index No.
B077 4810	Cover:Harness:Duplex	57 - 7
B077 5811	Bracket:Power Pack:Left	69 - 7
B077 5812	Bracket:Power Pack:Right	69 - 6
B077 5825	Bracket:Connector:Harness	71 - 15
B077 5856	Supporter:Control Board	77 - 2
B077 5860	Bracket:Safety Switch	71 - 10
B077 5861	Lever:Safety Switch	71 - 8
B077 5862	Cover:Lever	71 - 9
B077 5865	Lever:Safety Switch:Front	71 - 13
B077 5866	Bracket:Safety Switch	71 - 14
B077 5871	Rack:Application:Ass'y	77 - 4
B077 5876	Stay:Rack	77 - 5
B077 5898	Bracket:Power Supply Cord	69 - 8
B077 6022	Housing:Manual Feed	29 - 13
B077 6039	Cover:Gear	29 - 11
B077 6044	Guide Plate:Feed	29 - 24
B077 6065	Rail:Holder	29 - 39
B077 6067	Manual Feed Table	27 - 10
B077 6068	Cover:Manual Feed Table	27 - 11
B077 6069	Side Fence:Front	27 - 21
B077 6070	Side Fence:Inner Back	27 - 19
B077 6071	Side Fence:Auxiliary:Front	27 - 22
B077 6072	Side Fence:Auxiliary:Rear	27 - 20
B077 6090	Bracket:Support Stay	27 - 6
B077 6106	Cover:Holder:Middle	27 - 1
B077 6107	Cover:Contact Point	27 - 5
B077 6108	Cover:Manual Feed:Inner Back	27 - 4
B077 6109	Cover:Manual Feed:Front	27 - 3
B077 6302	Cover:Left Front:NA	11 - 18
B077 6305	Cover:Left Front:EU	11 - 18
B077 6308	Cover:Css:Exp	13 - 37
B077 6312	Cover:Upper Right:Small:EU	13 - 33
B077 6314	Cover:Upper:EU	13 - 35
B077 6316	Cover:Front:EU:Ass'y	11 - 3
B077 6322	Inner Cover:Right:EU	35 - 9

Part No.	Description	Page and Index No.
B077 6324	Cover:Left:Eu	11 - 8
B077 6325	Cover:Left Rear:EU	11 - 19
B077 6328	Cover:Rear:EU	13 - 10
B077 6330	Cover:Rear:Paper Feed Sub-unit:EU	13 - 16
B077 6335	Cover:Upper Rear:Scanner:EU	9 - 6
B077 6336	Cover:Right:Scanner:EU	9 - 8
B077 6337	Cover:Left:Scanner:EU	9 - 3
B077 6338	Cover:Lower:Operation Sub-unit:EU	9 - 1
B077 6352	Sheet:Power Source:NA	17 - 31
B077 6353	Case:Operation Sub-unit:NA	17 - 32
B077 6354	Sheet:Caption:NA	17 - 28
B077 6355	Keytop:10key:NA	17 - 23
B077 6356	Keytop:Copy:1:NA	17 - 29
B077 6357	Keytop:Copy:2:NA	17 - 30
B077 6358	Keytop:Clear Modes	17 - 20
B077 6362	Sheet:Power Source:EU	17 - 31
B077 6363	Case:Operation Sub-unit:EU	17 - 32
B077 6366	Keytop:Copy:1:EU	17 - 29
B077 6367	Keytop:Copy:2:EU	17 - 30
B077 6372	Sheet:Caption:TWN	17 - 28
B077 6377	Sheet:Caption:CHN	17 - 28
B077 6387	Keytop:10key:AA	17 - 23
B077 7757	Bracket:Circuit Breaker	69 - 9
B351 6522	ADF Exposure Glass	19 - 7
B351 6523	Seal - ADF Exposure Glass	19 - 6
B387 6053	Original Scale Decal - A4	9 - 17
B387 6053	Original Scale Decal - A4	97 - 22
B387 6054	Original Scale Decal - LT	9 - 17
B387 6054	Original Scale Decal - LT	97 - 22
B406 1387	Front Platen Cover	15 - 3
B406 1392	Rear Platen Cover	15 - 7
B406 1397	Original Holder	15 - 5
B548 5863	HDD:ATA:ST320014A	77 - 17
C225 2866	Decal - Keytop Cover (REX)	9 - 14
C225 2866	Decal - Keytop Cover (REX)	97 - 1

Part No.	Description	Page and Index No.
C225 2867	Decal - Keytop Cover (NSA)	9 - 14
C225 2867	Decal - Keytop Cover (NSA)	97 - 1
G011 3305	Gear - 16T	27 - 13
G012 3897	Film - Toner End Sensor Harnes	41 - 29
G012 3897	Film - Toner End Sensor Harnes	53 - 1
G020 1189	Fly Wheel	63 - 16
G020 1332	Hinge - Front Cover	11 - 4
G020 1917	Decal - LD	97 - 23
G020 1917	Decal - LD	25 - 28
G020 1920	Decal - Laser Diode	97 - 24
G020 1966	Cylindrical Lens	25 - 14
G020 1968	F Theta Mirror	25 - 23
G020 1969	BTL Lens	25 - 20
G020 2620	Push Switch - Paper Size	65 - 22
G021 9350	Loopback Connector - Parallel	99 - 10
G029 1980	Decal - LD	97 - 25
G029 1980	Decal - LD	25 - 2
G034 5820	Spring Plate - Power Supply Unit	69 - 20
G060 2905	Paper Guide - Manual Feed Tabl	27 - 17
G065 1118	Drum Shaft	63 - 23
G065 1122	Timing Pulley - 58Z/79T	63 - 18
G065 1128	Flange - Fly Wheel	63 - 17
G065 1143	Bushing - M34	63 - 8
G065 1170	Lower Dust	69 - 4
G065 1171	Upper Dust	69 - 3
G065 1173	Sheet - Duct	13 - 8
G065 1174	Sheet - Duct - Upper	13 - 9
G065 2241	Shutter - Toner Supply	43 - 8
G065 2251	Cover:PCU:Upper:Ass'y	43 - 3
G065 2259	Handle - PCU	43 - 2
G065 2270	Receptacle - Charge Roller	43 - 9
G065 2279	Entrance Seal - Toner Supply	43 - 29
G065 2282	Shield:PCU:Rail	45 - 2
G065 2321	Front Arm - Charge Unit	45 - 11
G065 2326	Rear Arm - Charge Unity	45 - 18

Part No.	Description	Page and Index No.
G065 2328	Cap - Toner Supply	43 - 4
G065 2767	Lever - Feed	33 - 36
G065 2774	Pressure Lever	33 - 28
G065 2775	Link Lever	33 - 32
G065 2776	Release Lever	33 - 25
G065 3066	Entrance Shield - Toner Supply	41 - 16
G065 3067	Coupling Shield	41 - 21
G065 4105	Housing - Thermostat	51 - 2
G065 4106	Thermostat	51 - 1
G065 4117	Harness - Fusing Unit(120V)	49 - 16
G065 4127	Harness - Fusing Unit(230V)	49 - 16
G065 5841	Gasket:Bracket:I/O Control Board	71 - 21
G065 5858	Option Cover	77 - 14
G065 5893	Card Cover	77 - 11
G329 1232	Pressure Plate:Ass'y	15 - *
G329 1320	Platen Cover Sheet	15 - 1
G329 1330	Cushion - Platen Cover	15 - 2
G329 1383	Feeler - Platen Cover Sensor	15 - 6
G329 1384	Bracket - Platen Cover	15 - 9
G404 2810	Spring Plate - 2nd Mirror	21 - 3
G564 6511	Left Scale - EU	9 - 4
G564 6522	Left Scale - NA	9 - 4
G570 1245	Rear Scale	9 - 7

Part No.	Description	Page and Index No.
N803 6701	Flash Memory Card-4MB	99 - 3



Part No.	Description	Page and Index No.
AA00 0204	Decal - Right Lower Cover	97 - 5
AA00 0204	Decal - Right Lower Cover	11 - 35
AA00 0546	Decal:Laserclass1:CHN	97 - 6
AA00 0547	Decal:Laserclass1:KOR	97 - 7
AA00 1392	Decal - A1	97 - 8
AA00 1392	Decal - A1	11 - 26
AA00 1393	Decal - A2	37 - 14
AA00 1393	Decal - A2	97 - 9
AA00 3206	Decal:PCU:Spring:Caution Chart	97 - 10
AA00 3206	Decal:PCU:Spring:Caution Chart	45 - 9
AA01 2102	Development Filter	41 - 20
AA04 3416	Timing Belt - 40S3M192	11 - 11
AA04 3439	Timing Belt - S2M-224	23 - 18
AA04 3443	Timing Belt - S2M 140	61 - 10
AA04 3443	Timing Belt - S2M 140	59 - 20
AA04 3444	Timing Belt - S2M 350	61 - 1
AA04 3445	Timing Belt - S3M-360	67 - 1
AA04 3446	Timing Belt - S3M-312	67 - 12
AA04 3551	Timing Belt - B50S3M213UG (B079)	63 - 33
AA04 3553	Timing Belt-B60S2M316	63 - 19
AA04 3554	Timing Belt - B60S3M129	67 - 8
AA04 3555	Timing Belt - S2M234	55 - 23
AA04 3569	Timing Belt - B50S3M228 (B082)	63 - 33
AA04 3570	Timing Belt - B60S2M240	63 - 12
AA04 3571	Timing Belt - S3M - 180	63 - 3
AA05 0106	Carriage Drive Wire	23 - 11
AA06 0691	Tension Spring	33 - 14
AA06 0693	Tension Spring	33 - 27
AA06 0694	Tension Spring	67 - 32
AA06 0695	Tension Spring	67 - 16
AA06 0702	Tension Spring	19 - 23
AA06 0703	Tension Spring	23 - 12
AA06 0709	Tension Spring	57 - 15
AA06 0712	Torsion Spring	47 - 29
AA06 0713	Tension Spring	71 - 12

Part No.	Description	Page and Index No.
AA06 0716	Tension Spring	55 - 7
AA06 0839	Pressure Spring - Driven	57 - 22
AA06 0839	Pressure Spring - Driven	59 - 11
AA06 0840	Pressure Spring - 29n	51 - 24
AA06 0855	Return Spring	55 - 19
AA06 0879	Tension Spring	51 - 9
AA06 0908	Release Spring	33 - 33
AA06 0927	Spring:cleaning Blade:5.1n	47 - 15
AA06 2255	Spring:Cleaning Blade	45 - 24
AA06 2299	Pressure Spring	45 - 14
AA06 2300	Tension Spring	45 - 15
AA06 2304	Pressure Spring	37 - 6
AA06 2305	Tension Spring	37 - 22
AA06 2310	Pressure Spring	45 - 5
AA06 2312	Pressure Spring	53 - 15
AA06 2313	Gate Pawl Spring 1.5n	55 - 20
AA06 2316	Tension Spring - Shutter	43 - 7
AA06 2317	Tension Spring	63 - 7
AA06 3303	Pressure Spring	57 - 16
AA06 3304	Terminal Spring	37 - 36
AA06 3305	Torsion Spring	47 - 17
AA06 3371	Spring	63 - 28
AA06 3499	Pressure Spring	29 - 5
AA06 3564	Tension Spring	11 - 31
AA06 3566	Pressure Spring	39 - 10
AA06 3567	Tension Spring	29 - 29
AA06 3568	Pressure Spring	29 - 26
AA06 3569	Spring	29 - 36
AA06 3646	Pressure Spring - PCU Stopper	43 - 6
AA06 3648	Pressure Spring	45 - 12
AA06 3662	Compression Spring	11 - 23
AA06 3664	Spring:Fusing Cleaning Roller:5n	49 - 19
AA06 3854	Pressure Spring	53 - 11
AA06 3855	Spring - 3.5n	35 - 38
AA06 6152	Tension Spring	59 - 4

Part No.	Description	Page and Index No.
AA06 6335	Torsion Spring	61 - 17
AA06 6574	Torsion Spring	27 - 9
AA06 6575	Torsion Spring	35 - 23
AA06 6576	Torsion Spring	35 - 21
AA06 6577	Torsion Spring	37 - 8
AA08 0034	Bushing - 4x5x7	57 - 10
AA08 0229	Front Bushing - M6	37 - 5
AA08 0230	Rear Bushing - M6	37 - 38
AA08 0234	Bushing - 12x18x6	41 - 14
AA08 0246	Bushing - Bias Roller	47 - 31
AA08 0275	Bushing:Pressure:Mm4	11 - 22
AA08 0307	Bushing - M4	59 - 10
AA08 0307	Bushing - M4	57 - 23
AA08 2054	Bushing - M4	47 - 28
AA08 2058	Bushing - 6x10x9mm	55 - 8
AA08 2070	Bushing - 8x16x7	33 - 12
AA08 2070	Bushing - 8x16x7	27 - 8
AA08 2072	Bushing - M6	33 - 19
AA08 2073	Roller Busing	49 - 18
AA08 2074	Bushing - M8	59 - 1
AA08 2075	Bushing - M6	61 - 3
AA08 2079	Bushing - 6x8x5.8	35 - 27
AA08 2080	Bushing - M8	37 - 3
AA08 3018	Roller Clutch - 6x14x10	29 - 30
AA12 0115	Discharge Brush:Exit	55 - 4
AA14 0140	Screw - M3X4.5	49 - 22
AA14 0655	Shaft - Paper Feed	33 - 35
AA14 0666	Shaft - Hook	35 - 22
AA14 0753	Feed Shaft	29 - 21
AA14 3219	Stepped Screw	41 - 9
AA14 3301	Stepped Screw - M3x4	71 - 7
AA14 3432	Stepped Screw - M3	65 - 4
AA14 3461	Stepped Screw - M2.5	61 - 19
AA14 3499	Stepped Screw	77 - 20
AA14 3501	Stepped Screw - M8	13 - 34

Part No.	Description	Page and Index No.
AA14 3512	Stepped Screw - M2.5	71 - 11
AA14 3520	Shoulder Screw - M3	49 - 4
AA14 3520	Shoulder Screw - M3	9 - 2
AA14 3523	Shoulder Screw - M3	9 - 11
AA14 3533	Screw:10:M3x18	45 - 3
AA14 5810	Slide Shaft	39 - 4
AA14 9291	Pin - Link	37 - 10
AA14 9515	Gear Shaft	67 - 27
AA15 0401	Seal - 70x20	47 - 16
AA15 0671	Shield - Collection Coil	43 - 15
AA15 0684	Shield Plate	73 - 5
AA15 0685	Seal - 215x10	13 - 32
AA15 0711	Shield -base	23 - 8
AA15 0721	Shield:Side Plate:Left	21 - 13
AA15 0722	Shield:Side Plate:Front Rear:Left Middle	21 - 15
AA15 0723	Sheet:Left	21 - 16
AA15 0724	Sheet:Left Middle	21 - 17
AA15 0725	Sheet:Right	21 - 18
AA15 3053	Sponge - 317x5x5	41 - 19
AA15 3054	Sponge - 17x7x5	41 - 17
AA15 3070	Dehumidifier Sheet	13 - 4
AA15 3083	Seal - Toner Supply Unit Cover	39 - 8
AA15 3095	Shield - Development - Center	41 - 18
AA15 3390	Sponge - 202x3.5x4	13 - 30
AA15 3391	Frame Seal - Rear Right	35 - 4
AA15 3392	Sponge - 24x6x5	35 - 25
AA15 3393	Frame Seal - Rear Vertical	35 - 2
AA15 3442	Shield - Stay - PCU	37 - 27
AA15 3443	Mylar -development Unit-right	41 - 30
AA16 1125	Rubber Cushion	77 - 19
AA16 1133	Cushion - 4x15x1	21 - 19
AA16 1628	Link Cushion - 10x5x2	55 - 9
AA16 1629	Pad-guide Plate	53 - 16
AA16 2046	Cushion - 347x10x5	59 - 7
AB01 0156	Gear:Separate:Drive	33 - 30

Part No.	Description	Page and Index No.
AB01 0157	Gear:Separate:Driven	33 - 29
AB01 1088	Gear - 30Z	61 - 13
AB01 1188	Gear - 21Z	33 - 8
AB01 1189	Gear - 18Z	33 - 11
AB01 1190	Gear - 25Z	47 - 37
AB01 1377	Gear - 14Z	43 - 19
AB01 1378	Gear - 19Z	43 - 24
AB01 1379	Gear - 19Z	43 - 27
AB01 1380	Cam - Cleaning Blade	43 - 26
AB01 1386	Development Sleeve Gear	41 - 7
AB01 1387	Gear - 23Z	29 - 23
AB01 1388	Gear - Z16	29 - 8
AB01 1389	Gear - 20Z	29 - 7
AB01 1390	Gear - 27Z	29 - 34
AB01 1446	Gear - 29Z	41 - 8
AB01 3485	Gear - 20Z	37 - 2
AB01 3882	Gear - 40Z	51 - 13
AB01 4038	Gear - 22Z	67 - 14
AB01 4039	Gear - 31Z	67 - 21
AB01 4040	Gear - 29Z	67 - 36
AB01 4046	Gear - 25Z	51 - 26
AB01 4049	Gear - 24Z	55 - 25
AB01 4051	Gear - 16Z	37 - 4
AB01 4060	Gear - 21Z	41 - 13
AB01 4061	Gear - 13Z	41 - 11
AB01 4062	Gear - 17Z/25Z	41 - 15
AB01 4090	Gear - 18Z	33 - 1
AB01 4159	Gear - 49Z	67 - 38
AB01 4160	Idler Gear-registration	67 - 15
AB01 4161	Reverse Roller Gear	59 - 23
AB01 4162	Gear - 46Z	59 - 19
AB01 4164	Gear - 28T	67 - 28
AB01 4189	Gear - 27Z	47 - 14
AB01 4219	Gear - 24Z	67 - 5
AB01 4222	Gear - 33Z/30T	63 - 14

Part No.	Description	Page and Index No.
AB01 4223	Gear - 30Z	63 - 15
AB01 4237	Gear:Fusing Drive Sub-unit:No.1	63 - 29
AB01 4238	Gear:Fusing Drive Sub-unit:No.2	63 - 30
AB01 7454	Gear - 24Z/30Z	29 - 32
AB01 7458	Gear Pulley - 18Z/22T	55 - 24
AB03 0474	Pulley - 24T	61 - 2
AB03 0561	Timing Pulley - 31Z/20T	67 - 13
AB03 0562	Timing Pulley - 31Z/20T	67 - 20
AB03 0564	Pulley - M17	11 - 14
AB03 0566	Timing Pulley - 20T	67 - 29
AB03 0567	Timing Pulley - 18T	67 - 19
AB03 0568	Pulley - 23T	55 - 16
AB03 0572	Timing Pulley - Z61	23 - 17
AB03 0584	Timing Pulley - 15T	11 - 12
AB03 0625	Timing Pulley - 20Z	67 - 2
AB03 0634	Pulley	67 - 34
AB03 0669	Timing Pulley - Registration	67 - 7
AB03 0670	Gear - 24Z	59 - 18
AB03 0671	Gear Pulley - Rransport	61 - 11
AB03 0672	Idler Pulley	55 - 22
AB03 0714	Timing Pulley - 32Z/52T	63 - 21
AB03 0715	Timing Pulley - Transfer Unit	63 - 13
AB03 0716	Gear - 32Z/29T	63 - 2
AB03 0717	Gear - 30Z/18T	63 - 4
AB03 2061	Front Scanner Pulley	23 - 22
AB03 2062	Rear Scanner Pulley	23 - 16
AC01 2067	Exposure Glass	9 - 5
AC01 5024	Shield Glass - Polygon Motor	25 - 15
AC01 5025	Shield Glass	25 - 6
AC03 0110	Scanner Mirror	21 - 12
AC03 0115	Mirror	25 - 17
AD02 1127	Receptacle	37 - 35
AD02 5021	Pick-off Pawl	45 - 7
AD02 7012	Roller:Charge:Apply	45 - 30
AD04 1095	Cleaning Blade:Ass'y	45 - 25

Part No.	Description	Page and Index No.
AD04 7023	Cleaning Entrance Seal	43 - 13
AE01 1071	Hot Roller - 39.8mm T0.4	51 - 15
AE02 0123	Pressure Roller:Mm32:Ass'y	51 - 20
AE03 0047	Ball Bearing - 30x42x7	51 - 14
AE03 0048	Ball Bearing - 8x22x7	51 - 19
AE04 2054	Fusing Cleaning Roller:Ass'y	49 - 17
AE04 4030	Hot Rollerstripper	51 - 10
AF01 3006	Bottom Plate Pad	31 - 3
AF01 3016	Bottom Plate Pad	29 - 6
AF01 7026	End Fence	31 - 11
AF02 0404	Transport Roller	33 - 39
AF02 0410	Registration Roller	37 - 24
AF02 0509	Reverse Roller - Duplex	59 - 12
AF02 0510	Exit Transport Roller	61 - 4
AF02 0511	Reverse Roller - Driven	57 - 3
AF02 0511	Reverse Roller - Driven	59 - 9
AF02 0512	Driven Roller - Duplex	57 - 17
AF02 0513	Transport Roller	61 - 6
AF02 0514	Exit Roller	55 - 3
AF02 0515	Transport Roller	55 - 15
AF02 0515	Driven Registration Roller	37 - 23
AF02 5036	Duplex Junction Gate	57 - 14
AF03 0049	Pick-up Roller	29 - 22
AF03 0049	Pick-up Roller	33 - 7
AF03 1046	Feed Roller - Manual Feed	29 - 12
AF03 1049	Feed Roller	33 - 10
AF03 2046	Separation Roller - Manual Feed	29 - 2
AF03 2049	Separation Roller	33 - 21
AF04 0031	Driven Roller	29 - 18
AF04 0559	Driven Roller - M9	27 - 23
AF04 0571	Guide Roller	53 - 6
AF04 0571	Guide Roller	35 - 12
AF04 0574	Guide Roller	55 - 11
AF04 0575	Driven Roller	29 - 42
AF04 0575	Driven Roller	53 - 19

Part No.	Description	Page and Index No.
AF04 0599	Pressure Roller:15	53 - 8
AF04 0601	Pressure Roller:Entrance	53 - 14
AG05 0085	Registration Roller Knob	37 - 1
AG05 0094	Knob:Fusing	51 - 18
AG07 0019	Magnet Catch:Ass'y	11 - 27
AG07 1010	Magnet Catch	13 - 24
AH01 0009	Rubber Pad - H5	75 - 9
AH01 0009	Rubber Pad - H5	23 - 21
AW01 0048	Photosensor - GP2A28N1	61 - 15
AW01 0048	Photosensor - GP2A28N1	59 - 3
AW01 0048	Photosensor - GP2A28N1	37 - 19
AW01 0049	Photo Reflection Sensor	53 - 22
AW01 0056	Original Sensor - H=2-66	19 - 4
AW01 0059	Original Sensor - H=1-66	19 - 25
AW01 0061	Paper Feed Sensor:Fusing Exit	35 - 19
AW01 0084	Photo Refiection Sensor:Paper Feed (1st Tray)	33 - 6
AW02 0096	Photointerruptor	33 - 6
AW02 0097	Photointerrupter	63 - 10
AW02 0100	Photointerrupter - P1CH2MM	19 - 12
AW02 0120	Photointerruptor - Flat	21 - 22
AW02 0120	Photointerruptor - Flat	75 - 7
AW02 0120	Photointerruptor - Flat	29 - 19
AW02 0120	Photointerruptor - Flat	33 - 37
AW02 0126	Photointerruptor	61 - 9
AW10 0052	Thermistor - Center	51 - 4
AW10 0053	Thermistor - Rear	51 - 5
AW31 0006	Toner Overflow Sensor	47 - 38
AX04 0078	DC Motor - 3W	65 - 16
AX05 0195	DC Motor:Toner Bottle:Ass'y	63 - 38
AX06 0239	Brushless Motor:Main:Ass'y	63 - 37
AX06 0240	Brushless Motor:DCZ30W:Ass'y	65 - 6
AX06 0241	Brushless Motor:DC13W:Ass'y	71 - 3
AX06 0245	Polygon Scanner:27300rpm:M	25 - 10
AX20 0138	Electrical Clutch - Mice-13	37 - 37
AX20 0138	Electrical Clutch - Mice-13	67 - 26

Part No.	Description	Page and Index No.
AX20 0140	Electrical Clutch	29 - 31
AX20 0231	Magnetic Clutch - 0.5N M-28Z	67 - 4
AX21 0081	Transfer Unit Clutch	63 - 9
AX31 0039	Total Counter	13 - 28
AX40 0137	Heater - 120V 9W	75 - 2
AX40 0138	Heater - 230V 9W	75 - 2
AX40 0140	Heater - 120V 15W	23 - 2
AX40 0142	Heater - 240V 15W	23 - 2
AX43 0090	Heater:120V:550W:215mm	51 - 16
AX43 0091	Heater:230V:550W:215mm	51 - 16
AX44 0173	Heater:120V:650W:335mm	51 - 17
AX44 0174	Heater:230V:650W:335mm	51 - 17
AX50 0046	Quenching Lamp	73 - 12
AX50 0083	Xenon Lamp:Mm8.5	21 - 6
AX64 0113	Fan Motor - 80mm - DC 2.4W	69 - 1
AX64 0128	Fan Motor - DC 24V 1.44W	19 - 2
AX64 0142	Fan:Sirocco:DC24V:3350Rpm	71 - 5
AX64 0143	Fan:Sirocco:DC24V:3350rpm	35 - 30
AZ23 0109	Power Supply Unit:283W:DOM/NA	69 - 13
AZ23 0110	Power Supply Unit:283W:EU/AA	69 - 13
AZ23 0111	Power Supply Unit:283W:CHN	69 - 13
AZ32 0112	Power Pack:CBT	69 - 5
AZ50 0062	Stabilizer:Xenon Lamp	19 - 10
GA00 3035	Energy Decal	11 - 5
GA00 3035	Energy Decal	97 - 26
GA08 0002	Bushing - 6mm	29 - 35
GA08 0002	Bushing - 6mm	67 - 3
GC03 0020	Sync. Detector Mirror	25 - 25

Part No.	Description	Page and Index No.
0313 0060B	Philips Pan Head Screw - M3x6	37 -106
0313 0060B	Philips Pan Head Screw - M3x6	61 -109
0314 0060B	Philips Pan Head Screw - M4x6	23 -104
0314 0120B	Philips Pan Head Screw - M4x12	19 -104
0314 0180B	Philips Pan Head Screw - M4x18	19 -107
0353 0040B	Screw - M3X4	55 -103
0353 0040B	Screw - M3X4	53 -103
0353 0040B	Screw - M3X4	29 -105
0353 0060B	Philips Pan Head Screw - M3x6	37 -110
0353 0060B	Philips Pan Head Screw - M3x6	31 -102
0353 0060B	Philips Pan Head Screw - M3x6	19 -101
0353 0080Z	Philips Trass Head Screw - M3x8	77 -102
0353 0120B	Bind Screw - M3x12	59 -107
0354 0080B	Screw - M4X8	13 -103
0450 3006B	Tapping Screw - M3x6	13 -102
0450 3006B	Tapping Screw - M3x6	45 -103
0450 3006B	Tapping Screw - M3x6	53 -102
0450 3006B	Tapping Screw - M3x6	55 -102
0450 3008B	Tapping Screw - M3x8	47 -101
0450 3008B	Tapping Screw - M3x8	41 -103
0450 3008B	Tapping Screw - M3x8	33 -102
0450 3008B	Tapping Screw - M3x8	43 -101
0450 3008B	Tapping Screw - M3x8	45 -101
0450 3008B	Tapping Screw - M3x8	37 -101
0450 3008B	Tapping Screw - M3x8	23 -103
0450 3008B	Tapping Screw - M3x8	25 -102
0450 3008B	Tapping Screw - M3x8	39 -102
0450 3008B	Tapping Screw - M3x8	29 -106
0450 3008B	Tapping Screw - M3x8	63 -108
0450 3008B	Tapping Screw - M3x8	11 -102
0450 3008B	Tapping Screw - M3x8	35 -102
0450 3008B	Tapping Screw - M3x8	31 -104
0450 3008H	Tapping Screw - M3x8	13 -107
0450 3008H	Tapping Screw M3x8	57 -103
0450 3010B	Tapping Screw - M3x10	41 -102

Part No.	Description	Page and Index No.
0450 3010B	Tapping Screw - M3x10	25 -101
0450 3010B	Tapping Screw - M3x10	27 -106
0450 3012B	Tapping Screw - 3x12	11 -103
0450 3014B	Tapping Screw - M3x14	41 -101
0450 4012B	Tapping Screw - M4x12	15 -101
0450 4035B	Philips Tapping Screw - M4x35	69 -101
0451 3005W	Tapping Screw - 3x5	73 -104
0451 3006B	Tapping Screw - M3x6	37 -103
0451 3006B	Tapping Screw - M3x6	73 -101
0451 3006B	Tapping Screw - M3x6	33 -103
0451 3006B	Tapping Screw - M3x6	35 -103
0451 3006B	Tapping Screw - M3x6	51 -103
0451 3006B	Tapping Screw - M3x6	45 -105
0451 3006B	Tapping Screw - M3x6	47 -103
0451 3006B	Tapping Screw - M3x6	49 -102
0451 3006B	Tapping Screw - M3x6	53 -101
0451 3006B	Tapping Screw - M3x6	71 -101
0451 3006B	Tapping Screw - M3x6	55 -101
0451 3006B	Tapping Screw - M3x6	57 -102
0451 3006B	Tapping Screw - M3x6	59 -104
0451 3006B	Tapping Screw - M3x6	69 -102
0451 3006B	Tapping Screw - M3x6	61 -102
0451 3006B	Tapping Screw - M3x6	63 -104
0451 3006B	Tapping Screw - M3x6	65 -101
0451 3006B	Tapping Screw - M3x6	67 -102
0451 3006B	Tapping Screw - M3x6	13 -105
0451 3006B	Tapping Screw - M3x6	23 -101
0451 3006B	Tapping Screw - M3x6	77 -101
0451 3006B	Tapping Screw - M3x6	21 -101
0451 3006B	Tapping Screw - M3x6	19 -103
0451 3006B	Tapping Screw - M3x6	75 -101
0451 3006B	Tapping Screw - M3x6	11 -104
0451 3008B	Tapping Screw - M3x8	49 -103
0451 3008B	Tapping Screw - M3x8	33 -101
0451 3008B	Tapping Screw - M3x8	73 -103

Part No.	Description	Page and Index No.
0451 3008B	Tapping Screw - M3x8	27 -104
0451 3008B	Tapping Screw - M3x8	29 -101
0451 3008B	Tapping Screw - M3x8	45 -102
0451 3008B	Tapping Screw - M3x8	65 -103
0451 3008B	Tapping Screw - M3x8	63 -103
0451 3008H	Tapping Screw - M3x8	67 -103
0451 3008H	Tapping Screw - M3x8	13 -101
0451 3008H	Tapping Screw - M3x8	69 -107
0451 3008H	Tapping Screw - M3x8	57 -101
0451 3008H	Tapping Screw - M3x8	11 -101
0451 3008H	Tapping Screw - M3x8	19 -106
0451 3008H	Tapping Screw - M3x8	27 -101
0451 3008H	Tapping Screw - M3x8	9 -101
0451 3010H	Tapping Screw - 3x10	9 -103
0451 3012H	Tapping Screw - 3x12	9 -102
0451 3014B	Tapping Screw - M3-14	67 -106
0451 3014B	Tapping Screw - M3-14	63 -105
0451 4008B	Philips Tapping Screw - M4x8	31 -101
0451 4010B	Tapping Screw - 4x10	13 -104
0451 4010B	Tapping Screw - 4x10	27 -105
0451 4016B	Tapping Screw - M4-16	75 -102
0452 3008B	Tapping Screw - M3x8	31 -103
0452 3010B	Tapping Bind Screw - M3x10	39 -101
0453 3006B	Tapping Screw - M3x6	51 -102
0453 3025B	Binding Selsf-Tapping Screw:M3x25	35 -104
0453 4030B	Binding Self Tapping Screw:4x30	71 -107
0534 0050E	Headless Screw - M4x5	63 -106
0575 0050E	Hexagon Headless Set Screw - M5x5	23 -108
0633 0140G	Parallel Pin - 3x14	63 -107
0720 0020E	Retaining Ring - M2	37 -105
0720 0030E	Retaining Ring - M3	41 -104
0720 0030E	Retaining Ring - M3	59 -105
0720 0030E	Retaining Ring - M3	51 -106
0720 0030E	Retaining Ring - M3	53 -105
0720 0040E	Retaining Ring - M4	51 -105

Part No.	Description	Page and Index No.
0720 0040E	Retaining Ring - M4	41 -106
0720 0040E	Retaining Ring - M4	29 -103
0720 0040E	Retaining Ring - M4	33 -105
0720 0040E	Retaining Ring - M4	61 -106
0720 0040E	Retaining Ring - M4	55 -104
0720 0040E	Retaining Ring - M4	43 -102
0720 0040E	Retaining Ring - M4	45 -104
0720 0040E	Retaining Ring - M4	37 -104
0720 0060E	Retaining Ring - M6	37 -107
0720 0060E	Retaining Ring - M6	35 -105
0720 0060E	Retaining Ring - M6	59 -101
0720 0060E	Retaining Ring - M6	27 -103
0720 0060E	Retaining Ring - M6	31 -105
0720 0060E	Retaining Ring - M6	11 -105
0720 0060E	Retaining Ring - M6	67 -108
0720 0060E	Retaining Ring - M6	33 -104
0720 0060E	Retaining Ring - M6	23 -109
0725 0110E	C Ring - M11	41 -105
0801 0149	Philips Pan Head Screw - M4x6	69 -103
0801 0149	Philips Pan Head Screw - M4x6	67 -104
0801 0149	Philips Pan Head Screw - M4x6	71 -103
0801 0149	Philips Pan Head Screw - M4x6	51 -101
0801 0149	Philips Pan Head Screw - M4x6	49 -104
0801 0149	Philips Pan Head Screw - M4x6	23 -105
0802 5276	Tapping Screw With Washer - M3x6	19 -102
0802 5276	Tapping Screw With Washer - M3x6	59 -102
0802 5276	Tapping Screw With Washer - M3x6	63 -101
0802 5276	Tapping Screw With Washer - M3x6	71 -102
0802 5276	Tapping Screw With Washer - M3x6	35 -101
0802 5276	Tapping Screw With Washer - M3x6	37 -102
0802 5276	Tapping Screw With Washer - M3x6	73 -102
0802 5276	Tapping Screw With Washer - M3x6	23 -102
0802 5276	Tapping Screw With Washer - M3x6	65 -102
0802 5276	Tapping Screw With Washer - M3x6	61 -105
0802 5279	Tapping Screw With Washer - M3x8	63 -102

Part No.	Description	Page and Index No.
0802 5279	Tapping Screw With Washer - M3x8	67 -101
0804 6075	Hexagonal Bolt - M3x8	9 -104
0804 6075	Hexagonal Bolt - M3x8	51 -104
0804 6075	Hexagonal Bolt - M3x8	49 -101
0805 0089	Retaining Ring - M4	33 -106
0805 0097	Ring Separator	41 -107
0805 3480	Bushing - 6mm	61 -101
0805 3480	Bushing - 6mm	29 -102
0805 3480	Bushing - 6mm	33 -107
0951 3006B	Philips Screw With Flat Washer-M3x6	21 -102
0951 3006B	Philips Screw With Flat Washer-M3x6	47 -102
0951 3008B	Philips Screw With Flat Washer-M3x8	25 -103
0954 3012B	Screw - M3X12	51 -107
0957 3012B	Double Sems Screw - M3 x 12	49 -105
1005 0728	Rivet - NRP335	21 -103
1005 0967	Heatsink	85 -101
1102 2391	Connector - HIF3FB-40PA-2.54DSA	93 -101
1102 3822	Connector - 20P	81 -101
1102 4204	CT Header - 5P	85 -102
1102 5305	Connector - 6P	85 -103
1102 5306	Connector - 7P	81 -102
1102 6245	Relay Connector - 2P	71 -115
1102 6246	Relay Connector - 4P	37 -108
1102 6246	Relay Connector - 4P	71 -112
1102 6256	Relay Connector - 13P	71 -118
1102 6260	Relay Connector - 3P	71 -114
1102 6263	Connector - 6P	71 -113
1102 6266	Relay Connector - 9P	71 -117
1102 6295	Connector - 2P	81 -103
1102 6297	Connector - 4P	85 -104
1102 6297	Connector - 4P	81 -104
1102 6301	Connector - 8P	81 -105
1102 6302	Connector - 9P	81 -106
1102 6303	Connector - 10P	85 -105
1102 6303	Connector - 10P	81 -107

Part No.	Description	Page and Index No.
1102 6305	Connector - 12P	81 -108
1102 6308	Connector - 15P	81 -109
1102 6309	Connector - 2P	81 -110
1102 6311	Connector - 4P	81 -111
1102 6316	Connector - 9P	81 -112
1102 6321	Connector	81 -113
1102 6394	Connector - 12P	81 -114
1102 6396	Connector - 1P	81 -115
1102 6397	Box Header	81 -116
1102 6398	Connector - 2P	81 -117
1102 6401	Connector - 26P	81 -118
1102 6402	Connector - 2P	81 -119
1102 6595	Connector - 11P	85 -106
1102 6789	Connector - 100P	93 -102
1102 6815	Connector - 53258-0410	93 -103
1102 6943	Relay Connector -10p	71 -116
1102 7244	Connector	81 -120
1102 7389	Connector - FH12-50S-0.5SV	85 -107
1102 7389	Connector - FH12-50S-0.5SV	81 -121
1102 7615	Connector - B8B-XH-A	93 -104
1102 7729	Connector - DX10G1M-50SE	85 -108
1102 8112	Connector - FCN-568P068-G/05A-V4	93 -105
1102 8189	DIPMM Connector - 54534-1440	93 -106
1102 8243	Connector - FH12-33S-0.5SV	85 -109
1102 8272	Connector - TX25-100P-12ST-H1	85 -110
1102 8357	Connector - 52777-0809	85 -111
1102 8502	Connector - 54679-1615	69 -108
1102 8504	Connector	67 -105
1102 8567	Connector - 52775-0800	93 -107
1102 8829	Connector - DM-1D4-N3210	93 -108
1102 8988	Connector	93 -109
1102 9180	Connector:leee	93 -110
1104 0588	DIP Socket - 28p	93 -111
1105 0162	Locking Support	19 -105
1105 0165	Flat Cable Clamp	35 -106

Part No.	Description	Page and Index No.
1105 0192	Locking Support	69 -104
1105 0192	Locking Support	65 -105
1105 0267	Harness Clamp - YMC-10-0	73 -108
1105 0267	Harness Clamp - YMC-10-0	29 -104
1105 0283	Clamp	33 -108
1105 0283	Clamp	61 -107
1105 0283	Clamp	37 -109
1105 0291	Harness Clamp - LWS-3S	61 -103
1105 0292	Wire Saddle	23 -107
1105 0310	Harness Clamp - LWS-1S	69 -105
1105 0328	Harness Clamp - ES-0505	59 -108
1105 0328	Harness Clamp - ES-0505	61 -104
1105 0349	Edge Saddle	27 -102
1105 0349	Edge Saddle	65 -108
1105 0460	Clamp	59 -103
1105 0487	Harness Clamp	13 -106
1105 0487	Harness Clamp	65 -106
1105 0487	Harness Clamp	71 -104
1105 0487	Harness Clamp	73 -107
1105 0487	Harness Clamp	23 -106
1105 0488	Harness Clamp	75 -103
1105 0488	Harness Clamp	69 -106
1105 0488	Harness Clamp	65 -107
1105 0489	Harness Clamp - LWS 1316	75 -105
1105 0508	Harness Clamp - LWS-0711	73 -110
1105 0508	Harness Clamp - LWS-0711	21 -105
1105 0511	Harness Clamp - LWS-0306ZC	53 -104
1105 0511	Harness Clamp - LWS-0306ZC	71 -106
1105 0511	Harness Clamp - LWS-0306ZC	67 -109
1105 0511	Harness Clamp - LWS-0306ZC	65 -104
1105 0511	Harness Clamp - LWS-0306ZC	73 -109
1105 0511	Harness Clamp - LWS-0306ZC	75 -104
1105 0511	Harness Clamp - LWS-0306ZC	63 -109
1105 0516	Clamp	71 -105
1105 0516	Clamp	73 -105

Part No.	Description	Page and Index No.
1105 0516	Clamp	21 -104
1105 0516	Clamp	75 -106
1105 0522	Edge Saddle - Les0510	73 -106
1107 0388	Fuse (Glass Case) - 2A - 125V	69 -113
1107 0392	Fuse - 6.3A 125V	69 -110
1107 0472	Circuit Breaker - W28XQ1A 8A 25V	69 -109
1107 0629	Fuse (Ceramic Case) - 15A - 125V	69 -112
1107 0652	Fuse (glass Case) - 10A - 125V	69 -111
1107 0745	Fuse - 1A 250V	69 -113
1107 0753	Fuse (glass Case) - 6.3A - 250V	69 -110
1107 0899	Fuse:5A:250V	69 -111
1204 1385	Push Switch	93 -112
1204 1537	DIP Switch	81 -122
1204 1542	DIP Switch	93 -113
1204 2466	Micro Switch - V-16506-1c25	61 -108
1204 2466	Micro Switch - V-16506-1c25	59 -106
1204 2521	Micro Switch	71 -108
1204 2529	Switch - V-5F912DN	67 -107
1204 2529	Switch - V-5F912DN	71 -109
1204 2608	Rocker Switch:SDDJE33900	71 -110
1400 0767	Transistor:DTA114EUA	81 -123
1400 0775	Transistor - 2SC4081	85 -112
1400 0775	Transistor - 2SC4081	81 -124
1400 0801	Transistor - DTC113ZUA	93 -114
1400 0810	Transistor:DTC114EUA	85 -113
1400 0810	Transistor:DTC114EUA	81 -125
1400 0902	Transistor - DTA113ZUA	81 -126
1401 1205	Fet:HAT1044M	93 -115
1401 1206	Fet:HAT2054M	93 -116
1402 1265	Diode - RB411D	93 -117
1402 1322	Diode Array - DAN202U	81 -127
1402 1336	Diode - 1SS355	85 -114
1402 1336	Diode - 1SS355	81 -128
1402 1343	Diode - RB106L-40	93 -118
1402 1584	Diode - DAN217U	81 -129

Part No.	Description	Page and Index No.
1402 1647	Diode - UDZS3.6B	85 -115
1402 1662	Diode:PTZ6.2B	85 -116
1402 1662	Diode:PTZ6.2b	81 -130
1402 1663	Diode - ZTP12B	81 -131
1402 1664	Diode - HSU83	93 -119
1403 0907	Diode - SML-310LT	85 -117
1403 0907	Diode - SML-310LT	93 -120
1403 0953	LED - SML-310MT	85 -118
1403 0978	LED - SML-310DT	85 -119
1404 0360	Thermistor - 103HT	81 -132
1407 1535	IC - TD62308AP	81 -133
1407 1596	TTLIC - SN74LS14NS	85 -120
1407 1596	TTLIC - SN74LS14NS	81 -134
1407 1880	TTLIC - SN74LS04NS	81 -135
1407 2187	TTLIC - SN74LS07NS	85 -121
1407 2187	TTLIC - SN74LS07NS	81 -136
1407 2218	TTLIC - SN74LS06NS	85 -122
1407 2219	IC - TD62003AP	81 -137
1407 4771	IC - MC68334GFC16	85 -123
1407 5047	CMOS Logic:TC7SH32FU	93 -121
1407 5078	Flash Memory - MBM29F800BA-70PFTN	85 -124
1407 5090	IC - DS90CF364MTD	85 -125
1407 5275	CMOS Logic - 74LVCHR16245A TSSOP	93 -122
1407 5300	CMOS Logic - 74LVC16244A TSSOP	93 -123
1407 5321	CMOS Logic - 74LVCH16374A TSSOP	93 -124
1407 5322	IC - CMOS LOGIC SN74LVC161284DGG	93 -125
1407 5334	IC - CMOS LOGIC 74LVC244A TSSOP	93 -126
1407 5344	IC - SN74LV02APW	81 -138
1407 5346	IC - SN74LS74ANS	85 -126
1407 5351	IC - SN74LV14APW	85 -127
1407 5353	IC - SN74LV244APW	85 -128
1407 5364	IC - SN74AHCT244PW	93 -127
1407 5366	IC - 74LVC08A TSSOP	93 -128
1407 5376	IC - SN74LV32APW	85 -129
1407 5435	IC - SN74AHC1G04HDCK	85 -130

Part No.	Description	Page and Index No.
1407 5469	IC - SN74LV07APW	85 -131
1407 5523	ROM - I2C SOP 3V	93 -129
1407 5528	IC - SN74LVC126APW	93 -130
1407 5529	IC - SN74LVC374ANS	93 -131
1407 5567	IC:SN74IVCC3245APW	85 -132
1407 5594	IC:CD4066BPW	81 -139
1407 5602	IC - SN74AHCT174PW	93 -132
1407 5604	IC - SN74LVC16245ADGG	93 -133
1407 5666	CMOS IC - NC7WZ17P6	93 -134
1407 5713	IC:SN74IV06APW	85 -133
1407 5717	IC - ICS960001AF	93 -135
1407 5793	Clock Generator:HD151TS304RP	85 -134
1407 5809	CPC:RM7065A-300T-REV1.4	93 -136
1408 0877	Comparator - LM339NS	81 -140
1408 1095	IC - BA10324AF	81 -141
1408 1204	IC - TA8083P	81 -142
1408 1273	IC - RN5VD28A	93 -137
1408 1398	Detector - RN5VD42A	93 -138
1408 1486	IC:PST9330U	85 -135
1408 1555	Regulator - L1087MP-3.3	85 -136
1408 1565	IC - RN5VD21A	93 -139
1408 1649	IC - RN5VD14A	93 -140
1408 1730	IC - MM1096BF	85 -137
1408 1794	Series Regulator:LM1085IT-ADJ	85 -138
1408 1827	DC/DC Converter:SP6121CN	93 -141
1503 0460	Oscillator - 32.768KHZ	85 -139
1503 0842	Oscillator - 14.31818MHZ	93 -142
1503 0946	Crystal Oscillator - 9.8304Mhz	81 -143
1503 1004	Oscillator - 19.6608Mhz	85 -140
1503 1106	Crystal Oscillator:40.97Mhz	85 -141
1600 1340	Resistor:330Ω:±5%:1W	81 -144
1601 7752	Resistor Array - 10K Ω ±5%	93 -143
1601 7752	Resistor Array - 10K Ω ±5%	81 -145
1601 7760	Resistor Array	81 -146
1601 7791	Resistor Array - 1K Ω ±5%	81 -147

Part No.	Description	Page and Index No.
1601 7867	Resistor - 33 Ω \pm 5% 1/16W	93 -144
1601 7871	Resistor - 68 Ω \pm 5% 1/16W	93 -145
1601 7877	Resistor Array 4.7k Ω \pm 5% 1/32W	85 -142
1601 7879	Resistor - 22 Ω \pm 5% 1/16W	93 -146
1601 7886	Resistor Array 3.3k Ω \pm 5% 1/32W	85 -143
1601 7887	Resistor Array - 10K Ω \pm 5% 1/32W	85 -144
1601 7896	Resistor Array - 56 Ω \pm 5% 1/32W	85 -145
1601 7899	Resistor Array - 56 Ω \pm 5% 1/16W	93 -147
1601 7915	Resistor Array - 33 Ω \pm 5% 1/16W	93 -148
1601 7916	Resistor - 47 Ω \pm 5% 1/16W	93 -149
1601 7919	Resistor - 10K Ω \pm 5% 1/16W	93 -150
1601 7926	Resistor - 68 Ω \pm 5% 1/16W	93 -151
1601 7959	Resistor	85 -146
1601 7960	Resistor Array - 100 Ω \pm 5% 1/16W	85 -147
1601 7961	Resistor Array:120 Ω : \pm 5%:1/16W	85 -148
1601 7981	Resistor Array - 100K Ω : \pm 5%:1/16W	85 -149
1601 7983	Resistor Array:2.2k Ω : \pm 5%:1/16W	85 -150
1601 7996	Resistor Array:1.2k Ω : \pm 5%:1/16W	85 -151
1604 4729	Capacitor - 47 μ F \pm 20% 16V	93 -152
1604 4848	Capacitor - 100 μ F \pm 20% 10V	93 -153
1604 4918	Capacitor - 150 μ F \pm 20% 6.3V	93 -154
1604 4942	Capacitor - 33 μ F \pm 20%	85 -152
1604 4970	Capacitor - 33 μ F \pm 20% 50V	93 -155
1604 4992	Capacitor - 100 μ F \pm 20% 10V	93 -156
1604 4994	Capacitor - 100 μ F \pm 20% 6.3V	93 -157
1604 5147	Capacitor:330 μ F: \pm 20%:6.3V	85 -153
1604 5153	Capacitor:220 μ F: \pm 20%:6.3V	93 -158
1605 0832	Capacitor - 8PF \pm 0.5pF 50V	93 -159
1605 0976	Capacitor - 1 μ F +80% -20% 10V	93 -160
1605 1124	Capacitor - 4.7 μ F +80 -20% 10V	93 -161
1605 1124	Capacitor - 4.7 μ F +80 -20% 10V	81 -148
1605 1132	Capacitor - 2.2 μ F +80-20% 16V	93 -162
1605 1160	Capacitor:0.22 μ F:+80-20%:16V	85 -154
1605 1162	Capacitor - 10 μ F +80 -20% 10V	93 -163
1605 1167	Capacitor - 0.22 μ F \pm 10% 10V	85 -155

Part No.	Description	Page and Index No.
1605 1187	Ceramic Capacitor 0.047 μ F \pm 10% 50V	85 -156
1605 1354	Capacitor:1200pf: \pm 5%:50V	93 -164
1605 1371	Capacitor:4.7 μ F:+80-20%:6.3V	85 -157
1607 0747	FPC Core - FPC-25-12	71 -111
1607 1206	Filter - Acc2012I-250	93 -165
1607 1225	Filter - Acc4516I-700	93 -166
1607 1228	Inductor - SLF7045-4R7M2R0	93 -167
1607 1422	Inductor:SLF12555-6r0n3r6	93 -168
1610 1353	Resistor:10k Ω : \pm 0.5%:1/16W	93 -169
1610 1355	Resistor:33k Ω : \pm 0.5%:1/16W	93 -170
1610 1405	Resistor:20k Ω : \pm 0.5%:1/16W	93 -171
1610 1514	Resistor:3.3k Ω : \pm 0.5%:1/16W	93 -172
1633 0000	Resistor - 0 Ω 1/10W	93 -173
1634 0000	Resistor - 0 Ω 1/16W	93 -174
1634 0000	Resistor - 0 Ω 1/16W	85 -158
1640 2470	Capacitor - 47 μ F \pm 20% 25V	81 -149
1640 2471	Capacitor - 470 μ F \pm 20% 25V	81 -150
1640 5101	Capacitor - 100 μ F \pm 20% 50V	81 -151
1644 1470	Capacitor - 47 μ F \pm 20% 16V	85 -159
1650 2221	Resistor:220 Ω : \pm 5%:1/4W	81 -152
1650 4100	Resistor - 10 Ω \pm 5% 1/10W	81 -153
1650 4100	Resistor - 10 Ω \pm 5% 1/10W	93 -175
1650 4100	Resistor - 10 Ω \pm 5% 1/10W	85 -160
1650 4101	Resistor - 100 Ω \pm 5%1/10W	93 -176
1650 4101	Resistor - 100 Ω \pm 5%1/10W	81 -154
1650 4101	Resistor - 100 Ω \pm 5%1/10W	85 -161
1650 4102	Resistor - 1K Ω \pm 5% 1/10W	85 -162
1650 4102	Resistor - 1K Ω \pm 5% 1/10W	81 -155
1650 4102	Resistor - 1K Ω \pm 5% 1/10W	93 -177
1650 4103	Resistor - 10K Ω \pm 5% 1/10W	81 -156
1650 4103	Resistor - 10K Ω \pm 5% 1/10W	93 -178
1650 4103	Resistor - 10K Ω \pm 5% 1/10W	85 -163
1650 4104	Resistor - 100K Ω \pm 5%1/10W	81 -157
1650 4104	Resistor - 100K Ω \pm 5%1/10W	85 -164
1650 4105	Resistor - 1M Ω \pm 5% 1/10W	81 -158

Part No.	Description	Page and Index No.
1650 4105	Resistor - 1M Ω \pm 5% 1/10W	85 -165
1650 4106	Resistor - 10M Ω \pm 5%1/10W	85 -166
1650 4109	Resistor - 1 Ω \pm 5% 1/10W	93 -179
1650 4121	Resistor - 120 Ω \pm 5%1/10W	93 -180
1650 4122	Resistor - 1.2K Ω \pm 5% 1/10W	93 -181
1650 4150	Resistor - 15 Ω \pm 5% 1/10W	93 -182
1650 4152	Resistor - 1.5K Ω \pm 5% 1/10W	93 -183
1650 4161	Resistor - 160 Ω \pm 5% 1/10W	81 -159
1650 4202	Resistor - 2K Ω \pm 5%1/10W	85 -167
1650 4204	Resistor - 200K Ω \pm 5%1/10W	81 -160
1650 4220	Chip Resistor - 22 Ω \pm 5% 1/10W	93 -184
1650 4222	Resistor - 2.2K Ω \pm 5%1/10W	85 -168
1650 4222	Resistor - 2.2K Ω \pm 5%1/10W	81 -161
1650 4223	Resistor - 22K Ω \pm 5%1/10W	85 -169
1650 4223	Resistor - 22K Ω \pm 5%1/10W	81 -162
1650 4229	Resistor - 2.2 Ω \pm 5% 1/10W	93 -185
1650 4330	Chip Resistor - 33 Ω \pm 5% 1/10W	93 -186
1650 4330	Chip Resistor - 33 Ω \pm 5% 1/10W	85 -170
1650 4334	Resistor - 330K Ω \pm 5%1/10W	85 -171
1650 4391	Resistor - 390 Ω \pm 5% 1/10W	85 -172
1650 4470	Resistor - 47 Ω \pm 5%1/10W	85 -173
1650 4470	Resistor - 47 Ω \pm 5%1/10W	93 -187
1650 4472	Resistor - 4.7K Ω \pm 5% 1/10W	93 -188
1650 4472	Resistor - 4.7K Ω \pm 5% 1/10W	85 -174
1650 4472	Resistor - 4.7K Ω \pm 5% 1/10W	81 -163
1650 4519	Resistor:5.1 Ω : \pm 5%:1/10W	93 -189
1650 4560	Chip Resistor - 56 Ω \pm 5% 1/10W	85 -175
1650 4561	Resistor - 560 Ω \pm 5% 1/10W	93 -190
1650 4562	Resistor - 5.6K Ω \pm 5% 1/10W	93 -191
1650 4562	Resistor - 5.6K Ω \pm 5% 1/10W	81 -164
1650 4562	Resistor - 5.6K Ω \pm 5% 1/10W	85 -176
1650 4622	Resistor:6.2k Ω : \pm 5%:1/10W	93 -192
1650 4680	Resistor - 68 Ω \pm 5%1/10W	93 -193
1650 4680	Resistor - 68 Ω \pm 5%1/10W	85 -177
1650 4681	Resistor - 680 Ω \pm 5% 1/10W	81 -165

Part No.	Description	Page and Index No.
1650 4683	Resistor - 68K Ω \pm 5% 1/10W	93 -194
1650 4751	Resistor - 750 Ω \pm 5% 1/10W	85 -178
1650 4820	Resistor - 82 Ω \pm 5% 1/10W	93 -195
1652 1000	Chip Resistor:100 Ω : \pm 1%:1/4W	81 -166
1654 1000	Resistor - 100 Ω \pm 1% 1/10W	85 -179
1654 1002	Resistor - 10K Ω \pm 5%1/10W	81 -167
1654 1003	Resistor - 100K Ω \pm 1%1/10W	81 -168
1654 1403	Resistor:140k Ω : \pm 1%:1/10W	81 -169
1654 1432	Resistor:14.3k Ω : \pm 1%:1/10W	93 -196
1654 2002	Resistor - 20K Ω \pm 1%1/10W	81 -170
1654 2401	Resistor - 2.4K Ω \pm 1% 1/10W	81 -171
1654 2402	Chip Resistor:24k Ω : \pm 1%:1/10W	81 -172
1654 2432	Resistor:24.3k Ω : \pm 1%:1/10W	93 -197
1654 4641	Resistor:4.64k Ω : \pm 1%:1/10W	81 -173
1654 5609	Resistor:56 Ω : \pm 1%:1/10W	85 -180
1654 5621	Resistor:5.62k Ω : \pm 1%:1/10W	81 -174
1654 9531	Resistor:9.53k Ω : \pm 1%:1/10W	93 -198
1660 0100	Capacitor - 10PF \pm 0.5pF 50V	85 -181
1660 2101	Capacitor - 100pF - \pm 10% - 50V	93 -199
1660 2101	Capacitor - 100pF - \pm 10% - 50V	81 -175
1660 2101	Capacitor - 100pF - \pm 10% - 50V	85 -182
1660 2121	Capacitor - 120pF \pm 5% 50V	93 -200
1660 2150	Capacitor - 15pF \pm 5% 50V	93 -201
1660 2150	Capacitor - 15pF \pm 5% 50V	85 -183
1660 2220	Capacitor - 22pF \pm 20% 35V	85 -184
1660 2221	Capacitor - 220pF \pm 20% 50V	93 -202
1660 2270	Capacitor - 27pF \pm 20% 35V	93 -203
1660 2270	Capacitor - 27pF \pm 20% 35V	81 -176
1660 2330	Capacitor - 33pF - \pm 5% - 50V	85 -185
1660 2330	Capacitor - 33pF - \pm 5% - 50V	93 -204
1660 2390	Ceramic Capacitor - 39pF 50V	93 -205
1660 2470	Capacitor - 47pF \pm 5% 50V	93 -206
1660 2471	Capacitor - 470pF - \pm 5% - 50V	81 -177
1660 2471	Capacitor - 470pF - \pm 5% - 50V	93 -207
1660 2471	Capacitor - 470pF - \pm 5% - 50V	85 -186

Part No.	Description	Page and Index No.
1660 4102	Capacitor - 1000pF $\pm 10\%$ 50V	93 -208
1660 4102	Capacitor - 1000pF $\pm 10\%$ 50V	85 -187
1660 4222	Capacitor - 2200pF - $\pm 10\%$ - 50V	93 -209
1660 4332	Capacitor - 3300pF - $\pm 10\%$ - 50V	93 -210
1660 4472	Capacitor - 4700PF $\pm 10\%$ 50V	85 -188
1660 4472	Capacitor - 4700PF $\pm 10\%$ 50V	81 -178
1660 6103	Capacitor - 10000pF - $+80\%$ - 20% 50V	93 -211
1660 6103	Capacitor - 10000pF - $+80\%$ - 20% 50V	81 -179
1660 6103	Capacitor - 10000pF - $+80\%$ - 20% 50V	85 -189
1660 8104	Capacitor - 0.1 μ F $+80\%$ - 20% 25V	81 -180
1660 8104	Capacitor - 0.1 μ F $+80\%$ - 20% 25V	85 -190
1660 8104	Capacitor - 0.1 μ F $+80\%$ - 20% 25V	93 -212
1902 0042	RAM-1M X8 70ns TSOP G2	85 -191
1906 0046	Flash Memory:MOM29DL324BE80TN	93 -213
1906 0047	Flash Memory:MBM29DL640E80TN	93 -214
1907 0012	SDRAM - 128m 2MX16x4 133Mhz	93 -215

Part No.	Description	Page and Index No.
5203 1852	Bushing - 6x8x4mm	45 - 26
5203 9502	Grease 501	99 - 9
5206 2686	Snap Ring	33 - 26
5206 2686	Snap Ring	41 - 2
5206 2686	Snap Ring	37 - 12
5206 2686	Snap Ring	11 - 33
5215 1667	Platen Cover Stud	15 - 10
5216 4198	Stepped Screw - Guide Plate	29 - 14
5447 2681	Snap Ring	33 - 9
5447 2681	Snap Ring	29 - 1
5447 2681	Snap Ring	45 - 10
5447 2681	Snap Ring	55 - 13
5447 2681	Snap Ring	57 - 5
5447 2681	Snap Ring	35 - 1