


Gestetner® **LANIER**  **RICOH**® **SAVIN**®




B064/B065
PARTS CATALOG

RICOH GROUP COMPANIES

001361MIU




Gestetner[®]
LANIER
RICOH[®]
savin[®]



RICOH GROUP COMPANIES



Gestetner[®]  **LANIER RICOH[®] SAVIN**



**B064/B065
PARTS CATALOG**

001361MIU



It is the reader's responsibility when discussing the information contained within this document to maintain a level of confidentiality that is in the best interest of Ricoh Corporation and its member companies.

**NO PART OF THIS DOCUMENT MAY BE REPRODUCED IN ANY
FASHION AND DISTRIBUTED WITHOUT THE PRIOR
PERMISSION OF RICOH CORPORATION.**

All product names, domain names or product illustrations, including desktop images, used in this document are trademarks, registered trademarks or the property of their respective companies.

They are used throughout this book in an informational or editorial fashion only and for the benefit of such companies. No such use, or the use of any trade name, or web site is intended to convey endorsement or other affiliation with Ricoh products.



LEGEND

PRODUCT CODE	COMPANY			
	GESTETNER	LANIER	RICOH	SAVIN
B064	6002	LD075	Aficio 1060	2560
B065	7502	LD060	Aficio 1075	2575
B476	Copy Tray Type 1075			
B468/B469	Finisher SR860/SR850			
B473/B474/B475	LCT RT43			
B470	Cover Interposer Tray Type 1075			
B471	Mail Box CS390			
G338/G339	Printer/Scanner Kit Type 1075			
B478	Finisher SR840			
B513	Jogger Unit type 1075			
B531	Punch Unit Type 1090			

DOCUMENTATION HISTORY

REV. NO.	DATE	COMMENTS
*	6/2002	Original Printing
1	11/2002	Addition of B478, B513,B531



B064/B065 PARTS CATALOG

TABLE OF CONTENTS

B064/B065 PARTS LOCATION AND LIST

LOCATION OF UNIT	3	22.TANDEM TRAY 3 (B064/B065)	56
1.EXTERIOR 1 (B064/B065)	14	23.UNIVERSAL TRAY (B064/B065)	58
2.EXTERIOR 2 (B064/B065)	16	24.BY-PASS FEED TRAY (B064/B065)	60
3.OPERATION PANEL (B064/B065)	18	25.PAPER FEED UNIT 1 (B064/B065)	62
4.DF EXTERIOR (B064/B065)	20	26.PAPER FEED UNIT 2 (B064/B065)	64
5.DF ORIGINAL FEED 1 (B064/B065)	22	27.VERTICAL TRANSPORT (B064/B065)	66
6.DF ORIGINAL FEED 2 (B064/B065)	24	28.PAPER REGISTRATION 1 (B064/B065)	68
7.DF ORIGINAL TRANSFER 1 (B064/B065)	26	29.PAPER REGISTRATION 2 (B064/B065)	70
8.DF ORIGINAL TRANSFER 2 (B064/B065)	28	30.PAPER REGISTRATION 3 (B064/B065)	72
9.DF ORIGINAL TRANSFER 3 (B064/B065)	30	31.TONER HOPPER SECTION (B064/B065)	74
10.DF ORIGINAL TRANSFER 4 (B064/B065)	32	32.TONER SUPPLY UNIT (B064/B065)	76
11.DF ORIGINAL EXIT (B064/B065)	34	33.DEVELOPMENT UNIT 1 (B064/B065)	78
12.DF DRIVE/ELECTRICAL 1 (B064/B065)	36	34.DEVELOPMENT UNIT 2 (B064/B065)	80
13.DF DRIVE/ELECTRICAL 2 (B064/B065)	38	35.PCU 1 (B064/B065)	82
14.DF FRAME SECTION (B064/B065)	40	36.PCU 2 (B064/B065)	84
15.OPTICS SECTION 1 (B064/B065)	42	37.PCU 3 (B064/B065)	86
16.OPTICS SECTION 2 (B064/B065)	44	38.PCU 4 (B064/B065)	88
17.OPTICS SECTION 3 (B064/B065)	46	39.TRANSFER BELT UNIT 1 (B064/B065)	90
18.OPTICS SECTION 4 (B064/B065)	48	40.TRANSFER BELT UNIT 2 (B064/B065)	92
19.LASER UNIT (B064/B065)	50	41.FUSING UNIT 1 (B064/B065)	94
20.TANDEM TRAY 1 (B064/B065)	52	42.FUSING UNIT 2 (B064/B065)	96
21.TANDEM TRAY 2 (B064/B065)	54	43.FUSING UNIT 3 (B064/B065)	98
		44.FUSING UNIT 4 (B064/B065)	100

45.PAPER EXIT SECTION 1 (B064/B065).....	102
46.PAPER EXIT SECTION 2 (B064/B065).....	104
47.PAPER EXIT SECTION 3 (B064/B065).....	106
48.DUPLEX UNIT 1 (B064/B065)	108
49.DUPLEX UNIT 2 (B064/B065)	110
50.DUPLEX UNIT 3 (B064/B065)	112
51.DUPLEX UNIT 4 (B064/B065)	114
52.DUPLEX UNIT 5 (B064/B065)	116
53.DRIVE SECTION 1 (B064/B065)	118
54.DRIVE SECTION 2 (B064/B065)	120
55.TONER COLLECTION (B064/B065)	122
56.ELECTRICAL SECTION 1 (B064/B065)	124
57.ELECTRICAL SECTION 2 (B064/B065)	126
58.ELECTRICAL SECTION 3 (B064/B065)	128
59.ELECTRICAL SECTION 4 (B064/B065)	130
60.ELECTRICAL SECTION 5 (B064/B065)	132
61.ELECTRICAL SECTION 6 (B064/B065)	134
62.UPPER FRAME 1 (B064/B065)	136
63.UPPER FRAME 2 (B064/B065)	138
64.UPPER FRAME 3 (B064/B065)	140
65.LOWER FRAME 1 (B064/B065)	142
66.LOWER FRAME 2 (B064/B065)	144
67.BCU BOARD (B064/B065)	146
68.IPU BOARD (B064/B065)	156
69.GW BOARD (B064/B065)	164
70.DECAL AND DOCUMENTS (B064/B065)	172
71.SPECIAL TOOLS (B064/B065).....	176

B064/B065 PARTS INDEX

PARTS INDEX	2
--------------------------	----------

COPY TRAY B476 PARTS LOCATION AND LIST

1.COPY TRAY TYPE 1075 (B476)	2
------------------------------------	---

COPY TRAY B476 PARTS INDEX

PARTS INDEX	2
--------------------------	----------

FINISHER B468/B469 PARTS LOCATION AND LIST

LOCATION OF UNIT	2
-------------------------------	----------

1.EXTERIOR (B468/B469).....	6
2.PAPER TRANSFER (B468/B469)	8
3.SHIFT TRANSFER SECTION 1 (B468/B469)....	10
4.SHIFT TRANSFER SECTION 2 (B468/B469)....	12
5.SHIFT TRANSFER SECTION 3 (B468/B469)....	14
6.STAPLE TRANSFER SECTION 1 (B468/B469)	16
7.STAPLE TRANSFER SECTION 2 (B468/B469)	18
8.STAPLE TRAY 1 (B468/B469)	20
9.STAPLE TRAY 2 (B468/B469)	22
10.STAPLE TRAY 3 (B468/B469)	24
11.STAPLE TRAY 4 (B468/B469)	26
12.PAPER CRIMP SECTION 1 (B468/B469)	28
13.PAPER CRIMP SECTION 2 (B468/B469)	30
14.UPPER PAPER EXIT (B468/B469).....	32
15.LOWER PAPER EXIT 1 (B468/B469)	34
16.LOWER PAPER EXIT 2 (B468/B469)	36
17.DRIVE SECTION 1 (B468/B469).....	38
18.DRIVE SECTION 2 (B468/B469).....	40
19.ELECTRICAL SECTION (B468/B469)	42
20.FRAME SECTION (B468/B469)	44
21.MAIN CONTROL BOARD (B468)	46
22.MAIN CONTROL BOARD (B469)	52
23.DECAL AND DOCUMENTS (B468/B469)	58

FINISHER B468/B469 PARTS INDEX

PARTS INDEX	2
--------------------------	----------

LCT B473/474/B475 PARTS LOCATION AND LIST

1.EXTERIOR (B473)	2
2.PAPER FEED 1 (B473)	4
3.PAPER FEED 2 (B473)	6
4. TRAY DRIVE 1 (B473)	8
5. TRAY DRIVE 2 (B473)	10
6. TRAY DRIVE 3 (B473)	12
7. TRAY EXTENSION KIT (B474)	14
8. A3 PAPER TRAY KIT 1 (B475)	16
9. A3 PAPER TRAY KIT 2 (B475)	18
10. MAIN CONTROL BOARD (B473)	20
11. DECALS AND DOCUMENTS (B473/B475)	22

LCT B473/474/B475 PARTS INDEX

PARTS INDEX	2
--------------------------	----------

COVER INTERPOSER TRAY TYPE 1075 B470 PARTS LOCATION AND LIST

1.EXTERIOR (B470)	2
2.ORIGINAL FEED 1 (B470)	4
3.ORIGINAL FEED 2 (B470)	6
4.ORIGINAL FEED 3 (B470)	8
5.TRANSPORT SECTION (B470)	10

6.ELECTRICAL AND DRIVE (B470)	12
-------------------------------------	----

7.DECAL AND DOCUMENTS (B470)	14
------------------------------------	----

COVER INTERPOSER TRAY TYPE 1075 B470 PARTS INDEX

PARTS INDEX	2
--------------------------	----------

MAIL BOX B471 PARTS LOCATION AND LIST

1.EXTERIOR (B471)	2
2.PAPER EXIT 1 (B471)	4
3.PAPER EXIT 2 (B471)	6
4.PAPER EXIT 3 (B471)	8
5.DECAL AND DOCUMENTS (B471)	10

MAIL BOX B471 PARTS INDEX

PARTS INDEX	2
--------------------------	----------

PRINTER/SCANNER G338/G339/B525/B515 PARTS LOCATION AND LIST

PRINTER/SCANNER/IEEE1394/IEEE802.11B	2
--	---

PRINTER/SCANNER G338/G339/B525/B515 PARTS INDEX

PARTS INDEX	2
--------------------------	----------

FINISHER B478 PARTS LOCATION AND LIST

LOCATION OF UNIT	2
1.EXTERIOR (B478)	6
2.STAPLE TRAY 1 (B478)	8
3.STAPLE TRAY 2 (B478)	10
4.STAPLE TRAY 3 (B478)	12
5.STAPLE TRAY 4 (B478)	14
6.STAPLER UNIT (B478)	16
7.STAPLE TRANSPORT 1 (B478)	18
8.STAPLE TRANSPORT 2 (B478)	20
9.STAPLE TRANSPORT 3 (B478)	22
10.STAPLE TRANSPORT 4 (B478)	24
11.TRANSPORT SECTION 1 (B478)	26
12.TRANSPORT SECTION 2 (B478)	28
13.PAPER EXIT SECTION 1 (B478)	30
14.PAPER EXIT SECTION 2 (B478)	32
15.PAPER EXIT SECTION 3 (B478)	34
16.PAPER EXIT SECTION 4 (B478)	36
17.DRIVE SECTION (B478)	38
18.ELECTRICAL SECTION (B478)	40
19.FRAME SECTION 1 (B478)	42
20.FRAME SECTION 2 (B478)	44
21.DECAL AND DOCUMENT (B478)	46

FINISHER B478 PARTS INDEX

PARTS INDEX	2
--------------------------	----------

JOGGER UNIT B513 PARTS LOCATION AND LIST

1.JOGGER UNIT (B513)	2
----------------------------	---

JOGGER UNIT B513 PARTS INDEX


PARTS INDEX	2
--------------------------	----------

PUNCH UNIT B531 PARTS LOCATION AND LIST

1.PUNCHI UNIT (B531)	2
----------------------------	---

PUNCH UNIT B531 PARTS INDEX


PARTS INDEX	2
--------------------------	----------



B064/B065 PARTS LOCATION AND LIST

Best Solution






This section instructs you as to the numbers and names on this machine.




LOCATIONS OF UNITS

1. EXTERIOR 1 (B064/B065)




See Page 15

2. EXTERIOR 2 (B064/B065)




See Page 17

3. OPERATION PANEL (B064/B065)




See Page 19

4. DF EXTERIOR (B064/B065)




See Page 21

5. DF ORIGINAL FEED 1 (B064/B065)



See Page 23


6. DF ORIGINAL FEED 2 (B064/B065)



See Page 25


LOCATIONS OF UNITS

7. DF ORIGINAL TRANSFER 1 (B064/B065)




See Page 27

8. DF ORIGINAL TRANSFER 2 (B064/B065)




See Page 29

9. DF ORIGINAL TRANSFER 3 (B064/B065)




See Page 31

10. DF ORIGINAL TRANSFER 4 (B064/B065)




See Page 33

11. DF ORIGINAL EXIT (B064/B065)



See Page 35


12. DF DRIVE/ELECTRICAL 1 (B064/B065)



See Page 37


LOCATIONS OF UNITS

13. DF DRIVE/ELECTRICAL 2 (B064/B065)




See Page 39

14. DF FRAME SECTION (B064/B065)




See Page 41

15. OPTICS SECTION 1 (B064/B065)




See Page 43

16. OPTICS SECTION 2 (B064/B065)




See Page 45

17. OPTICS SECTION 3 (B064/B065)



See Page 47


18. OPTICS SECTION 4 (B064/B065)



See Page 49


LOCATIONS OF UNITS

19. LASER UNIT (B064/B065)




See Page 51

20. TANDEM TRAY 1 (B064/B065)




See Page 53

21. TANDEM TRAY 2 (B064/B065)




See Page 55

22. TANDEM TRAY 3 (B064/B065)




See Page 57

23. UNIVERSAL TRAY (B064/B065)



See Page 59


24. BY-PASS FEED TRAY (B064/B065)



See Page 61


LOCATIONS OF UNITS

25. PAPER FEED UNIT 1 (B064/B065)




See Page 63

26. PAPER FEED UNIT 2 (B064/B065)




See Page 65

27. VERTICAL TRANSPORT (B064/B065)




See Page 67

28. PAPER REGISTRATION 1 (B064/B065)




See Page 69

29. PAPER REGISTRATION 2 (B064/B065)



See Page 71


30. PAPER REGISTRATION 3 (B064/B065)



See Page 73


LOCATIONS OF UNITS

31. TONER HOPPER SECTION (B064/B065)




See Page 75

32. TONER SUPPLY UNIT (B064/B065)




See Page 77

33. DEVELOPMENT UNIT 1 (B064/B065)




See Page 79

34. DEVELOPMENT UNIT 2 (B064/B065)




See Page 81

35. PCU 1 (B064/B065)



See Page 83


36. PCU 2 (B064/B065)



See Page 85


LOCATIONS OF UNITS

37. PCU 3 (B064/B065)




See Page 87

38. PCU 4 (B064/B065)




See Page 89

39. TRANSFER BELT UNIT 1 (B064/B065)




See Page 91

40. TRANSFER BELT UNIT 2 (B064/B065)




See Page 93

41. FUSING UNIT 1 (B064/B065)



See Page 95


42. FUSING UNIT 2 (B064/B065)



See Page 97


LOCATIONS OF UNITS

43. FUSING UNIT 3 (B064/B065)




See Page 99

44. FUSING UNIT 4 (B064/B065)




See Page 101

45. PAPER EXIT SECTION 1 (B064/B065)




See Page 103

46. PAPER EXIT SECTION 2 (B064/B065)




See Page 105

47. PAPER EXIT SECTION 3 (B064/B065)



See Page 107


48. DUPLEX UNIT 1 (B064/B065)



See Page 109


LOCATIONS OF UNITS

49. DUPLEX UNIT 2 (B064/B065)




See Page 111

50. DUPLEX UNIT 3 (B064/B065)




See Page 113

51. DUPLEX UNIT 4 (B064/B065)




See Page 115

52. DUPLEX UNIT 5 (B064/B065)




See Page 117

53. DRIVE SECTION 1 (B064/B065)



See Page 119


54. DRIVE SECTION 2 (B064/B065)



See Page 121


LOCATIONS OF UNITS

55. TONER COLLECTION (B064/B065)




See Page 123

56. ELECTRICAL SECTION 1 (B064/B065)




See Page 125

57. ELECTRICAL SECTION 2 (B064/B065)




See Page 127

58. ELECTRICAL SECTION 3 (B064/B065)




See Page 129

59. ELECTRICAL SECTION 4 (B064/B065)



See Page 131


60. ELECTRICAL SECTION 5 (B064/B065)



See Page 133


LOCATIONS OF UNITS

61. ELECTRICAL SECTION 6 (B064/B065)




See Page 135

62. UPPER FRAME 1 (B064/B065)




See Page 137

63. UPPER FRAME 2 (B064/B065)




See Page 139

64. UPPER FRAME 3 (B064/B065)




See Page 141

65. LOWER FRAME 1 (B064/B065)




See Page 143

66. LOWER FRAME 2 (B064/B065)



See Page 145

1.EXTERIOR 1 (B064/B065)




1.EXTERIOR 1 (B064/B065)

Rev. 02/27/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	A294 1292	Door Switch Bracket	1
2	B065 1361	Decal - Misfeed Removal	1
3	B065 1329	Upper Right Door Seal	1
4	A293 1343	Upper Hinge	1
5	B065 1366	Decal - Toner Supply	1
6	B065 1301	Front Door	1
7	B065 1327	Door Catch	1
8	B065 1325	Main Switch Cover	1
9	B065 1223	Lower Hinge	1
10	B065 1323	Guide Plate Lever	1
11	B065 1326	Micro Switch Lever	1
12	B064 7012	Model Name Plate (B064 RIC)	1
12	B064 7018	Model Name Plate (B064 LAN)	1
12	B064 7019	Model Name Plate (B064 INF)	1
12	B065 7012	Model Name Plate (B065 RIC)	1
12	B065 7018	Model Name Plate (B065 LAN)	1
12	B065 7019	Model Name Plate (B065 INF)	1
12	B064 7015	Model Name Plate - GES 6002	1
12	B064 7016	Model Name Plate - NSH 6005	1
12	B064 7017	Model Name Plate - REX 6008	1
12	B065 7015	Model Name Plate - GES 7502	1
12	B065 7016	Model Name Plate - NSH 7505	1
12	B065 7017	Model Name Plate - REX 7508	1
13	B065 1363	Decal - Main Switch (NA/ASIA/KOR)	1
13	B065 1364	Decal - Main Switch (EU/CHN/TWN)	1
14	B065 1315	Inner Cover - Main Switch	1
15	B065 1316	Fusing Inner Cover	1
16	B065 3699	Decal - Release Lever	1
17	B065 1313	PCU Inner Cover	1
18	AX64 0137	Cooling Fan - 24V	1
19	B065 1318	PCU Duct Inner Cover	1
20	A060 2512	Registration Roller Knob	2
21	A294 1378	Decal - Total Counter	1
22	B065 1367	Decal - Front Door	1
23	B065 1314	Lower Right Inner Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
24	A229 3290	Right Inner Cover	1
25	A229 3291	Right Inner Cover	1
26	AA10 0006	Nut - M3.6	1
27	B065 6184	Paper Feed Inner Cover	1
28	B027 8521	O/I Holder	1
29	B023 1101	Stand Holder	2
30	B065 8490	Decal Sheet - Paper Size	1
31	B070 1307	Decal - Caution Chart Paper Set	1
32	B065 1369	Decal - Cleaning	1
33	B477 4431	Decal - Original Table	1
101	0450 3008B	Tapping Screw - M3x8	
102	0450 4010B	Tapping Screw - 4x10	
103	0354 0080B	Screw - M4X8	
104	0451 4008B	Philips Tapping Screw - M4x8	
105	0951 4008B	Philips Screw With Washer - M4x8	
106	0951 4012B	Philips Screw With Flat Washer	

2.EXTERIOR 2 (B064/B065)




2.EXTERIOR 2 (B064/B065)

Rev. 02/10/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 3689	Toner Collection Bottle Bracket	1
2	A096 3712	Ratch	1
3	B065 3681	Toner Collection Bottle	1
4	AA00 0059	Caution Decal - English	1
5	A007 3751	Large Cap - Toner Collection Tank	1
6	B065 1334	Lower Left Cover	1
7	B065 4480	Decal - Cover	1
8	B065 1344	G4 Cap	1
9	B065 1304	Upper Left Cover	1
10	B065 1311	Upper Left Cover	1
11	B477 4391	Decal - Exposure Glass Cleaning	1
12	AA14 3416	Stepped Screw - M4x3	4
13	B065 1312	Operation Inner Cover	1
14	AX64 0110	Axial Fan - Mm40 24V	1
15	B065 1345	Fan Bracket	1
16	B065 1309	Upper Rear Cover	1
17	AA15 2701	Duct Seal	1
18	AA01 2119	Filter	1
19	B065 1332	Louver	1
20	B065 1243	Operation Panel Inner Cover	1
21	B065 1305	Upper Rear Cover	1
22	AA01 0108	Ozone Filter	1
23	AA01 0114	Front Ozone Filter	1
24	A293 1332	Duct Holder	1
25	B065 1237	Exhaust Cover Duct	1
26	B065 1308	Lower Rear Cover	1
27	B065 1244	Upper Left Cover	1
28	B065 1302	Upper Right Cover	1
29	B065 1343	NCU Cap	1
30	B065 1303	LCT Cover	1
31	B065 1310	Upper Right Cover	1
32	B065 1333	Lower Right Cover	1
33	B065 1341	Connector Cap	2
34	B065 1342	Coupling Cap	1
35	AA15 2315	Tank Seal	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4010H	Tapping Screw - 4x10	
102	0450 3008B	Tapping Screw - M3x8	
103	0451 3012H	Tapping Screw - 3x12	
104	0313 0100B	Philips Pan Head Screw - M3x10	
105	0450 4008B	Tapping Screw - 4x8	
106	0451 4008B	Philips Tapping Screw - M4x8	

3.OPERATION PANEL (B064/B065)




3.OPERATION PANEL (B064/B065)

Rev. 02/27/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 1406	Operation Panel Ass'y - A4 (EU)	1
1	B065 1404	Operation Panel Ass'y - LT	1
1	B065 1418	Operation Panel Ass'y (KOR)	1
1	B065 1416	Operation Panel Ass'y A4 (CHN)	1
1	B065 1408	Operation Panel Ass'y (TWN)	1
1	B065 1414	Operation Panel Ass'y (ASIA)	1
2	B065 1448	Cap - Application	1
3	B065 1456	Sheet - Left Operation	1
4	B065 1440	Keytop - 10key	1
5	B065 1423	Left Operation PCB	1
6	B065 5173	LCDC Board - LT	1
6	B065 5174	LCDC Board - A4	1
6	B065 5239	LCDC Board (TWN/ASIA)	1
6	B065 5240	LCDC Board (CHN)	1
6	B065 5241	LCDC Board (KOR)	1
7	B065 1470	LCDC Bracket	1
8	B065 1429	LCD	1
9	B065 1459	LCD Short Sheet	2
10	B065 1458	LCD Long Sheet	2
11	B065 1454	Sheet - Right Operation	1
12	B065 1422	Right Operation PCB Ass'y	1
13	A229 5216	Touch Panel	1
14	B065 1457	Sheet - Touch Panel	1
15	B065 1447	Keytop - Counter	1
16	B065 1439	Keytop - Reset Switch	1
17	B065 1446	Keytop - Function	1
18	B065 1444	Keytop - Power Source	1
19	B065 1455	Sheet - Power Source	1
20	B065 1443	Keytop - Sample Print	1
21	B065 1441	Keytop - Start	1
22	B065 1442	Keytop - Clear/Stop	1
23	B065 1460	Keytop - Application - LT	1
23	B065 1462	Keytop - Application - A4	1
24	B065 1461	Keytop - Display - LT	1
24	B065 1463	Keytop - Display - A4	1

Index No.	Part No.	Description	Q'ty Per Assembly
25	B065 1451	Lens - Application	1
26	B065 1425	Operation Panel Case - LT	1
26	B065 1427	Operation Panel Case - A4	1
101	0451 3006B	Tapping Screw - M3x6	




4.DF EXTERIOR (B064/B065)

Rev. 02/27/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B477 1891	Front Cover	1
2	B477 2711	Pressure Plate	1
3	B477 1922	Lower Cover	1
4	B477 2715	Pressure Plate Tape	8
5	B477 1861	Exit Cover	1
6	B477 4911	Rear Cover Sponge	4
7	B477 1912	Rear Cover	1
8	B477 4431	Decal - Original Table	1
9	B477 4381	Caution Decal - CIS	1
10	A859 7211	Stepped Screw	2
11	B477 4362	Decal - Misfeed Removal - Ext	1
12	B065 7001	ADF Unit	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0951 5010B	Philips Screw With Washer - M5x10	
102	0451 3006H	Tapping Screw - 3x6	

5.DF ORIGINAL FEED 1 (B064/B065)




5.DF ORIGINAL FEED 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B477 2272	Table Side Fence	1
2	A376 4599	Side Fence Pad	1
3	G564 4151	Rail - Side Fence	1
4	B477 4311	Decal - Original Base	1
5	5206 2686	Snap Ring	1
6	A806 1351	Original Sensor Feeler	1
7	B477 2286	Original Sensor Feeler Stud	1
8	B477 2262	Original Table Base	1
9	B477 2263	Cushion	1
10	AW02 0086	Photointerruptor	2
11	B477 2281	Original Sensor Bracket	1
12	B477 2323	Base Lift Lever	1
13	B477 2322	Base Lift Shaft	1
14	5053 0447	Bushing - 6mm	1
15	A806 1335	Original Table Guide Plate	1
16	B477 2264	Base Cushion Sheet	1
17	B477 5671	Registration Relay Harness	1
18	5053 0223	Bushing - 8mm	1
19	A806 2281	Gear - Z47	1
20	B477 1731	Face Original Table	1
21	5215 2621	Snap Ring - M6	1
22	5447 2681	Snap Ring	1
23	B477 2291	Original Table Stay	1
24	5415 4145	Stud	1
25	B477 1765	Spring Plate - Original Table Stopp	1
26	B477 1761	Original Table Stopper	1
27	B477 1755	Back Original Table	1
28	AW01 0087	Photo Sensor - Ass'y	3
29	B477 5631	Original Table Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0450 3006B	Tapping Screw - M3x6	
103	0802 5279	Tapping Screw - With Washer - M3X8	
104	0632 0140G	Parallel Pin	
105	0720 0040B	Retaining Ring - M4	
106	0720 0060B	Retaining Ring - M6	
107	1105 0310	Harness Clamp - LWS-1S	

6.DF ORIGINAL FEED 2 (B064/B065)



6.DF ORIGINAL FEED 2 (B064/B065)

Rev. 02/28/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	A806 2271	Gear - Z18	1
2	A806 2151	Timing Pulley - T19/Z23 S2M/M0.6	1
3	B477 2222	Pick-up Roller Bracket	1
4	5447 2681	Snap Ring	2
5	5053 0447	Bushing - 6mm	2
6	A806 1321	Pickup Roller	1
7	AA13 2171	Spacer - 6x20x1	1
8	A806 4118	Timing Belt - B40S2M118	1
9	B477 2231	Pick-up Roller Lever	1
10	B477 2182	Rear Entrance Guide	1
11	A806 1163	Guide Plate Cushion	4
12	A806 2153	Timing Pulley - T27 S2M	1
13	A628 1225	Bushing - 8mm	4
14	B477 2191	Separation Shaft	1
15	A806 1293	Feed Belt Drive Roller	1
16	A680 1621	Feed-in Unit Stopper	1
17	B477 2172	Front Entrance Guide	1
18	AA13 2013	Spacer	1
19	AA06 3315	Spring - Belt Drive Shaft	1
20	A418 1158	Spacer - M6.5x1	1
21	B301 1286	Bushing - 6x10x6	1
22	A806 1295	Feed Belt	1
23	A806 4261	Spring Belt Guide Roller	2
24	A806 1292	Feed Belt Bracket	1
25	A806 1298	Transport Belt Roller Shaft	1
26	A806 1294	Feed Belt Driven Roller	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060B	Retaining Ring - M6	
102	0720 0040B	Retaining Ring - M4	

B064/B065




7.DF ORIGINAL TRANSFER 1 (B064/B065)

Rev. 02/27/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	5446 2824	Screw - Duplex Guide Plate	1
2	B477 1841	Front Cover Bracket	1
3	B477 4912	Paper Feed Cover Sponge	8
4	B477 1851	Rear Cover Bracket	1
5	B477 1825	Paper Feed Release Lever	2
6	B477 4117	Spring	2
7	B477 1831	Grip Shaft	1
8	G564 6076	Decal - Exposure Glass	1
9	B477 4352	Decal - Misfeed Removal	1
10	B477 1821	Paper Feed Cover Grip	1
11	B477 4331	Decal - Original Size	1
12	B477 2361	Pull Out Roller Bracket	1
13	B477 1791	Paper Feed Cover	1
14	B477 2391	Paper Feed Grounding Plate	1
15	B477 5651	Paper Size Relay Harness	1
16	AW02 0104	Photointerruptor	3
17	AW02 0095	Photointerruptor	1
18	B477 2382	Paper Size Sensor Bracket	1
19	AA08 0037	Bushing - 6mm	2
20	B477 4111	Spring	2
21	B477 2351	Driven Pull Out Roller	1
22	AW01 0049	Photo Reflection Sensor	2
23	B477 2373	Relay Roller Arm	4
24	B477 2372	Driven Paper Feed Roller	4
25	B477 4113	Spring	4
26	B477 2341	Upper Paper Feed Guide	1
27	B477 5671	Registration Relay Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0805 0089	Retaining Ring - M4	
102	0451 3008B	Tapping Screw - M3x8	
103	0450 3008B	Tapping Screw - M3x8	
104	0720 0040B	Retaining Ring - M4	
105	0451 3006B	Tapping Screw - M3x6	
106	1105 0310	Harness Clamp - LWS-1S	
107	1105 0511	Harness Clamp - LWS-0306ZC	

8.DF ORIGINAL TRANSFER 2 (B064/B065)




8.DF ORIGINAL TRANSFER 2 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B477 2581	Entrance Scanning Guide	1
2	B477 2145	Guide Bracket	1
3	B477 4115	Spring	4
4	B477 2577	Driven Entrance Scanning Roller	2
5	5324 1658	Bushing- 4x8x4.5mm	1
6	A374 2181	Spacer	1
7	B477 2575	Entrance Scanning Roller Shaft	1
8	B477 2574	Roller Arm	4
9	A422 1063	Seal - 0.7x13x20	1
10	B477 2561	Entrance Scanning Base	1
11	A422 1079	Bushing - 8x16x5mm	1
12	B477 1775	Paper Feed Cover Bracket	1
13	AA14 3074	Stepped Screw - M4x5	1
14	B477 2111	Pull Out Roller	1
15	B477 2411	Drive Entrance Scanning Roller	1
16	B477 2121	Drive Relay Roller	1
17	AW01 0049	Photo Reflection Sensor	1
18	B477 2665	Registration Sensor Bracket	1
19	A859 3225	Discharge Brush	1
20	B477 2471	Entrance Scanning Guide Plate	1
21	5206 2684	Shoulder Screw - M3	1
22	B477 2143	Lower Anti-static Brush	1
23	B477 2141	Lower Paper Feed Guide	1
24	B477 2151	Separation Cap	1
25	B477 2161	Lower Grounding Plate	1
26	B477 5681	Registration Sensor Relay Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0720 0060B	Retaining Ring - M6	
103	0742 3808	Ball Bearing - 8x16x5	
104	0450 3008B	Tapping Screw - M3x8	
105	0453 3006B	Tapping Screw - M3x6	
106	1105 0514	Edge Saddle - EDS-0607I	

9.DF ORIGINAL TRANSFER 3 (B064/B065)




9.DF ORIGINAL TRANSFER 3 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B477 1191	Front Left Stopper	1
2	5415 4145	Stud	1
3	B477 4121	Spring	2
4	B477 4123	Spring	2
5	B477 1131	Front Scanning Bracket	1
6	B477 2517	Scanning Guide Plate	1
7	5053 0447	Bushing - 6mm	1
8	B477 2511	Scanning Roller	1
9	B477 2431	Front Scanning Arm	1
10	B477 2425	Front Scanning Roller Arm	1
11	B477 2421	Drive Scanning Roller	1
12	B477 1141	Rear Scanning Bracket	1
13	A697 2131	Antistatic Brush	1
14	B477 2453	Rear Lock Hook - CIS	1
15	B477 2452	Lever Shaft - Misfeed Removal	1
16	B477 4125	Spring	1
17	B477 2455	Front Lock Hook - CIS	1
18	B477 2495	Paper Feed Sensor Bracket	1
19	AW01 0049	Photo Reflection Sensor	1
20	B477 2491	Anti-static Brush	1
21	B477 2481	Entrance Scanning Guide	1
22	B477 2487	Upper Exit Scanning Sheet	1
23	B477 2521	Scanning Roller Cover	1
24	B477 3817	Timing Belt	1
25	B477 2516	Discharge Brush	1
26	B477 2451	Rear Lever Shaft - Misfeed Removal	1
27	B477 2480	Upper Exit Scanning Guide Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0720 0060B	Retaining Ring - M6	
103	0742 3808	Ball Bearing - 8x16x5	
104	0805 0089	Retaining Ring - M4	
105	1105 0511	Harness Clamp - LWS-0306ZC	

10.DF ORIGINAL TRANSFER 4 (B064/B065)




10.DF ORIGINAL TRANSFER 4 (B064/B065)

Rev. 02/14/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	A422 1078	Bushing - 6x12x4mm	1
2	B477 2621	Anti-static Brush	1
3	B477 3245	Pulley	1
4	B477 3819	Timing Belt	1
5	B477 3243	Pulley	1
6	B477 3933	CIS Inverter Bracket	1
7	B477 2683	CIS Sheet	1
8	B477 2682	CIS Sheet Bracket	1
9	5447 2681	Snap Ring	1
10	A859 2241	Reverse Roller	1
11	A247 2900	Torque Limiter - 53mm x 1mm	1
12	B477 3131	Reverse Roller Shaft	1
13	B477 2131	Inverter Roller Stay	1
14	B477 5830	Contact Image Sensor	1
15	B477 2441	Exit Cis Roller	1
16	B477 2811	Drive Exit Roller	1
17	B477 2820	Upper Exit Guide Plate	1
18	B351 3835	Discharge Brush - Exit	1
19	AW02 0075	Photointerruptor	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	1105 0159	PCB Stud	
103	0720 0040B	Retaining Ring - M4	
104	0632 0120G	Parallel Pin - 2x12	
105	0805 0089	Retaining Ring - M4	
106	0720 0060B	Retaining Ring - M6	
107	0742 3808	Ball Bearing - 8x16x5	
108	0741 3706	Ball Bearing - 6x10x3	

11.DF ORIGINAL EXIT (B064/B065)




11.DF ORIGINAL EXIT (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B477 3241	Gear - 21Z	1
2	B477 2661	Back Scanning Positioning Pin	1
3	B477 2641	Long Arm Shaft	1
4	B477 2631	Lower Exit Guide Plate	1
5	B477 2645	Short Arm Shaft	1
6	B477 2636	Driven Exit Scanning Roller	8
7	B477 4127	Exit Arm Spring	4
8	B477 2637	Driven Exit Arm	4
9	B477 2653	Bushing - 6mm	1
10	B477 4129	Spring - 12n	2
11	B477 2651	Back Scanning Roller	1
12	B477 2621	Anti-static Brush	1
13	B477 2715	Pressure Plate Tape	4
14	B477 2611	Lower Exit	1
15	B477 2881	Guide Plate Bracket	1
16	A697 2131	Antistatic Brush	1
17	A859 4836	Bushing- Exit Driven Roller	4
18	B477 4131	Spring	4
19	B477 2861	Driven Exit Roller	2
20	B477 2872	Exit Arm	4
21	B477 4132	Spring	4
22	B477 2851	Lower Exit Guide Plate Sheet	4
23	B477 2841	Lower Exit Guide	1
24	B477 2875	Exit Shaft	1
25	A422 1063	Seal - 0.7x13x20	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0805 0089	Retaining Ring - M4	
102	0720 0030E	Retaining Ring - M3	
103	0450 3008B	Tapping Screw - M3x8	
104	0451 3006B	Tapping Screw - M3x6	
105	0802 5276	Tapping Screw With Washer - M3x6	


12.DF DRIVE/ELECTRICAL 1 (B064/B065)



12.DF DRIVE/ELECTRICAL 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B477 3711	Paper Feed Motor	1
2	B477 3115	Paper Feed Motor Stay	1
3	B477 3111	Paper Feed Motor Bracket	1
4	AA06 0842	Tension Spring	1
5	B477 3163	Gear - 50Z	1
6	B477 3161	Gear - 37Z	1
7	B477 3151	Gear - 31Z	1
8	A548 2139	Pulley	2
9	5447 2681	Snap Ring	3
10	B477 3121	Separation Roller Shaft	1
11	B477 3123	Gear - 24Z	1
12	A806 2244	Separation Shaft Stopper	1
13	AW02 0075	Photointerruptor	1
14	A859 2230	Ball Bearing - 6x13x5	4
15	B477 3820	Timing Belt	1
16	5053 0447	Bushing - 6mm	2
17	B477 3811	Timing Belt	1
18	B477 3145	Pulley	1
19	B477 3181	Paper Feed Drive Bracket	1
20	A680 2262	Feeler - Pick-up Roller Cam	1
21	B477 3251	Pick-up Roller Cam	1
22	B477 3141	Gear - 23Z	1
23	B477 3812	Timing Belt	1
24	B477 3143	Gear - 20Z	1
25	AX04 0096	Stepping Motor - DC 18W	1
26	B477 3177	Pulley	1
27	B477 3173	Pulley	1
28	B477 3821	Timing Belt	1
29	B477 3813	Timing Belt	1
30	B477 3171	Pulley	1
31	B301 2141	Pulley - 39Z	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4006B	Tapping Screw - 4x6	
102	0451 3006B	Tapping Screw - M3x6	
103	0632 0120G	Parallel Pin - 2x12	
104	0720 0040B	Retaining Ring - M4	
105	0720 0060B	Retaining Ring - M6	
106	1105 0310	Harness Clamp - LWS-1S	
107	1105 0511	Harness Clamp - LWS-0306ZC	




13.DF DRIVE/ELECTRICAL 2 (B064/B065)

Rev. 03/28/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B477 5751	Interface Harness	1
3	B477 5601	Registration/Paper Size Sensor Harness	1
4	B477 5611	Detection Sensor Harness	1
5	B477 5621	Original Sensor Harness	1
6	B477 5731	ADF-CIS Harness	1
7	B477 5711	Pick-up Motor Harness	1
8	B477 5571	ADF Main Control Board	1
9	B477 5691	Paper Feed Motor Harness	1
10	B477 5721	CIS Harness	1
11	B477 3731	Exit Motor	1
12	A697 1125	Stepped Screw - Lever	1
13	B477 3721	Scanning Motor	1
14	B477 3215	Scanning Motor Stay	1
15	B477 3211	Scanning Motor Bracket	1
16	AA06 0846	Tension Spring	1
17	B477 3217	Pulley	2
18	B477 3815	Timing Belt	1
19	B477 3818	Timing Belt	1
20	5936 2321	Rubber Bushing - Vibration Damper	2
21	B477 3814	Timing Belt	1
22	B477 3816	Timing Belt	1
23	A806 2285	Gear - Z20/Z47	1
24	A806 2287	Gear - Z20/Z47	1
25	A806 2283	Gear - Z20/Z47	2
26	A806 2161	Timing Pulley - T30/Z20 S2M/M0.8	1
27	AA13 2152	Spacer - 8x20x1	1
28	A806 4117	Timing Belt - B40S2M158	1
29	B477 2332	Motor Bracket	1
30	A806 2911	Stepper Motor Ass'y - DC 13W	1
31	B477 4141	Spring - 12.6n	1
32	5215 2621	Snap Ring - M6	1
33	B477 3175	Pulley	2
34	5419 5714	Stepped Screw - M4	1
35	B477 3231	Tightner	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	B477 5761	CIS Harness	1
37	B477 5515	Main ROM	1
38	A680 1171	Harness Holder	1
101	0451 3006B	Tapping Screw - M3x6	
102	1607 0623	Ferrite Core - TFC-16-8-13	
103	0451 4006B	Tapping Screw - 4x6	
104	0720 0040B	Retaining Ring - M4	
105	0720 0060B	Retaining Ring - M6	
106	0353 0050B	Philips Truss Head Screw - M3x5	
107	1105 0310	Harness Clamp - LWS-1S	
108	1107 0884	Fuse - 5A 250V	
109	1607 0622	Ferrite Core TFC16816	1

14.DF FRAME SECTION (B064/B065)




14.DF FRAME SECTION (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B477 1111	Front Side Plate	1
2	B477 1121	Rear Side Plate	1
3	B477 2333	Motor Bracket Cushion	1
4	B477 1171	Arm Shaft	1
5	AA14 3039	Spring Holder	2
6	B301 1136	Spring Plate - 0.4mm	2
7	B477 1151	Left Frame Stay	1
8	A351 4281	Anti-vibration Cushion	2
9	B477 1510	Left Hinge	1
10	A806 1135	Contact Point Shaft	1
11	B477 1161	Right Frame Stay	1
12	B477 1520	Right Hinge	1
13	B477 1185	Sensor Feeler	1
14	AW02 0075	Photointerruptor	2
15	B477 1181	Sensor Bracket	1
16	B477 4921	Clamp	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0030B	Retaining Ring - M3	
102	0451 3006B	Tapping Screw - M3x6	
103	1105 0310	Harness Clamp - LWS-1S	
104	1105 0290	Harness Clamp - HORIZONTAL	
105	1105 0511	Harness Clamp - LWS-0306ZC	

15.OPTICS SECTION 1 (B064/B065)




15.OPTICS SECTION 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AW01 0034	Original Width Sensor	1
2	AA15 0704	Seal - 90x29.5x0.2	1
3	B065 1787	Scale Bracket	1
4	B065 1782	Seal	1
5	B065 1784	Ground Plate	2
6	B065 1783	Exposure Glass	1
7	B065 1772	Left Scale	1
8	AA14 3520	Shoulder Screw - M3	6
9	AX40 0063	Anticondensation Heater - 230V 9W	1
9	AX40 0064	Anticondensation Heater - 230V 9W	1
10	B065 1775	Sheet Through Scale (LT)	1
10	B065 1776	Sheet Through Scale (A4)	1
11	B065 1779	Decal - Scale (LT)	1
11	B065 1778	Decal - Scale (A4)	1
12	A628 3112	Shielding Sheet	1
13	AC01 2067	Exposure Glass	1
14	B065 1093	ADF Bracket	2
15	B065 1070	Upper Front Stay	1
16	B065 1785	Right Stay	1
17	B065 1841	Inner Cover	1
18	AW01 0059	Original Sensor - H=1-66	2
19	B065 1788	Printing Rear Scale	1
20	5442 1924	Exposure Glass Cushion	4
21	AA16 1137	Cushion - 0.5	2
22	B065 1843	Grounding Plate	1
23	B065 1773	Scale Bracket Seal	2
24	B477 5741	Original Connecting Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0040B	Screw - M3X4	
102	0353 0060B	Philips Pan Head Screw - M3x6	
103	0450 3008B	Tapping Screw - M3x8	
104	0353 0080B	Screw - M3X8	
105	0354 0080B	Screw - M4X8	
106	0451 4008B	Philips Tapping Screw - M4x8	
107	0453 3006B	Tapping Screw - M3x6	

16.OPTICS SECTION 2 (B064/B065)




16.OPTICS SECTION 2 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 1691	Polygon Motor Cover	1
2	G029 1982	LD - Decal	1
3	B065 1797	Scanner Duct Filter	1
4	B065 1791	Left Scanner Duct	1
5	B065 1801	Right Scanner Duct	1
6	B065 1721	Image Scanning Board	1
7	B065 5469	FFC/SBU Harness - 15p	2
8	B065 5470	FFC/SBU Harness - 40p	1
9	B065 1171	Development Fan Bracket	1
10	B065 1833	Harness Bracket	1
11	B065 1698	Development Cooling Duct	1
12	B065 5401	20p Cable - LVDS SBU	1
13	B065 5650	Scanner Unit Harness	1
14	B065 5405	LCDC Harness	1
15	B065 5195	VIB Board	1
16	B065 5501	VIB Power Source Harness	1
17	AX64 0135	Cooling Fan - 24V	2
18	B065 1172	Development Fan Harness	1
19	B065 1834	Insulating Sheet	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0516	Clamp	
102	0353 0060B	Philips Pan Head Screw - M3x6	
103	0354 0080B	Screw - M4X8	
104	0951 3008B	Philips Screw With Flat Washer - M3x8	
105	0451 4020B	Tapping Scrw - M4x20	
106	1105 0306	Metal Clamp - Al-4	
107	1105 0516	Clamp	
108	0451 4008B	Philips Tapping Screw - M4x8	
109	1105 0511	Harness Clamp - LWS-0306ZC	

17.OPTICS SECTION 3 (B064/B065)




17.OPTICS SECTION 3 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AB03 2717	Pulley - 26Z	4
2	AA13 2174	Spacer - M8	2
3	A096 1873	Scanner Shoe Pin	8
4	A293 1766	2nd Mirror Plate	4
5	A069 1883	Shoe - Scanner	8
6	B065 1766	Second Mirror	2
7	B065 1753	Adjusting Plate	1
8	B065 1751	2nd Scanner Unit	1
9	AX50 0081	Exposure Lamp	1
10	A294 1712	Rear Holder - Lamp	1
11	B065 1735	Reflector	1
12	B065 1736	Invertor Cover	1
13	B065 1741	Harness Guide	1
14	B065 1733	1st Scanner Front Side Plate	1
15	B065 1737	Clamp	2
16	B065 1740	Harness Plate	1
17	B065 1734	1st Scanner Rear Side Plate	1
18	B065 1743	1st Mirror	1
19	B065 1732	1st Scanner Frame	1
20	B065 1738	Spring Plate	2
21	B065 5610	1st Scanner Harness	1
22	B065 5220	Relay Board	1
23	AZ50 0060	Exposure Lamp Inverter	1
24	B065 1742	Insulator	1
25	B065 1731	1st Scanner Unit	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 3006W	Tapping Screw - M3x6	
102	0453 3006B	Tapping Screw - M3x6	
103	0954 4008B	Philips Screw - M4x8	
104	0951 3006B	Philips Screw With Flat Washer - M3x6	
105	0954 3008B	Philips Screw - M3x8	
106	0720 0060E	Retaining Ring - M6	
107	0951 3006	Philips Screw With Flat Washer M3x6	

18.OPTICS SECTION 4 (B064/B065)




18.OPTICS SECTION 4 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A293 1674	Front Slide Rail	2
2	AB03 2717	Pulley - 26Z	2
3	B065 1830	Scanner Board Guide	1
4	B065 1831	Scanner Board Bracket	1
5	B065 1715	Scanner Wire	2
6	B065 1713	Rear Wire Tension Bracket	1
7	AA06 0221	Gripper Solenoid Spring	2
8	B065 1685	Rear Frame	1
9	B065 5454	HP Sensor Relay Harness	1
10	AW02 0056	Photointerruptor - EE-SX4235A-P1	1
11	B065 1825	H.P. Sensor Bracket	1
12	A267 1820	Sheet - Photointerrupter	1
13	B065 5180	SDRD Board	1
14	B065 1706	Bracket - Scanner Motor	1
15	A134 1724	Cushion - Stepper Motor	1
16	B065 1708	Stepper Motor	1
17	AA06 0763	Tension Spring	1
18	A134 1698	Idle Pulley	2
19	B065 1718	Screw - M4X8	3
20	B065 1717	Timing Belt	1
21	AB03 0727	Pulley - 58Z	1
22	AB03 2070	Pulley	1
23	B065 1688	Lens Holder Block	2
24	B065 1711	Drive Shaft	1
25	AB03 2069	Pulley	1
26	B065 1712	Front Wire Tension Bracket	1
27	B065 1682	Front Frame	1
28	G029 1982	LD - Decal	1
29	B065 5471	Grounding Wire	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0354 0080B	Screw - M4X8	
102	0720 0060B	Retaining Ring - M6	
103	0353 0060B	Philips Pan Head Screw - M3x6	
104	0314 0080B	Philips Pan Head Screw - M4x8	
105	0314 0120B	Philips Pan Head Screw - M4x12	
106	0314 0060B	Philips Pan Head Screw - M4x6	
107	0354 0060B	Screw - M4X6	
108	0805 3368	Ball Bearing - 8x16x5mm	
109	1105 0487	Harness Clamp	
110	1105 0489	Harness Clamp - LWS 1316	

19.LASER UNIT (B064/B065)




19.LASER UNIT (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 5403	12P Cable - LVDS LIDB	1
2	B065 5489	Harness (B065)	1
3	B065 1951	Seal - 2	1
4	B065 5477	LD Relay Harness	1
5	B065 5437	LD Control Harness	1
6	B065 1859	LD Unit	1
7	B065 1950	Seal - 1	1
8	B065 1912	Lens Holder - L0	1
9	AC02 4007	Lens - L0	1
10	AC03 0147	1st Mirror	1
11	B065 1915	1st Mirror Holder	1
12	B065 5453	Relay Polygon Motor Harness	1
13	AX06 0250	Polygon Mirror Motor	1
14	B065 1955	Seal - Lens L1	1
15	B065 1952	Seal - 3	1
16	G570 2827	Supporting Plate	1
17	B065 1925	Lens Holder - L2 Right	1
18	B065 1926	Lens Holder - L2 Left	1
19	GC02 5010	Lens L2	1
20	B065 1930	2nd Mirror Holder	2
21	B065 1932	Middle Mirror Holder	1
22	AC03 0148	2nd Mirror	1
23	B065 1953	Seal - 4	1
24	B065 1946	Seal - Shield Glass Holder	1
25	B065 1944	Shield Glass Holder	1
26	B065 1945	Seal - Shield Glass	1
27	B065 1940	Shield Glass Rail	1
28	AC01 5037	Shield Glass	1
29	A293 5310	Sync Detector Board	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0080B	Screw - M3X8	
102	0354 0080B	Screw - M4X8	
103	0451 4010B	Tapping Screw - 4x10	
104	1105 0306	Metal Clamp - Al-4	
105	0353 0060B	Philips Pan Head Screw - M3x6	

20.TANDEM TRAY 1 (B064/B065)




20.TANDEM TRAY 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 6630	Tandem Cover	1
2	B065 6635	Decal - Paper Tray 1	1
3	AW02 0008	Photointerruptor	1
4	A248 6646	Cover Bracket	1
5	B065 6846	Decal - Paper Set - Left	1
6	A293 6647	Support Bracket - End Fence	2
7	A248 6645	Side Plate - Left	1
8	A293 6643	Side Fence - Left Front	1
9	A293 6640	Tray Bottom Plate - Left Front	1
10	A248 6639	Tray Bottom Plate - Left Middle	1
10	A293 6637	Tray Bottom Plate - Left Middle (KOR)	1
11	A293 6642	Tray Bottom Plate - Left Rear	1
12	A096 6678	Decal - Left Paper Set	1
12	AA00 3015	Decal - Left Paper Set (KOR)	1
13	B065 6831	Sensor Bracket	1
14	AA00 2010	Decal - Paper Level	1
15	A293 6644	Side Fence - Left Rear	1
16	A293 6646	Rear Cover - Tandem LCT	1
17	A293 6649	Rear Cover Cushion - Tandem LCT	1
18	A248 6624	Left Back Fence	1
19	B065 6823	Timing Belt Cover	1
20	AB03 3085	Timing Pulley - 15T	1
21	AA14 0685	Shaft - Back Fence Slider	1
22	A248 6623	Slider - Left Back Fence	1
23	B065 6830	Pulley Bracket	1
24	AA04 3271	Timing Belt S3M196T	1
25	A248 6615	Coupling Lever - Left	1
26	A247 5428	DC Harness - Left	1
27	AB03 3084	Timing Pulley - 15T	1
28	5053 0447	Bushing - 6mm	2
29	AA14 0686	Shaft - Timing Pulley	1
30	AB01 9475	Gear - 48T	1
31	AA06 0759	Tension Spring	1
32	B065 6821	Pulley Bracket	1
33	B065 6826	DC Motor Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
34	AX04 0107	DC Motor - 19.2W	1
35	AW02 0056	Photointerruptor - EE-SX4235A-P1	2
36	AB01 3798	Gear - Z18	1
101	1105 0230	Clamp	
102	1105 0328	Harness Clamp - ES-0505	
103	0313 0080B	Philips Pan Head Screw - M3x8	
104	0434 0060B	Pan Head Self-tapping Screw - M4x6	
105	0314 0060B	Philips Pan Head Screw - M4x6	
106	0720 0040B	Retaining Ring - M4	
107	0801 0146	Screw - M4X4	
108	0452 4008B	Binding Self Tapping Screw - M4x8	
109	0452 4010B	Tapping Bind Screw - M4x10	
110	0965 3008W	Tapping Screw With Flat Washer - M3x8	
111	0951 4008B	Philips Screw With Washer - M4x8	

21.TANDEM TRAY 2 (B064/B065)




21.TANDEM TRAY 2 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 6873	Sensor Bracket	1
2	B065 6859	Right Stopper	1
3	AA00 2246	Decal - Caution	1
4	A248 6745	Inner Cover - Tandem LCT	1
5	B065 6875	Protection - Inner Cover	1
6	B065 6877	Decal - Paper Set - Right	1
7	A096 6671	Paper Guide Plate	1
8	A293 6736	Side Fence - Right Front	1
9	B065 6706	Paper Volume Sensor Bracket	1
10	AW02 0120	Photointerruptor - Flat	5
11	5201 2858	Friction Pad	1
12	A096 6677	Decal - Right Paper Set	1
12	AA00 3014	Decal - Right Paper Set (KOR)	1
13	A294 6670	Base - Right Tandem Tray	1
13	A293 6678	Base - Right Tandem LCT (KOR)	1
14	B065 6874	Bracket - Paper Volumesensor	1
15	A248 6738	Side Fence - Right Rear	1
16	A293 6739	Inner Cover - Right Rear	1
17	AA15 3063	Seal - 4x10x70	1
18	AA15 3138	Inner Cover Cushion - Right Rear	1
19	A176 6695	Misfeed Removal Guide	1
20	B065 6672	Tandem Connecting Guide	1
21	AA00 2010	Decal - Paper Level	1
22	A248 6666	Side Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0801 0146	Screw - M4X4	
102	0434 0060B	Pan Head Self-tapping Screw - M4x6	
103	0451 4008B	Philips Tapping Screw - M4x8	
104	0951 4006B	Philips Screw With Washer - M4x6	
105	0314 0060B	Philips Pan Head Screw - M4x6	
106	0452 4008B	Binding Self Tapping Screw - M4x8	
107	0951 4008B	Philips Screw With Washer - M4x8	
108	0453 4008B	Tapping Bind Screw - M4x8	

22.TANDEM TRAY 3 (B064/B065)




22.TANDEM TRAY 3 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A248 6714	DC Solenoid - Front End Fence	1
2	A248 6717	Front Release Lever	1
3	AA06 0758	Tension Spring - Short	2
4	A248 6713	Hook - Tension Sprong	2
5	AA06 0757	Tension Spring - Long	2
6	A293 6713	Front End Fence	1
7	A293 6712	End Fence Guide (A4)	2
8	B065 6881	Detector Bracket	1
9	AW02 0056	Photointerruptor - EE-SX4245A-P1	4
10	A293 6714	Rear End Fence	1
11	B065 6884	Detector Bracket	1
12	A248 6727	DC Solenoid - Rear End Fence	1
13	B065 6811	Side Plate - Right Rear	1
14	A248 6730	Rear Release Lever	1
15	AB03 2058	Wire Pulley - M10	2
16	A248 6695	Guide - Pulley	4
17	AB03 2719	Pulley - M10	2
18	A248 6687	Right Drive Shaft	1
19	A248 6684	Pulley Drive Wire Ass'y	2
20	5053 0223	Bushing - 8mm	2
21	B065 6744	Right Tandem Harness	1
22	B065 6743	Right Connecting Bracket	1
23	B065 6862	Large Lever	1
24	AA13 2203	Spacer - 6mm	1
25	A010 5700	Sensor	1
26	AA16 1129	Cushion - Large	1
27	B065 6851	Right Base - Tandem LCT	1
28	AF02 2105	Roller - Slide Rail	1
29	AA16 1130	Cushion - Small	2
30	B065 6864	Small Lever	1
31	A248 6694	Wire Ring	4
32	B065 6870	Stay - Right Base	2
33	A294 6690	Feeler - Paper Height Sensor	1
34	B065 6717	Paper Volume Shield Plate	1
35	B065 6710	Front Right Side Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A248 6701	Oil Damper	1
37	AB01 3781	Gear - 30Z	1
38	B065 6872	Oil Damper Bracket	1
39	A294 6655	Front Roller - Slide Rail	1
101	0633 0200G	Pin - M3x20	
102	0720 0040B	Retaining Ring - M4	
103	0720 0060B	Retaining Ring - M6	
104	0434 0060B	Pan Head Self- Tapping Screw - M4x6	
105	0313 0080B	Philips Pan Head Screw - M3x8	
106	1105 0267	Harness Clamp - YMC-10-0	
107	1105 0291	Harness Clamp - LWS-3S	
108	1106 0411	Bushing - 11.5mm	
109	0951 3006B	Philips Screw With Flat Washer - M3x6	
110	0313 0120B	Philips Pan Head Screw - M3x12	
111	0452 3006B	Tapping Screw - M3x6	

23.UNIVERSAL TRAY (B064/B065)

Rev. 02/27/2003




23.UNIVERSAL TRAY (B064/B065)

Rev. 02/27/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 6502	Paper Tray Assembly (LT)	1
1	B065 6504	Paper Tray Assembly (A4)	1
2	B065 6576	Coupling Link	1
3	A293 6585	Knob - Paper Size Selection	1
4	AF01 0092	Paper Tray - LT	1
4	AF01 0091	Paper Tray (A4)	1
5	A293 6579	Link Guide	1
6	AA00 2258	Decal - Paper Size - LT	1
6	AA00 2259	Decal - Paper Size - A4	1
7	AA00 2261	Decal - Universal Tray	1
8	B065 6545	Decal - Positioning	2
9	AF01 6079	Left Rear Side Fence	1
10	A096 6553	Side Fence Pad	2
11	B065 6534	Front Side Fence	1
12	A134 2978	Spring Plate	1
13	B065 6538	Positioning Stopper Lever	1
14	B065 6533	Front Side Fence Ass'y	1
15	AF01 7029	Paper End Fence	1
16	A048 2838	Nylon Rivet	2
17	AF01 3005	Bottom Plate Pad	1
18	AF01 1043	Bottom Plate	1
19	AB01 3868	Gear - 16Z	1
20	B065 6591	Paper Tray Holder Base	1
21	AA00 2010	Decal - Paper Level	1
22	B065 6541	Rear Side Fence	1
23	A267 2859	Side Fence Stopper	1
24	A267 2860	Rear Lever Stopper	1
25	A267 2857	Spring Plate - Side Fence	1
26	A176 6570	Paper Stopper	1
27	B065 6540	Rear Side Fence Ass'y	1
28	B065 6571	Paper Size Detection	1
29	A293 6574	Actuator Guide	1
30	B065 6524	Bottom Plate Lift Shaft	1
31	B065 6526	Lift Lever	1
32	A176 6695	Misfeed Removal Guide	1

Index No.	Part No.	Description	Q'ty Per Assembly
33	B065 6581	Paper Tray Holder Stay	1
34	B065 6633	Paper Tray Cover - Short (2nd)	1
34	B065 6632	Paper Tray Cover - Long (3rd)	1
35	A229 6556	Tray Bottom Plate	1
36	B065 6588	Right Support Plate	1
37	B065 6589	Left Support Plate	1
38	B065 6636	Decal - Paper Tray 2	1
38	B065 6637	Decal - Paper Tray 3	1
39	B065 6579	Tapping Screw M4x8	1
101	0451 3008B	Tapping Screw - M3x8	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0453 4008B	Tapping Bind Screw - M4x8	
104	0360 4008B	Screw - M3 X 8	
105	0720 0060E	Retaining Ring - M6	
106	0450 4008B	Tapping Screw - 4x8	
107	0450 3008B	Tapping Screw - M3x8	

24.BY-PASS FEED TRAY (B064/B065)




24.BY-PASS FEED TRAY (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 2743	Front Shaft - By-pass	1
2	5206 2686	Snap Ring	1
3	B065 2729	Paper End Feeler	1
4	B065 2721	Paper Feed Guide Plate - By-pass	1
5	B065 2660	Paper Feed Cover	1
6	B065 2662	Magnet Catch Bracket	1
7	A096 2780	Feed Guide Gear	2
8	B065 2730	By-pass Table	1
9	B065 2746	Decal - Paper Set	1
10	B065 2737	Front Side Fence - By-pass	1
11	B351 4135	Magnet Catch - Original Table	1
12	B065 2735	Rear Side Fence - By-pass	1
13	B065 2732	Manual Feed Table	1
14	B065 2738	Front Support Stay - By-pass	1
15	B065 2740	Rear Support Stay - By-pass	1
16	B065 2741	Sensor Bracket	1
17	AB01 3492	Gear - 16Z	1
18	A096 5335	Paper Size Switch	1
19	B065 2733	By-pass Table Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0453 3006B	Tapping Screw - M3x6	
103	0452 3008H	Binding Self-tapping Screw - 3x8	
104	0451 4008B	Philips Tapping Screw - M4x8	

25.PAPER FEED UNIT 1 (B064/B065)




25.PAPER FEED UNIT 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AF03 0051	Pick-up Roller	1
2	5447 2681	Snap Ring	2
3	AF03 1065	Paper Feed Roller	1
4	B065 6350	Pick-up Gear Cover	1
5	AB01 1465	Idler Gear	1
6	B065 6357	Pick-up Arm	1
7	AA08 2118	Bushing - M6	2
8	AA06 0898	Spring	1
9	AA14 0828	Feed Roller Shaft	1
10	B065 6445	Feed Lever	1
11	AA06 0899	Spring	1
12	B065 6358	Paper Feed Sensor Bracket	1
13	AW01 0098	Photointerruptor	3
14	B065 6364	Feed Stay	1
15	B065 6375	Paper Feed Unit Stay	1
16	AB01 7617	Gear - 21Z/38Z	1
17	B065 6318	Pick-up Solenoid	1
18	AA06 0897	Spring	1
19	B065 6488	Upper Paper Feed Harness	1
20	B065 6487	Lower Paper Feed Harness	1
21	B065 6345	Paper End Sensor Bracket	1
22	AW02 0056	Photointerruptor - EE-SX4235A-P1	1
23	B065 6339	Feed Guide Plate	1
24	AF02 0562	Transport Roller	1
25	AB01 1466	Gear - 35Z	1
26	B065 6353	Feed Gear Cover	1
27	B065 6366	Drive Bracket	1
28	5894 2540	Arm Screw	1
29	B065 6457	Driven Pressure Lever	1
30	AA06 0896	Spring	1
31	B065 6334	Heat Sink Base	1
32	B065 6337	Heat Sink	1
33	B065 6338	Heat Sink Sheet	1
34	AA06 3889	Heat Sink Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	1105 0328	Harness Clamp - ES-0505	
103	1105 0511	Harness Clamp - LWS-0306ZC	
104	0353 0040B	Screw - M3X4	
105	0720 0040E	Retaining Ring - M4	
106	0720 0060E	Retaining Ring - M6	
107	0742 3808	Ball Bearing - 8x16x5	
108	1102 6249	Relay Connector - 6P	
109	1102 6251	Connector - 8P	
110	1102 6252	Connector - 9P	
111	1105 0542	Harness Clamp - MSBS-1207	

26.PAPER FEED UNIT 2 (B064/B065)

Rev. 02/27/2003




26.PAPER FEED UNIT 2 (B064/B065)

Rev. 04/22/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 6372	Guide Plate	1
2	AF02 2149	Transport Roller	1
3	AA08 0327	Bushing - M4	2
4	AA14 0829	Driven Shaft	1
5	B065 6453	Transport Roller Lever	1
6	AA14 3402	Screw - Scale	2
7	B065 6454	Driven Release Lever	1
8	B065 6455	Driven Pressure Lever	1
9	B065 6317	Relay Shaft	1
10	AA08 2118	Bushing - M6	4
11	AB01 1469	Gear - 19Z	1
12	B065 6330	Rear Side Plate - Paper Feed	1
13	AB01 1470	Gear - 18Z	1
14	B065 6452	Tray Link Guide	1
15	B065 6346	Paper Tray Link	1
16	AA14 3718	Stepped Screw - M4	1
17	AA06 0901	Spring	1
18	AA04 3575	Timing Belt	1
19	AB01 7618	Pulley - 30Z/24Z	1
20	B065 6456	Vertical Transport Link	1
21	AA06 0900	Spring	1
22	AB03 0734	Pulley - 30Z	1
23	AB01 1490	Gear - 38Z	1
24	AB01 1491	Gear - 21Z	1
25	B065 6306	Reverse Drive Shaft	1
26	AB01 1471	Reverse Gear	1
27	AB01 1391	Driven Reverse Gear - 21Z	1
29	B065 6320	Reverse Roller - Pressure Release	1
30	B065 6333	Reverse Haousing	1
31	B065 6371	Support Guide Plate	1
32	B065 6336	Front Side Plate - Paper Feed	1
33	B065 6416	Ball Bearing - 6x12x4.5	1
34	B065 6307	Reverse Driven Shaft	1
35	B065 6399	Torquelimiter	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	AF03 2050	Separation Roller	1
37	5447 2681	Snap Ring	1
38	B065 6323	Paper Feed Motor	1
39	B065 6394	Motor Bracket	1
40	AA06 0904	Spring	1
41	AB03 0733	Pulley - 20T	1
42	AA04 3576	Timing Belt	1
43	B065 6415	Motor Base	1
101	0353 0040B	Screw - M3X4	
102	0573 0030E	Hexagon Headless Set Screw - M3x3	
103	0720 0040E	Retaining Ring - M4	
104	0451 4008B	Philips Tapping Screw - M4x8	
105	1105 0522	Edge Saddle - Les0510	
106	1105 0328	Harness Clamp - ES-0505	
107	0720 0060E	Retaining Ring - M6	
108	0450 4008B	Tapping Screw - 4x8	

27.VERTICAL TRANSPORT (B064/B065)




27.VERTICAL TRANSPORT (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 6200	Paper Feed Unit	3
2	B065 6361	Relay Guide Plate - Paper Feed	1
3	B065 6489	Relay Unit Harness	1
4	B065 6323	Paper Feed Motor	1
5	AF02 0562	Transport Roller	1
6	AB01 1466	Gear - 35Z	1
7	AA04 3575	Timing Belt	1
8	AB01 7619	Gear - 24Z/40Z	1
9	B065 6472	Relay Unit Guide Plate	1
10	AA06 3878	Spring	1
11	B065 6429	Release Cover - Vertical Transport	1
12	A029 2984	Decal - Grip	1
13	B065 6426	Release Lever - Vertical Transport	1
14	B065 6428	Release Button - Vertical Transport	1
15	B065 6427	Release Lever - Vertical Transport	1
16	5201 1796	Stepped Screw - M4	3
17	B065 6403	Front Side Plate - Vertical Transpo	1
18	B065 6405	Guide Plate - Vertical Transport	1
19	B065 6404	Rear Side Plate - Vertical Transpor	1
20	AF02 0295	Vertical Driven Roller	4
21	AA08 0241	Bushing - M4	8
22	AA06 3487	Spring - 10mm	8
23	B065 6407	Transport Pressure Plate	1
24	AA14 3715	Stepped Screw - M5	4
25	B065 6402	Transport Pressure Plate	1
26	A096 5528	Micro Switch Sheet	1
27	B065 6122	Micro Switch Bracket	1
28	A423 4433	Spring	1
29	A423 4432	Shoulder Screw - M2.5	1
30	B065 6078	LCT Stay	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	1204 2521	Micro Switch	
103	0353 0040B	Screw - M3X4	
104	0720 0060E	Retaining Ring - M6	
105	0742 3808	Ball Bearing - 8x16x5	
106	1102 6249	Relay Connector - 6P	
107	1105 0511	Harness Clamp - LWS-0306ZC	

28.PAPER REGISTRATION 1 (B064/B065)




28.PAPER REGISTRATION 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 2763	Relay Registration Harness	1
2	AW01 0098	Photointerruptor	1
3	B065 2621	Sensor Bracket	1
4	B065 2620	Paper Dust Removal Case	1
5	AA15 2441	Case Seal	4
6	B065 2608	Development Connector Bracket	1
7	B065 2614	Front Upper Guide Plate	1
8	A096 2622	Front Lower Registration Guide	1
9	B065 2682	Paper Feed Stay	1
10	5447 2681	Snap Ring	2
11	AF03 1066	Paper Feed Roller (By-pass)	1
12	AB01 1478	Gear - 18Z	1
13	AA08 2116	Bushing - M8	3
14	AA06 0888	Spring	1
15	B065 2688	Pick-up Roller Arm	1
16	5447 2706	Gear - 15T	1
17	AF03 0050	Pick-up Roller (By-pass)	1
18	AA14 0819	Feed Roller Shaft	1
19	AA06 0887	Spring	1
20	B065 2690	Pick-up Roller Solenoid	1
21	AA08 3019	Bushing	1
22	AX20 0242	Magnetic Clutch	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1102 6247	Connector - 4P	
102	1102 6260	Relay Connector - 3P	
103	1102 6279	Connector - 3P	
104	0451 4008B	Philips Tapping Screw - M4x8	
105	1105 0511	Harness Clamp - LWS-0306ZC	
106	0720 0060E	Retaining Ring - M6	
107	0805 0088	Retaining Ring - M6	

29.PAPER REGISTRATION 2 (B064/B065)




29.PAPER REGISTRATION 2 (B064/B065)

Rev. 02/28/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	5205 2697	Bushing - Upper Registration Roller	2
2	5442 2754	Spring - Registration Roller	2
3	A247 2800	Ball Bearing - 8x12x5	2
4	AA13 2025	Spacer - 1x8x12	2
5	B065 2627	Lower Registration Roller	1
6	B065 2623	Upper Registration Roller	1
7	A096 2612	Lower Registration Guide	1
8	B065 2701	Lower Guide Plate - Bypass	1
9	A053 2916	Friction Pad - B	1
10	G011 1058	Snap Ring	3
11	AB01 7608	Reverse Gear	1
12	B065 2713	Drive Reverse Shaft	1
13	AA08 2118	Bushing - M6	3
14	5447 2681	Snap Ring	1
15	AF03 2050	Separation Roller	1
16	B065 6399	Torquelimiter	1
17	B065 2714	Separation Roller Shaft	1
18	B065 2699	Separation Roller Stay	1
19	AB01 7609	Reverse Gear	1
20	AB01 4077	Registration Roller Gear	1
21	AA04 3944	Timing Belt	1
22	AW01 0098	Photointerruptor	1
23	B065 2708	Middle Sensor Bracket	1
24	B065 2707	Paper End Sensor Bracket	1
25	AW02 0056	Photointerruptor - EE-SX4235A-P1	1
26	AA06 0911	Spring	1
27	B065 2709	Reverse Pressure Lever	1
28	B065 2752	Motor Bracket	1
29	B065 6323	Paper Feed Motor	1
30	AB01 7606	Gear - 24Z/46Z	1
31	B065 2703	Bracket - Brake Peen	1
32	B478 3505	Timing Belt - B40S2M84	1
33	AB03 0578	Timing Pulley - 18Z	1
34	AB03 0577	Timing Pulley - 20Z	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040E	Retaining Ring - M4	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0720 0060E	Retaining Ring - M6	
104	0632 0100G	Pin - 2x10mm	
105	0805 3145	Ball Bearing - 6x12x4mm	
106	1105 0487	Harness Clamp	
107	1105 0511	Harness Clamp - LWS-0306ZC	
108	1105 0522	Edge Saddle - LES0510	
109	0453 3006B	Tapping Screw - M3x6	

30.PAPER REGISTRATION 3 (B064/B065)




30.PAPER REGISTRATION 3 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5205 2697	Bushing - Upper Registration Roller	2
2	AA06 3254	Driven Roller Spring	2
3	A229 2717	Lock Lever	1
4	AA00 1213	Decal - B2	1
5	AA14 0486	Lock Shaft	1
6	5443 2668	Bushing - 4x6x7mm	2
7	A229 2655	Read Rock	1
8	AA06 6211	Rear Lock Spring	1
9	B065 2647	Registration Guide Plate	1
10	A096 2633	Front Lock	1
11	AA08 2116	Bushing - M8	2
12	AF02 0564	Connecting Roller	1
13	AB01 1457	Transport Roller Gear	1
14	A469 2123	Rubber Cushion - 1x10x10mm	2
15	B065 2671	Duplex Exit Guide Plate	1
16	AA08 0034	Bushing - 4x5x7	2
17	AA06 3255	Exit Roller Spring	2
18	A294 2678	Roller - Duplex Exit	1
19	AF02 2110	Transport Driven Roller	1
20	B065 2665	Relay Guide Plate	1
21	B065 2762	Relay Paper Feed Harness	1
22	AW02 0120	Photointerruptor - Flat	1
23	B065 2675	LCT Guide Plate	1
24	A048 2838	Nylon Rivet	2
25	AA16 2079	Cushion	1
26	B065 2673	Upper Exit Guide Plate	1
27	B065 2761	By-pass Harness	1
28	AB03 0722	Pulley - 13mm	2
29	AA06 0890	Spring	1
30	B065 2655	Guide Plate Solenoid	1
31	B065 2754	Tightener Bracket	1
32	AB01 7607	Gear - 22Z/39Z	1
33	B065 2607	Front Support Plate	1
34	B065 2605	Front Paper Feed Side Plate	1
35	B065 2600	Rear Paper Feed Side Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1102 6246	Relay Connector - 4P	
102	1102 6257	Relay Connector - 14P	
103	1102 6258	Relay Connector - 15P	
104	1105 0328	Harness Clamp - ES-0505	
105	1105 0487	Harness Clamp	
106	1105 0511	Harness Clamp - LWS-0306ZC	
107	1105 0518	Edge Saddle - LES-1010	
108	1105 0522	Edge Saddle - LES0510	
109	0720 0040B	Retaining Ring - M4	
110	0453 3006B	Tapping Screw - M3x6	
111	0720 0030E	Retaining Ring - M3	
112	0720 0060E	Retaining Ring - M6	
113	0720 0040E	Retaining Ring - M4	
114	0742 3808	Ball Bearing - 8x16x5	
115	0451 4008B	Philips Tapping Screw - M4x8	

31.TONER HOPPER SECTION (B064/B065)

Rev. 02/27/2003




31.TONER HOPPER SECTION (B064/B065)

Rev. 02/27/2007

Index No.	Part No.	Description	Q'ty Per Assembly
1	A293 3231	Shield Holder	1
2	B065 3309	Toner Bottle Drive Bracket	1
3	AA06 0291	Spring	1
4	A229 3240	DC Motor	1
5	AA14 5817	Idler Shaft - Toner Bottle	1
6	B065 3311	Toner Bottle Turn Bracket	1
7	A229 3263	Outer Shutter Shield	1
8	A229 3261	Outer Shutter	1
9	A229 3262	Inner Shutter	1
10	A229 3266	Upper Shutter Shield	1
11	A229 3264	Shutter Lever	1
12	A229 3285	Shutter Cover	1
13	A229 3219	Rubber Bushing - Toner Supply Unit	1
14	B065 3304	Bottle Holder	1
15	A096 3224	Bottle Roller	2
16	B065 3307	Toner Bottle Gear	1
17	A293 3234	Shield Plate - Toner Bottle	1
18	A293 3230	Toner Bottle Chuck	1
19	A293 3227	Toner Slider	1
20	A134 3216	Screw	1
21	AA14 3758	Settepped Screw	1
22	A229 3232	Chuck Roller	1
23	A134 3179	Chuck Shaft	1
24	AA06 3366	Chuck Spring	1
25	A293 3220	Toner Bottle Stopper	1
26	A293 3282	Toner Bottle Pawl	1
27	AA06 3575	Toner Bottle Spring	1
28	B065 3273	Upper Stay	1
29	B065 3316	Hinge Bracket	1
30	A222 2724	External Circlip - Mm8	1
31	B065 3271	Lower Stay	1
32	A229 3258	Toner Catchpan	1
33	AA13 2024	Spacer - M6	1
34	A229 3243	Motor Joint Gear	1
35	A229 3242	Toner Bottle Joint Gear	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A134 3192	Seal - Toner Bottle	1
37	AA00 1394	Decal - Toner Supply	1
38	A229 3217	Retaining Ring Seal	1
39	B065 3301	Drive Bottle	1
41	B065 3342	Decal – Toner Supply	1
101	0450 3008B	Tapping Screw - M3x8	
102	0800 0072	Philips Pan Head Screw - M2.6x4	
103	0720 0040B	Retaining Ring - M4	
104	1105 0229	Clamp	
105	0451 4008B	Philips Tapping Screw - M4x8	
106	0805 0072	CS Ring	
107	0450 3006B	Tapping Screw - M3x6	
108	0354 0080B	Screw - M4X8	

32.TONER SUPPLY UNIT (B064/B065)




32.TONER SUPPLY UNIT (B064/B065)

Rev. 02/28/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 3161	Toner Separation Case	1
2	B065 3122	Toner Separation Joint Seal	1
3	B065 3123	Rear Toner Separation Joint Seal	1
4	B065 3125	Toner Separation Drive Shaft	1
5	5053 0447	Bushing - 6mm	2
6	B065 3120	Right Upper Case Seal	1
7	B065 3720	Toner Collection Coil - Exit	1
8	A229 3154	Case Seal	1
9	B065 3138	Idle Gear	1
10	B065 3139	Toner Collection Gear	1
11	AW31 0003	Toner End Sensor	1
12	A096 3181	Slitter	1
13	AA15 0361	Slitter Cover Seal	1
14	B065 3146	Nut	1
15	B065 3152	Lower Front Case Seal - Rear	2
16	B065 3153	Lower Filter Case Filter	1
17	B065 3151	Lower Right Case Seal	1
18	B065 3111	Toner Supply Unit	1
19	B065 3140	Upper Cover	1
20	B065 3141	Exit Toner Pile	1
21	B065 3143	Toner Separation Spring	1
22	B065 3142	Toner Separation Shutter	1
23	A096 3175	Bushing 8x14x8	1
24	AA06 0291	Spring	2
25	AB01 3748	Joint Gear - 15Z	2
26	AB01 3747	Gear - 16Z	1
27	AB01 3749	Gear - 15Z	1
28	A096 3176	Bushing - 6x12x8.5	1
29	B065 3121	Left Upper Case Seal	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 3008W	Binding Self Tapping Screw - M3x8	
102	0727 0060B	Retaining Ring C - 6	
103	0720 0060B	Retaining Ring - M6	
104	0720 0040B	Retaining Ring - M4	
105	0450 4008B	Tapping Screw - 4x8	
106	0727 0060E	Retaining Ring - M6	
107	0314 0060B	Philips Pan Head Screw - M4x6	
108	0354 0080B	Screw - M4X8	

33.DEVELOPMENT UNIT 1 (B064/B065)




33.DEVELOPMENT UNIT 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 3050	Development Unit	1
2	B065 3095	Development Guide Rail	1
3	B065 3099	Front Drum Seal	1
4	B065 3091	Entrance Seal	1
5	B065 3082	Development Bias Plate	1
6	B065 3100	Rear Drum Seal	1
7	B065 3071	Development Knob	1
8	B065 3076	Gear - 41Z	1
9	B065 3065	Toner Sensor Guide	1
10	AW23 0015	Toner Density Sensor	1
11	B065 3098	Gear - 17Z	1
12	B065 3073	Gear - 31Z	1
13	AB01 3790	Gear - 25Z	1
14	B065 3096	Gear - 20Z	1
15	B065 3081	Gear - 21Z	1
16	B065 3079	Ball Bearing Bracket	1
17	AA01 2060	Development Filter	1
18	A096 3141	Development Filter Case	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0060B	Philips Pan Head Screw - M3x6	
102	0951 4008B	Philips Screw With Washer - M4x8	
103	0452 3010B	Tapping Bind Screw - M3x10	
104	0720 0030E	Retaining Ring - M3	
105	0354 0080B	Screw - M4X8	

34.DEVELOPMENT UNIT 2 (B064/B065)




34.DEVELOPMENT UNIT 2 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 3062	Development Roller	1
2	B065 3080	Ball Bearing - 12x21x5	1
3	B065 3069	Bushing - 8mm	4
4	B065 3077	Development Roller Adjuster	1
5	AA14 3426	Stopped Screw - M4x17	2
6	AA08 0152	Bushing - 4x12x13	2
7	B065 3060	Lower Development Casing	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0720 0030E	Retaining Ring - M3	
103	0354 0120B	Screw - M4X12	


35.PCU 1 (B064/B065)



35.PCU 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 2410	Drum Shaft Knob	1
2	B065 3258	Development Drum Stay	1
3	AD00 4091	Charge Corona Unit	1
4	A096 2053	Cleaner Motor Cover	1
5	AA08 0147	Front Bushing	1
6	A176 2054	Grounding Plate	1
7	A096 2063	Corona Wire Cleaner	1
8	A096 2062	Wire Cleaner Slider	1
9	A096 2065	Slider Ring	1
10	A176 2061	Screw Shaft	1
11	AA16 1105	Cleaner Cushion	1
12	AA08 0148	Rear Bushing	1
13	AD02 3106	Charge Corona Casing	1
14	AA06 3248	Charge Terminal Spring	1
15	AA06 3249	Grid Terminal Spring	1
16	AD02 2285	Rear End Block	1
17	AD02 2307	Cover - Rear End Block	1
18	A096 2051	Rear Grid Anchor	1
19	AD02 0053	Charge Corona Wire	1
20	AA06 2284	Pressure Spring	1
21	AD02 2283	Front End Block	2
22	AA16 1119	Cushion - Wire	1
23	AX04 0061	Cleaner Motor - DC 0.5W	1
24	AB01 0087	Gear - 20Z	1
25	AD02 2306	Cover - Front End Block	1
26	A134 2363	Terminal Plate	1
27	A096 2052	Front Grid Anchor	1
28	A096 2057	Charge Corona Grid	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0354 0080B	Screw - M4X8	
102	0720 0025B	Retaining Ring - M2.5	
103	0965 3008B	Tapping Screw With Washer - M3x8	
104	0971 4006A	Philips Polycarbonate Screw - M4x6	



36.PCU 2 (B064/B065)

Rev. 02/14/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	A293 2418	Upper Unit Cover	1
2	B065 2391	Upper PCU Casing	1
3	B065 2494	Upper PCU Harness	1
4	A096 5320	Quenching Lamp	1
5	A096 2301	Grounding Plate	1
6	AW33 0003	Drum Potential Sensor	1
7	B065 2392	Receptacle	1
8	B065 2270	Upper PCU Ass'y	1
9	AA01 2060	Development Filter	1
10	B065 2426	Pressure Release Lever	1
11	AA06 0891	Spring	1
12	AB01 1461	Toner Recycling Connecting Gear	1
13	AB01 1462	Toner Recycling Gear	2
14	B065 2377	Toner Recycling Connecting Shaft	1
15	AA08 2122	Bushing	1
16	B065 2371	Drum Stay	1
18	AA08 0176	Bushing	1
19	AA15 3157	Joint Seal	1
20	B065 2400	Toner Recycling Joint	1
21	B065 2401	Toner Recycling Pipe	1
22	B065 2399	Joint - Toner Separation	1
23	B065 2406	Toner Separation Shutter	1
24	AD04 3078	Toner Collection Coil	1
25	B064 9510	Drum	1
26	B065 1957	Shield Glass Cover	1
27	B065 2423	Release Cam - Cleaning Blade	1
28	B065 2424	Cam Spring	1
29	AA13 2208	Spacer - M6	4
30	AA13 0042	Sleeve	1
31	A376 4131	Cushion T1	1
32	B065 2263	PCU Lower Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0354 0080B	Screw - M4X8	
102	0452 3008B	Tapping Screw - M3x8	
103	0951 3006B	Philips Screw With Flat Washer - M3x6	
104	0451 4008B	Philips Tapping Screw - M4x8	
105	0720 0040E	Retaining Ring - M4	
106	1105 0534	Clamp	
107	0451 4014B	Tapping Screw - M4x14	

B064/B065




37.PCU 3 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AD04 3077	Toner Collection Coil	1
2	B065 2421	Agitator Shaft	1
3	AA08 2121	Toner Collection Coil Bushing	2
4	B065 2428	Agitator Gear	1
5	B065 2425	Brush Roller Gear	1
6	AA08 2119	Roller Bushing	1
7	B065 2347	Cleaning Brush	1
8	B065 2366	Front Shaft	1
9	AA13 2024	Spacer - M6	1
10	AA08 2101	Bushing - 6x10x6	1
11	AA08 2094	Bushing - Brush Roller	1
12	AA15 2431	Front Drum Seal	1
13	AA15 3085	Inner Case Seal	2
14	AA15 3088	Cleaning Entrance Seal - 3x345x2	1
15	B065 2300	Lower PCU Casing	1
16	B065 2353	Blade Bracket	1
17	AB01 1459	Toner Collection Coil Gear	1
18	A294 3572	Rear Drum Seal	1
19	B065 2413	Entrance Transfer Stay	1
20	AB01 7612	Gear	1
21	AB01 1460	Idler Gear	1
22	B065 2427	Cam - Blade	1
23	B065 2422	Agitator Cleaning	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0951 3006B	Philips Screw With Flat Washer - M3x6	
102	0452 3008B	Tapping Screw - M3x8	
103	0452 3010B	Tapping Bind Screw - M3x10	
104	0720 0040E	Retaining Ring - M4	
105	0951 3008B	Philips Screw With Flat Washer - M3x8	

38.PCU 4 (B064/B065)




38.PCU 4 (B064/B065)

Rev. 01/31/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	G020 3566	Nut - 2.4mm	2
2	A048 2276	Ring - Transport Bracket	2
3	AA06 0892	Pick-off Pawl Spring	2
4	AD02 5024	Pick-off Pawl	2
5	AA14 3523	Shoulder Screw - M3	2
6	B065 2337	Pick-off Pawl Holder	1
7	AB01 7611	Pick-off Pawl Cam	1
8	AD04 1083	Cleaning Blade	1
9	AA13 2208	Spacer - M6	1
10	AA06 3610	Spring - 4060mN	1
11	B065 2316	Front Blade Seal	1
12	B065 2314	Blade Bracket	1
13	B065 2317	Rear Blade Seal	1
14	AA08 2120	Bushing	1
15	B065 2386	Middle PCU Casing	1
16	B065 2389	Shaft Bracket	1
17	B065 2342	Pick-off Pawl Shaft	1
18	AB01 1459	Toner Collection Coil Gear	2
19	AA08 2101	Bushing - 6x10x6	1
20	B065 2495	Lower PCU Harness	1
21	A134 5251	ID Sensor	1
22	B065 2364	Pick-off Pawl Positioning Plate	1
23	B065 2361	Entrance Seal Holder	1
24	B065 2362	Cleaning Entrance Seal	1
25	B065 2381	Grounding Plate	1
26	B065 2344	Pick-off Pawl Bracket	1
27	AB01 1460	Idler Gear	1
28	AA08 2121	Toner Collection Coil Bushing	1
29	B065 2369	Grounding Plate - Entrance Seal	1
30	AA06 3576	Spring	1
31	AA14 3432	Stepped Screw - M3	1
32	B065 2358	Bracket Grounding Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0452 3008B	Tapping Screw - M3x8	
103	0452 3010B	Tapping Bind Screw - M3x10	
104	0951 3006B	Philips Screw With Flat Washer - M3x6	
105	0951 3008B	Philips Screw With Flat Washer - M3x8	

39.TRANSFER BELT UNIT 1 (B064/B065)




39. TRANSFER BELT UNIT 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B065 3850	Transfer Unit	1
1	B065 3818	Transfer Unit Guide Plate	1
2	B065 3873	Toner Collection Gear	1
3	A229 3861	Front Arm	1
4	A229 3875	Drive Electrode	1
5	A293 3899	Transfer Belt - Mojito Service	1
6	B065 3866	Drive Roller	1
7	A229 3862	Rear Arm	1
8	B065 3872	Transfer Unit Joint	1
9	B065 3870	Bias Roller	1
10	B065 3875	Terminal	1
11	B065 3874	Electrode Plate	1
12	B065 3868	Pressure Arm	2
13	A229 3865	Transport Driven Roller	1
14	B065 3865	Transfer Belt Frame	1
15	B065 3876	Bias Electrode Plate	1
16	B065 3878	Bias Terminal	1
17	B065 3950	Grounding Bracket	1
18	H053 1150	Stepped Screw - Locking	1
19	AA06 3310	Guide Plate Spring	1
20	B065 3942	Guide Plate	1
21	B065 3947	Anti-static Plate	1
22	B065 3945	Entrance Seal Holder	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0623 0120E	Spring Pin - M3x12	
103	0633 0180G	Parallel Pin - 3x18mm	
104	0720 0060E	Retaining Ring - M6	
105	0951 3008B	Philips Screw With Flat Washer - M3x8	
106	0951 4014B	Philips Screw With Washer - M4x14	

40.TRANSFER BELT UNIT 2 (B064/B065)




40. TRANSFER BELT UNIT 2 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AD04 1076	Cleaning Roller Cleaning Blade	1
2	B065 3962	Spring Plate	2
3	B065 3965	Lever Shaft	1
4	B065 3963	Lever	1
5	B065 3964	Bushing	1
6	B065 3961	Shaft	1
7	AA06 3877	Spring	1
8	A293 3916	Cleaning Roller - Transfer Belt	1
9	AA13 2024	Spacer - M6	1
10	B065 3911	Toner Collection Coil - Transfer	1
11	AD04 7025	Exit Seal	1
12	A229 3934	Tape	1
13	B065 3914	Transfer Agitator	1
14	AA08 2101	Bushing - 6x10x6	2
15	B065 3918	Toner Collection Gear Coil	2
16	B065 3928	Cleaning Roller Terminal	1
17	A229 3910	Front Bushing	1
18	B065 3922	Electrode Plate Cover	1
19	B065 3920	Idle Gear - 1	1
20	B065 3921	Idle Gear - 2	1
21	B065 3906	Transfer Unit Casing	1
22	AA08 2058	Bushing - 6x10x9mm	1
23	A229 3911	Rear Bushing	1
24	AB01 4176	Cam Gear - 37z	1
25	B065 3955	Entrance Guide Plate	1
26	AZ32 0107	Transfer Power Pack	1
27	B065 3976	Transfer Harness	1
28	B065 3966	Solenoid	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0951 3006B	Philips Screw With Flat Washer - M3x6	
102	0450 3008B	Tapping Screw - M3x8	
103	1105 0487	Harness Clamp	
104	0951 3004W	Philips Screw With Flat Washer - M3	

41.FUSING UNIT 1 (B064/B065)




41.FUSING UNIT 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 4255	Insulator	1
2	B065 4274	Decal - Misfeed Removal	1
3	B065 4481	Decal - Exit	1
4	B065 4268	Fusing Inner Cover	1
5	B065 4167	Decal - Fusing Knob	1
6	AG05 0092	Knob: Fusing	1
7	B065 4200	Web Unit	1
8	B065 4207	Web Shaft	2
9	AE03 1026	Bushing - Oil Supply Roller	2
10	AA06 3886	Spring	2
11	B065 4212	Stopper Bracket	1
12	B065 4211	Pressure Roller Gear	1
13	B065 4217	Web Bracket	1
14	AE04 0038	Cleaning Web Pressure Roller	1
15	B065 4202	Web Bracket	1
16	AE04 5046	Cleaning Web	1
17	B065 4242	Rolling Drive Gear	1
18	B065 4239	Web Drive Shaft	1
19	AE03 1036	Bushing - 6mm	4
20	B065 4222	Gear - 37Z	5
21	B065 4241	Gear	1
22	B065 4247	Brake Pad	1
23	B065 4232	Feeler Guard Bracket	1
24	B065 4246	Spring Plate	1
25	B065 4226	Drive Bracket	1
26	B065 4231	Web Cover	1
27	AX04 0136	Cleaning Motor	1
28	B065 4225	Motor Plate Bracket	1
29	AW02 0120	Photointerruptor - Flat	1
30	B065 4223	Motor Gear	1
31	B065 4244	Gear - 23Z	1
32	B065 4238	Gear - 50Z	1
33	B065 4235	Web Idle Gear	1
34	B065 4248	Web Harness	1
35	B065 4234	Stopper Gear	2

Index No.	Part No.	Description	Q'ty Per Assembly
36	AA06 3851	Pressure Spring	1
37	B065 4221	Feeler Spring	1
38	B065 4219	Web End Feeler	1
39	B065 4251	Positioning Plate - Web Unit	1
101	0360 4006B	Hexagonal Head Screw - M4x6	
102	0951 4008B	Philips Screw With Washer - M4x8	
103	0720 0040E	Retaining Ring - M4	
104	0720 0030E	Retaining Ring - M3	
105	0954 4008B	Philips Screw - M4x8	
106	0353 0060B	Philips Pan Head Screw - M3x6	
107	1105 0511	Harness Clamp - LWS-0306ZC	
108	0354 0060B	Screw - M4X6	
109	0354 0080B	Screw - M4X8	
110	0453 3008B	Bind Tapping Screw - M3x8	

42.FUSING UNIT 2 (B064/B065)




42.FUSING UNIT 2 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 4017	Fusing Unit - 120V	1
1	B065 4027	Fusing Unit - 230V	1
1	B065 4019	Fusing Unit (TWN)	1
2	B065 4133	Lower Fusing Entrance Plate - 120V	1
2	B065 4135	Lower Fusing Entrance Plate - 230V	1
3	B065 4116	Lower Fusing Cover	1
4	B065 4138	Side Plate Cover	1
5	B065 4175	Front Fusing Grip	1
6	B065 4176	Grip Sheet	1
7	B065 4117	Upper Fusing Cover	1
8	AA06 0894	Spring	1
9	B065 4185	Exit Plate	1
10	AA14 3037	Development Cover Screw	2
11	B065 4398	Slider Cover	1
12	AA06 0539	Stripper Pawl Spring	5
13	AA06 0916	Slider Spring	1
14	H084 1501	Trast Screw	2
15	B065 4397	Release Slider	1
16	B065 4188	Front Lock Pawl	1
17	B065 4184	Stripper Pawls Grip	1
18	AA08 0274	Bushing	2
19	B065 4391	Guide Plate Bracket	1
20	AA06 6352	Spring	1
21	B065 4189	Rear Lock Pawl	1
22	AA14 0824	Stripper Pawl Release Shaft	1
23	A096 4319	Exit Roller Holder	2
24	AF04 0561	Fusing Exit Roller - Upper	2
25	AA06 0914	Stripper Pawls Spring	10
26	AA14 9746	Stripper Shaft	5
27	AE04 4043	Hot Roller Stripper	5
28	B065 4390	Fusing Exitguide Plate	1
29	B065 4129	Side Plate Sheet	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0360 4006B	Hexagonal Head Screw - M4x6	
102	0720 0030E	Retaining Ring - M3	

43.FUSING UNIT 3 (B064/B065)




43.FUSING UNIT 3 (B064/B065)

Rev. 02/27/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	AE03 2014	Bushing - 30x35x13.5	2
2	AE03 0017	Ball Bearing - 35x50x10	2
3	B065 4124	Front Heater Holder	1
4	A413 1670	Antistatic Brush	1
5	B065 4132	Middle Thermistor Cover	1
6	AW10 0075	Thermistor	1
7	B065 4130	Thermostat Housing - Middle	1
8	B065 4142	Upper Fusing Stay	1
9	B065 4127	Thermostat Housing	1
10	AW11 0026	Thermostat - 180°C	1
11	AW11 0027	Thermostat - 179°C	1
12	B065 4150	Front Harness	1
13	B065 4121	Thermostat Terminal	1
14	B065 4151	Rear Harness	1
15	AW10 0076	Thermistor: Inner Back	1
16	B065 4131	Rear Thermistor Bracket	1
17	B065 4170	Rear Heater Holder	1
18	B065 4159	Harness Holder	1
19	B065 4157	Connector Bracket	1
20	B065 4155	Fusing Harness (120V)	1
20	B065 4156	Fusing Harness (230V)	1
21	A247 4249	Connector - 3P	1
22	AB01 2316	Fusing Gear	1
23	AE01 1075	Hot Roller	1
24	AX44 0163	Fusing Lamp - 120V 550W	2
24	AX44 0164	Fusing Lamp - 230V 550W	2
25	B065 4180	Spacer - 16mm	2
26	AE03 0018	Ball Bearing - 12x28x8	2
27	AE02 0112	Pressure Roller	1
28	AA14 0823	Pressure Roller Shaft	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0954 3012B	Screw - M3X12	
102	0954 3006B	Screw - M3X6	
103	0360 4006B	Hexagonal Head Screw - M4x6	
104	0954 3010B	Philips Screw - M3x10	
105	0951 3005B	Philips Screw With Flat Washer M3x5	
106	0313 0080B	Philips Pan Head Screw - M3x8	
107	0314 0100B	Philips Pan Head Screw - M4x10	
108	0313 0050B	Philips Pan Head Screw - M3x5	
109	0725 0120E	Retaining Ring C - M12	
110	0725 0300E	Retaining Ring C - M30	

44.FUSING UNIT 4 (B064/B065)




44.FUSING UNIT 4 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA06 0893	Spring	2
2	B065 4145	Front Release Lever	1
3	B065 4177	Front Pressure Lever	1
4	A232 3566	Ball Bearing - 8x16x5	2
5	B065 4101	Front Side Plate	1
6	AF04 0055	Fusing Exit Roller	1
7	AB01 2319	Exit Gear	1
8	B065 4164	Right Support Bracket	1
9	AE03 1024	Bushing - M4x7	2
10	AE04 2052	Cleaning Roller	1
11	B065 4161	Left Support Bracket	1
12	B065 4160	Cleaning Roller Guide Plate	1
13	B065 4141	Spring Plate - Switch	1
14	B065 4139	Switch Holder	1
15	AW20 0005	Reed Switch	1
16	AA14 3037	Development Cover Screw	1
17	B065 4140	Lower Guide Plate - Exit	1
18	B065 4114	Left Stay	1
19	B065 4112	Right Stay	1
20	B065 4105	Rear Side Plate	1
21	AB01 2318	Idler Gear	1
22	AB01 2317	Fusing Drive Gear	1
23	B065 4178	Rear Pressure Lever	1
24	B065 4147	Rear Release Lever	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0360 4006B	Hexagonal Head Screw - M4x6	
102	0720 0060E	Retaining Ring - M6	
103	1105 0283	Clamp	
104	0720 0040E	Retaining Ring - M4	
105	0727 0080G	Retaining Ring - M8	
106	0807 5056	Washer - 8.1mm	

45.PAPER EXIT SECTION 1 (B064/B065)




45.PAPER EXIT SECTION 1 (B064/B065)

Rev. 04/14/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 4258	Fusing Grip	1
2	B065 4262	Lock Lever Bracket	1
3	B065 4260	Lever Shaft	1
4	B065 4259	Lock Lever	1
5	AA06 0903	Spring	1
6	B065 4266	Lever Contact Bracket	1
7	B065 4470	Support Bracket	1
8	B065 4273	Exit Grip Cover	1
9	AA08 0034	Bushing - 4x5x7	2
10	AA06 3577	Compression Spring	2
11	AF02 2126	Exit Roller - Driver	1
12	B065 4358	Paper Feed Sensor Bracket	1
13	AW02 0133	Photointerruptor	2
14	B065 4496	Relay Harness - Exit	1
15	B065 4354	Upper Exhaust Guide Plate	1
16	B065 4363	Upper Grip	1
17	B065 4359	Grip Supporter	2
18	AA08 0184	Bushing - Fusing Exit	2
19	B065 4361	Grip Shaft	1
20	B065 4373	Upper Exit Guide Plate	1
21	5447 2681	Snap Ring	2
22	AA06 6592	Spring	1
23	B065 4374	Exit Entrance Sensor Bracket	1
24	B065 4495	Relay Harness - Guide Plate	1
25	AA06 3879	Spring	2
26	AA08 0240	Bushing - MM5	2
27	B065 4360	Spring Plate	2
28	B065 4378	Driven Decura Roller	1
29	B065 4453	Middle Exit Guide Plate	1
30	B065 4381	Contact Point Shaft	1
31	B065 4154	Rear Fusing Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0353 0060B	Philips Pan Head Screw - M3x6	
103	0452 3008B	Tapping Screw - M3x8	
104	0453 3006B	Tapping Screw - M3x6	
105	1105 0522	Edge Saddle - LES0510	
106	1105 0511	Harness Clamp - LWS-0306ZC	
107	0720 0040E	Retaining Ring - M4	
108	0353 0080B	Screw - M3X8	

46.PAPER EXIT SECTION 2 (B064/B065)




46.PAPER EXIT SECTION 2 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA06 0902	Spring	1
2	B065 4415	Gate Pawl Solenoid	1
3	AA08 2117	Bushing - M6	6
4	B065 4441	Exit Drum Stay	1
5	AF02 0565	Inverter Roller	1
6	AB01 2028	Gear - 19Z	1
7	AA04 0056	Driven Roller	2
8	A229 4482	Exit Roller Holder	2
9	A229 4479	Reverse Guide Plate - Right	1
10	A229 4477	Reverse Guide Plate	1
11	B065 4413	Exit Gate Pawl	1
12	AF02 0579	Exit Decura Roller	1
13	AF02 0578	Entrance Decura Roller	1
14	A077 4162	Shoulder Screw - M3	1
15	B065 4254	Lower Entrance Guide Plate	1
16	A048 2838	Nylon Rivet	1
17	AB03 0578	Timing Pulley - 18Z	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0720 0040E	Retaining Ring - M4	

47.PAPER EXIT SECTION 3 (B064/B065)




47.PAPER EXIT SECTION 3 (B064/B065)

Rev. 02/27/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 4429	Exit Front Side Plate	1
2	B065 4252	Left Exit Tray	1
3	AF02 0581	Exit Drive Roller	1
4	B065 4308	Left Release Guide Plate	1
5	AA04 0056	Driven Roller	2
6	A229 4467	Pressure Arm	2
7	B065 4424	Exit Arm Pad	2
8	B065 4422	Guide Plate Lever	1
9	B065 4421	Pressure Shaft	1
10	B065 4460	Front Harness Bracket	1
11	B065 4459	Rear Harness Bracket	1
12	B065 4249	Right Exit Stay	1
13	B065 4433	Exit Rear Side Plate	1
14	AB01 2031	Gear	1
15	B065 4400	Bracket	1
16	AB01 9197	Exit Gear	1
17	B065 4497	Exit Harness	1
18	B065 4458	Exit Drawer Bracket	1
19	B065 4315	Exit Tightener	1
20	H521 1336	Lock Spring	1
21	AA06 0718	Tension Spring	1
22	B065 4317	Idle Pulley - 11mm	2
23	AB01 9200	Gear	1
24	AA04 3290	Timing Belt	1
25	A470 1704	Spring - Lower Exit Roller	1
26	A470 1703	Shift Clutch	1
27	AB03 0579	Timing Pulley - 27Z	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0290	Harness Clamp - HORIZONTAL	
102	1105 0328	Harness Clamp - ES-0505	
103	1105 0518	Edge Saddle - Les-1010	
104	1105 0511	Harness Clamp - LWS-0306ZC	
105	0451 4008B	Philips Tapping Screw - M4x8	
106	0720 0060E	Retaining Ring - M6	
107	0807 4146	Flat Washer - 6.3x18x1	
108	0742 3906	Ball Bearing - 6x14x5mm	
109	0720 0040E	Retaining Ring - M4	
110	0453 3008B	Bind Tapping Screw - M3x8	
111	0353 0060B	Philips Pan Head Screw - M3x6	
112	0805 3480	Bushing - 6mm	

48.DUPLEX UNIT 1 (B064/B065)




48.DUPLEX UNIT 1 (B064/B065)

Rev. 02/27/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 4525	Duplex Inner Cover	1
2	B065 4797	Caution Decal - Duplex	1
3	B065 4674	Release Grip	1
4	B065 4673	Release Lever Shaft	1
5	B065 4671	Duplex Lock Arm	1
6	B065 4675	Duplex Release Bracket	1
7	AA06 2320	Spring	1
8	B065 4672	Release Lever Bracket	1
9	5447 2681	Snap Ring	2
10	B065 4987	Upper Duplex Stay	1
11	A229 4800	Exit Guide Plate	1
12	AA06 6353	Spring	1
13	B065 4728	Spring Plate - Right Table Guide	1
14	B065 4726	Right Guide Table	1
15	B065 4500	Duplex Unit	1
16	B065 4725	Right Duplex Bracket	1
17	AA14 3307	Stepped Screw - M3	3
18	B065 4727	Right Sensor Bracket	1
19	A229 5442	Duplex Connecting Harness	1
20	AW02 0130	Photointerruptor	1
21	AF02 2077	Driven Roller	8
22	B065 4731	Spring Plate - Driven Roller	8
23	B065 4730	Lower Transport Guide Plate	1
24	A096 4928	Guide Plate Band	1
25	AA06 3581	Compression Spring	4
26	A229 4727	Guide Plate Pressure Holder	2
27	AF02 2067	Guide Stopper Roller	2
28	B065 4933	Guide Plate Lever Hook	1
29	B065 4867	Decal - Guide Plate Lever	1
30	B065 4531	Guide Plate Lever	1
31	B065 4648	Lever Cam	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0451 4006B	Tapping Screw - 4x6	
103	0450 3008B	Tapping Screw - M3x8	
104	0450 4008B	Tapping Screw - 4x8	
105	0720 0040E	Retaining Ring - M4	

49.DUPLEX UNIT 2 (B064/B065)




49.DUPLEX UNIT 2 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 4866	Reverse Knob	1
2	AA06 2318	Spring	1
3	AA14 3129	Shoulder Screw - Front Cover	1
4	B065 4647	Invertor Lever	1
5	A229 4623	Lower Entrance Guide Plate	1
6	AA06 3579	Compression Spring	2
7	AA08 0034	Bushing - 4x5x7	2
8	A229 4624	Duplex Driven Roller	1
9	AA08 2118	Bushing - M6	2
10	AA08 2116	Bushing - M8	2
11	B065 4627	Front Side Plate	1
12	AA06 0728	Tension Spring	1
13	A293 4615	Spacer	2
14	A293 4613	Front Gate Pawl	1
15	A293 4611	Reverse Roller	1
16	A293 4614	Rear Gate Pawl	1
17	AF02 1074	Entrance Inverter Roller	1
18	B065 4620	Rear Side Plate	1
19	B065 4632	Joint Holder	1
20	AA06 3582	Compression Spring	1
21	A229 4740	Drive Joint	1
22	B065 4644	Sensor Bracket	1
23	A229 4617	Duplex Discharge Brush	2
24	AW01 0058	Photosensor	1
25	B065 4640	Upper Entrance Guide Plate	1
26	AA14 3426	Stopped Screw - M4x17	1
27	5447 2681	Snap Ring	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0328	Harness Clamp - ES-0505	
102	0720 0060E	Retaining Ring - M6	
103	0720 0040E	Retaining Ring - M4	
104	0353 0050B	Philips Truss Head Screw - M3x5	
105	0450 3008B	Tapping Screw - M3x8	
106	0354 0060B	Screw - M4X6	
107	0451 4008B	Philips Tapping Screw - M4x8	

50.DUPLEX UNIT 3 (B064/B065)




50.DUPLEX UNIT 3 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 4780	Reverse Motor	1
2	B065 4810	Reverse Motor Bracket	1
3	AB01 7616	Gear	1
4	AA04 3291	Timing Belt	1
5	B065 4745	Reverse Solenoid	1
6	B065 4785	Transport Motor	1
7	A232 4666	Cushion - Stepper Motor	1
8	B065 4789	Transport Motor Bracket	1
9	AA04 3292	Timing Belt	1
10	B065 4696	Jogger Motor Bracket	1
11	B065 4650	Jogger Motor	1
12	AA02 1025	Magnet Catch	1
13	AA14 3183	Stepped Screw	2
14	5447 2681	Snap Ring	1
15	A294 4754	Roller Lever	1
16	AA06 0806	Spring	1
17	AA08 2118	Bushing - M6	2
18	B065 4720	Left Duplex Table	1
19	B065 4681	Front Jogger Fence	1
20	B065 4683	Spring Plate - Rear Jogger Fence	2
21	B065 4682	Rear Jogger Fence	1
22	AA08 0034	Bushing - 4x5x7	2
23	AA06 3655	Spring	2
24	AF02 0484	Driven Reverse Roller	1
25	B065 4655	Driven Reverse Bracket	1
26	AA14 3307	Stepped Screw - M3	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0030E	Retaining Ring - M3	
102	0720 0040E	Retaining Ring - M4	
103	0450 3006B	Tapping Screw - M3x6	
104	0353 0050B	Philips Truss Head Screw - M3x5	
105	1105 0508	Harness Clamp - LWS-0711	
106	1105 0511	Harness Clamp - LWS-0306ZC	
107	1105 0522	Edge Saddle - Les0510	
108	0450 3008B	Tapping Screw - M3x8	
109	0451 4006B	Tapping Screw - 4x6	
110	0353 0040B	Screw - M3X4	

51.DUPLEX UNIT 4 (B064/B065)




51.DUPLEX UNIT 4 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AB01 1464	Turn Gear	1
2	A232 3566	Ball Bearing - 8x16x5	4
3	AA08 2118	Bushing - M6	8
4	AB01 7614	Pulley	1
5	AB01 1463	Connecting Gear	1
6	AX20 0243	Magnetic Clutch	1
7	AB03 0731	Pulley - 29Z	1
8	AF02 1075	Duplex Turn Roller	1
9	AF02 1077	Driven Transport Roller	2
10	AA04 3293	Timing Belt	2
11	AF02 1076	Drive Inverter Roller	1
12	AF02 1078	Left Drive Roller	1
13	B065 4694	Jogger Guide Rod	1
14	AF02 1079	Right Drive Roller	1
15	AB03 0583	Timing Pulley - 24Z	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0720 0040E	Retaining Ring - M4	

52.DUPLEX UNIT 5 (B064/B065)




52.DUPLEX UNIT 5 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 4699	Jogger H.P. Sensor Bracket	1
2	B065 2762	Relay Paper Feed Harness	1
3	AW02 0120	Photointerruptor - Flat	1
4	B065 4733	Duplex Gate Pawl	1
5	B065 4738	Gate Pawl Cushion	1
6	B065 4860	Lower Duplex Bracket	1
7	B065 4865	Spacer	1
8	A294 4723	Belt Holder Fixing Plate	1
9	AA04 3294	Timing Belt	1
10	B065 4692	Front Jogger Fence Slider	1
11	B065 4693	Rear Jogger Fence Slider	1
12	A096 4595	Duplex Guide	2
13	AW02 0128	Photointerruptor	1
14	AW02 0130	Photointerruptor	2
15	B065 4715	Exit Reverse Sensor Bracket	1
16	A294 4669	Cushion	1
17	AB01 7615	Gear	1
18	B065 4710	Upper Transport Guide Plate	1
19	AA06 2318	Spring	1
20	AB03 0732	Jogger Pulley	1
21	B065 4791	Drawer Bracket - 12P	1
22	B065 4981	Duplex Harness - 12P	1
23	B065 4790	Drawer Bracket - 32P	1
24	B065 4980	Duplex Harness - 32P	1
25	B065 4619	Support Bracket	1
26	B065 4736	Exit Solenoid	1
27	B065 4820	Jogger Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4006B	Tapping Screw - 4x6	
102	1105 0328	Harness Clamp - ES-0505	
103	1105 0522	Edge Saddle - Les0510	
104	1105 0511	Harness Clamp - LWS-0306ZC	
105	1105 0508	Harness Clamp - LWS-0711	
106	0451 4008B	Philips Tapping Screw - M4x8	
107	0720 0040E	Retaining Ring - M4	
108	0453 3008B	Bind Tapping Screw - M3x8	
109	1105 0518	Edge Saddle - Les-1010	
110	1105 0516	Clamp	

53.DRIVE SECTION 1 (B064/B065)




53.DRIVE SECTION 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 5305	Development Drive Motor	1
2	AX06 0151	Stepper Motor	1
3	AA16 1122	Motor Cushion	1
4	A229 1132	Bracket - Registration Motor	1
5	AA04 3269	Timing Belt - S2M114	1
6	AB01 7449	Gear - 21Z/24T	1
7	A229 1133	Stepper Motor Base Ass'y	1
8	AA06 0720	Tension Spring - 7.75N	1
9	AB03 0427	Pulley - 81Z	1
10	A229 1135	Ring - 55	1
11	B065 1168	Fusing Drive Bracket	1
12	A229 1136	Fusing Drive Shaft	1
13	AA06 3490	Spring - 21.6mm	1
14	A096 1173	Fusing Drive Joint	1
15	B065 1157	Toner Recycling Bracket	1
16	AA06 6651	Spring	1
17	B065 1160	Toner Recycling Tightener	1
18	AA04 3946	Timing Belt	1
19	AB03 2716	Idle Pulley - M18	1
20	B065 1164	Tightener	1
21	AA06 6309	Torsion Spring	1
22	B065 1162	Fusing Motor Bracket	1
23	AX06 0253	Fusing Motor	1
24	AB03 0725	Pulley - 89Z	1
25	A293 1155	Duplex Drive Bracket	1
26	B065 1166	Duplex Drive Shaft	1
27	B065 1167	Duplex Drive Joint	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4010B	Tapping Screw - 4x10	
102	0720 0060B	Retaining Ring - M6	
103	0951 4008B	Philips Screw With Washer - M4x8	
104	0451 4008B	Philips Tapping Screw - M4x8	
105	0720 0040E	Retaining Ring - M4	
106	0354 0050B	Bind Screw - M4x5	
107	0720 0060E	Retaining Ring - M6	
108	0623 0140E	Spring Pin - 3x14mm	


54.DRIVE SECTION 2 (B064/B065)



54.DRIVE SECTION 2 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 5808	LCT Cable Bracket	1
2	B065 2481	Grid Receptacle Terminal	1
3	B065 2482	Charge Receptacle Terminal	1
4	A294 2051	Rear Receptacle	1
5	A294 2052	Receptacle Pin	2
6	B065 1154	Electrode Plate	1
7	B065 3262	Electrode Plate	1
8	B065 1137	Bracket	1
9	B065 1140	Drum Shaft	1
10	A134 1135	Fly Wheel	1
11	B065 1134	Partition Plate	1
12	B065 1145	Boss	1
13	AB01 2315	Gear - 156Z	1
14	AB01 1482	Gear - 40Z	1
15	AA04 3948	Timing Belt	1
16	AB01 7640	Gear - 38Z/59Z	1
17	AA06 0792	Tension Spring	1
18	B065 1122	Tightener Bracket	1
19	B065 1110	Main Motor	1
20	B065 1084	Positioning Plate	1
21	AB03 0458	Pulley - 28Z	1
22	AA04 3945	Timing Belt	1
23	A229 1135	Ring - 55	1
24	AB03 0724	Pulley - 74Z	1
25	B065 1147	Transfer Drive Bracket	1
26	B065 1149	Transfer Drive Joint	1
27	AA06 3654	Spring	1
28	B065 1131	Joint	1
29	AA13 2025	Spacer	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0453 3008B	Bind Tapping Screw - M3x8	
103	1102 8504	Connector	
104	0725 0120E	Retaining Ring C - M12	
105	0450 3008B	Tapping Screw - M3x8	
106	0951 5010B	Philips Screw With Washer - M5x10	
107	0720 0040E	Retaining Ring - M4	
108	0720 0060E	Retaining Ring - M6	
109	0450 4008B	Tapping Screw - 4x8	
110	0951 4005B	Philips Screw With Flat Wash - M4x5	
111	0633 0180G	Parallel Pin - 3x18mm	
112	1105 0490	Harness Clamp - IWS-2218	
113	1105 0489	Harness Clamp - LWS 1316	
114	1105 0516	Clamp	




55.TONER COLLECTION (B064/B065)

Rev. 02/28/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 3568	Case Cap	1
2	B065 3573	Toner Collection Agitator	1
3	B065 3565	Toner Collection Case	1
4	AW50 0023	Push Switch	2
5	B065 3566	Toner Receiving Spring	1
6	B065 3557	Toner Catchpan	1
7	B065 3609	Toner Separation Shaft - Long	1
8	B065 3588	Toner Collection Idle Gear	1
9	B065 3590	Toner Collection Shaft	1
10	5053 0447	Bushing - 6mm	1
11	B065 3585	Screw Gear	1
12	AA13 2208	Spacer - M6	2
13	B065 3561	Spring	1
14	B065 3587	Toner Collection Gear	2
15	B065 3581	Bushing	1
16	B065 3570	Toner Transport Coil	1
17	B065 3583	Spring Guide	1
18	B065 3586	Screw Gear	1
19	AX06 0235	DC Motor	1
20	H053 2208	Bushing - M4	1
21	B065 3559	Base	1
22	B065 3593	Toner Collection Discharge Harness	1
23	B065 3552	Toner Outlet Sub-unit - Transfer Ass'y	1
24	B065 3656	Toner Collection Seal - Transport	1
25	B065 3654	Toner Collection Cap	1
26	B065 3601	Toner Collection Pipe	2
27	B065 3660	Pulley	1
28	B065 3652	Shield Plate	1
29	B065 3649	Toner Collection Case - Transport	1
30	B065 3650	Toner Collection Joint	1
31	AW02 0120	Photointerruptor - Flat	2
32	B065 2762	Relay Paper Feed Harness	1
33	B065 3670	Transport Screw	2
34	A096 3712	Ratch	1
35	B065 3610	Toner Collection Shaft	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	5447 2681	Snap Ring	1
37	B065 3554	Toner Collection Ass'y - Trasfer	1
38	B065 3604	Toner Separation Shaft	1
39	B065 3629	Toner Separation Case	1
40	B065 3636	Toner Collection Seal	1
41	B065 3645	Gear - 22z	1
42	B065 3637	Seal - 40x68	1
44	B065 3633	Transport Screw	1
101	0451 4008B	Philips Tapping Screw - M4x8	
102	1105 0046	Harness Band	
103	0354 0080B	Screw - M4X8	
104	1105 0511	Harness Clamp - LWS-0306ZC	




56.ELECTRICAL SECTION 1 (B064/B065)

Rev. 02/28/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 5417	Left Harness	1
2	B065 5416	Upper Harness	1
3	B065 5120	BCU Board	1
4	B064 5855	PCB Cover	1
5	B065 5827	Upper Hinge	1
6	5919 2201	Shoulder Screw - M4	7
7	B065 5826	Lower Hinge Bracket	1
8	5447 2681	Snap Ring	1
9	B065 5874	Lower Hinge	1
10	B065 5791	Fan Motor Gasket	2
11	B065 5865	Fan Cover	1
12	AX64 0137	Cooling Fan - 24V	1
13	B065 5860	BCU Board Bracket	1
14	B065 5447	ADF Power Source Harness	1
15	B065 5503	ADF/CNB Harness	1
16	B065 5806	ADF Cable Bracket	1
17	B065 5807	Finisher Cable Bracket	1
18	B065 5445	Finisher Cable Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008B	Tapping Screw - M3x8	
102	1105 0316	Clamp	
103	1105 0516	Clamp	
104	1105 0489	Harness Clamp - LWS 1316	
105	1105 0518	Edge Saddle - Les-1010	
106	0451 4008B	Philips Tapping Screw - M4x8	
107	0453 3008B	Bind Tapping Screw - M3x8	
108	1102 8502	Connector - 54679-1615	
109	0360 3006B	Tapping Screw - M3x6	
110	1105 0511	Harness Clamp - LWS-0306ZC	
111	1105 0521	Clamp - LES-1017	
112	0451 4020B	Tapping Scrw - M4x20	
113	0360 3008B	Tapping Screw - M3x8	




57.ELECTRICAL SECTION 2 (B064/B065)

Rev. 01/31/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B004 5853	Bracket Grip	1
2	B065 5837	NIB Cover	1
3	B065 5863	IC Card Cover	1
4	B065 5752	Control Unit Side Plate	1
5	B065 5754	Centronics Cover	1
6	B065 5838	IEEE1394 Cover	2
7	G331 5700	SDRAM - 128MB	1
8	B065 5790	Panel Gasket	1
9	B065 5111	Controller Board	1
10	B065 5867	Fan Cover	1
11	AX64 0098	Fan Motor - DC5V 1.2W	1
12	B065 5861	HDD Side Plate	1
13	B065 5112	HDD - 40GB	1
14	AA14 3781	Binding Screw - M3x3.5	4
15	B066 5116	Power Source Harness	1
16	B065 5115	HDD Harness	1
17	B065 5858	HDD Bracket	1
18	AA16 1125	Rubber Cushion	4
19	AA14 3499	Stepped Screw	4
20	B065 5868	Clamp	4
21	B065 5821	Control Unit Base	1
22	B065 5508	IPU/PSU Harness	1
23	B065 5200	Mother Board	1
24	B065 5883	Fan Relay Harness	1
25	B065 5846	Mother Board Cover	1
26	B065 5507	MB/PSU Harness	1
27	B065 5510	MB2/PSU Harness	1
28	B065 5144	IPU Board	1
29	B065 5450	IPU/BCU Harness	1
30	B065 5841	IPU Cover	1
31	B065 5844	IPU Connector Cover	1
32	B065 5869	Base Sheet	1
33	B064 9099	NVRAM - Minus Counter	1
34	B065 5795	Controller Grounding Bracket	1
35	A669 1827	Spacer - 16mm	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	B066 5300	MLB Board	1
37	B066 5501	Spacer - 13mm	1
101	0451 3006B	Tapping Screw - M3x6	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0451 3014B	Tapping Screw - M3-14	
104	1105 0511	Harness Clamp - LWS-0306ZC	
105	1105 0488	Harness Clamp	
106	0353 0040B	Screw - M3X4	
107	0360 3006B	Screw - M3X6	

58.ELECTRICAL SECTION 3 (B064/B065)




58.ELECTRICAL SECTION 3 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA16 1104	Cushion - Motor	2
2	B065 1178	Fan Bracket - IPS	1
3	AA15 3155	Duct Seal - IPS	1
4	B065 1175	Entrance IPS Duct	1
5	A293 1095	Sirocco Fan - DC24V	1
6	AA15 1775	Seal - Fan	1
7	B065 1177	Upper Ips Duct	1
8	B065 1194	Exhaust Bracket	1
9	B065 1192	Upper Exhaust Duct	1
10	B065 1193	Lower Exhaust Duct	1
11	AA15 3156	Exhaust Duct Seal	2
12	AX65 0030	Cooling Fan - 24V	1
13	AZ32 0106	Charge Power Pack	1
14	B065 5804	Charge Power Pack Bracket	1
15	B065 5500	CNB/PSU Harness	1
16	B065 5509	DRB/BCU Power Sorce Harness	1
17	B065 5421	Safety Switch Harness	1
18	B065 5230	CNB Board	1
19	B065 5420	CNB Board Harness	1
20	B065 5802	CNB Board Bracket	1
21	B065 5185	DRB Board	1
22	B065 5803	DRB Board Bracket	1
23	B065 5805	CSS Bracket	1
24	A265 5154	Pcb:css	1
25	A293 5871	Css Board Bracket	1
26	B065 5468	Css Relay Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0951 4010B	Philips Screw With Washer - M4x10	
102	0707 4050B	Bushing - 4x5	
103	1102 6245	Relay Connector - 2P	
104	0450 4008B	Tapping Screw - 4x8	
105	0450 4016B	Tapping Screw - 4x16	
106	0451 4008B	Philips Tapping Screw - M4x8	
107	0451 3008B	Tapping Screw - M3x8	
108	1105 0488	Harness Clamp	
109	1105 0516	Clamp	
110	1105 0522	Edge Saddle - LES0510	

59.ELECTRICAL SECTION 4 (B064/B065)




59.ELECTRICAL SECTION 4 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA15 3154	Duct Seal - PCU	1
2	B065 1183	Fan Bracket	1
3	B065 1184	Entrance PCU Duct	1
4	AX64 0136	Cooling Fan - 24V	1
5	AZ30 0053	Development Power Pack	1
6	B065 5892	Power Pack Bracket	1
7	B065 5815	Charge Power Pack Bracket	1
8	AA15 3151	Duct Seal - PCU A	1
9	AA15 3152	Duct Seal - PCU B	1
10	AA15 3153	Duct Seal - PCU C	2
11	B065 1180	PCU Duct	1
12	B065 5814	Harness Guide	1
13	B065 5890	Upper Hinge Stay	1
14	B065 5868	Clamp	1
15	AA06 3880	Spring	8
16	5446 5832	Connector Guide Pin	8
17	B065 5817	Slide Rail Cover	1
18	B065 5819	Lower Hinge Bracket	1
19	B065 5422	Duplex DRB Harness	1
20	B065 5418	Duplex/Exit Harness	1
21	B065 5818	Main Switch Harness Guide	1
22	B065 5600	AC Harness - 120V	1
22	B065 5651	AC Harness - 240V	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0450 4008B	Tapping Screw - 4x8	
103	0450 4035B	Philips Tapping Screw - M4x35	
104	1102 6245	Relay Connector - 2P	
105	0451 3008B	Tapping Screw - M3x8	
106	1105 0522	Edge Saddle - LES0510	
107	1105 0532	Edge Saddle - LES-25I	
108	1105 0489	Harness Clamp - LWS 1316	
109	1105 0516	Clamp	
110	1105 0490	Harness Clamp - IWS-2218	
111	1105 0518	Edge Saddle - Les-1010	
112	1105 0314	Metal Clamp - AL-5	

60.ELECTRICAL SECTION 5 (B064/B065)




60.ELECTRICAL SECTION 5 (B064/B065)

Rev. 02/10/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 5701	Front Paper Bank Harness	1
2	B065 5483	Safety Switch	1
3	B065 5139	PFC Board	1
4	B065 5871	PFC Board Bracket	1
5	B065 5873	Upper PFC Board Stay	1
6	B065 5872	Lower PFC Board Stay	1
7	AZ24 0073	DC Power Supply Board - 120V	1
7	AZ24 0078	DC Power Supply Board - 240V	1
7	AZ24 0079	DC Power Supply Board - 240V (CHN)	1
8	B065 5502	PFC/PSU Harness	1
9	B065 3695	Bottle Guide	1
10	B065 5601	Paper Bank Heater Harness	1
11	B065 5672	Power Supply Cord - 120V	1
11	AZ00 0070	Power Supply Cord - 230V	1
11	B065 5673	Power Supply Cord - 230V (CHN)	1
12	B065 5879	Right PSU Stay	1
13	B065 5898	Power Supply Board Holder - 120V	1
13	B065 5877	Power Supply Board Holder - 240V	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0451 3008B	Tapping Screw - M3x8	
103	1105 0487	Harness Clamp	
104	1105 0488	Harness Clamp	
105	1105 0489	Harness Clamp - LWS 1316	
106	0801 0142	Screw - Spring Washer - M5X8	
107	1105 0532	Edge Saddle - LES-25I	
108	1107 1022	Fuse	
109	1107 0864	Fuse - 12A (120V)	
109	1107 0880	Fuse - 6.3A 250V (240V)	

61.ELECTRICAL SECTION 6 (B064/B065)




61.ELECTRICAL SECTION 6 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 6771	Armbracket	1
2	AA13 2203	Spacer - 6mm	1
3	B065 6769	Lock Arm	1
4	AA06 2252	Spring - Small	1
5	AA06 2251	Spring - Large	1
6	A248 6168	Bracket - Lift Motor	1
7	A248 6167	DC Motor - 19.2W	1
8	AX04 0135	Paper Tray Motor	2
9	B065 6767	Right Connecting Bracket	1
10	B065 5700	Rear Paper Bank Harness	1
11	AA06 3880	Spring	2
12	5446 5832	Connector Guide Pin	2
13	A248 6757	Left Connector Bracket	1
14	B065 6177	Paper Size Sensor Bracket	2
15	A096 5416	Paper Size Harness	2
16	AW50 0010	Push Switch	2
17	AA16 1096	Stopper Cushion	2
18	B065 6173	Stopper Bracket	2
19	B065 5878	Upper PSU Stay	1
20	B065 6755	Solenoid	1
21	A248 6758	DC Lock Solenoid	1
22	AA06 3268	Connector Spring	2
23	0803 0058	Stepped Screw	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0488	Harness Clamp	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0451 3008B	Tapping Screw - M3x8	
104	0414 0102B	Tapping Screw M4x10	
105	0720 0040B	Retaining Ring - M4	

62.UPPER FRAME 1 (B064/B065)




62.UPPER FRAME 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 5430	LD Switch Harness	1
2	B065 5041	Safety Switch Lever	1
3	B065 5811	Safety Switch Bracket	1
4	B065 1320	Receiving Tray - Operation Panel	1
5	B065 5816	Safety Switch Harness Cover	1
6	B065 5813	Main Switch Bracket	1
7	B065 1188	Duct - Fusing	1
8	AA15 3150	Duct Seal - Fusing	1
9	A294 2114	Toner Filter	1
10	B065 1185	Duct - Charge	1
11	AA15 3148	Duct Seal - Charge A	1
12	AA15 3149	Duct Seal - Charge B	1
13	5919 2201	Shoulder Screw - M4	1
14	B065 3267	Inner Back Cam	1
15	B065 3266	Toner Bottle Cam	1
16	B065 1328	Upper Hinge Guide Plate	1
17	AA06 3052	Turret Spring	1
18	A096 1355	Hinge Shaft	1
19	B065 1077	Right Stay	1
20	AA15 3144	Duct Seal - IPS A	1
21	AA15 3145	Duct Seal - IPS B	2
22	AA15 3146	Duct Seal - IPS C	1
23	AA15 3147	Duct Seal - IPS D	1
24	B065 1173	Ips Duct	1
25	B065 1845	Grounding Plate	6
26	B065 1844	Grounding Plate	3
27	B065 5899	Bushing	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040E	Retaining Ring - M4	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	1105 0518	Edge Saddle - Les-1010	
104	1204 2598	Switch	
105	0353 0120B	Bind Screw - M3x12	
106	1204 2390	Interlock Switch - FA8I-AB24	
107	1204 2521	Micro Switch	
108	0453 3008B	Bind Tapping Screw - M3x8	

63.UPPER FRAME 2 (B064/B065)




63.UPPER FRAME 2 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 3832	Transfer Unit Lever	1
2	AA08 2064	Bushing - 10mm	1
3	B065 1096	Front Transfer Stay	1
4	B065 3253	Upper Development Drum Stay	1
5	B065 3251	Development Unit Rail	1
6	A096 1679	Development Grounding Plate	1
7	AX31 0044	Counter	1
8	B065 5893	Counter Bracket	1
9	B065 3252	Right Rail - Drum Unit	1
10	6754 2866	Roller - Positioning Guide	2
11	B065 3827	Handle Stay	1
12	AX40 0160	Heater - 120V 9W	1
12	AX40 0161	Heater - 230V 9W	1
13	B065 3837	Heater Holder	1
14	B065 3838	Heat Insulation Heater	1
15	B065 3811	Transfer Unit Stay	1
16	B065 3812	Transfer Rely Harness	1
17	AA07 0058	Right Slide Rail	1
18	B065 1094	Duct Clip	1
19	B065 1091	Left Duct - PCU	1
20	B065 1095	Heat Insulation	1
21	B065 2496	PCU Connecting Harness	1
22	B065 1098	Left Rail	1
23	B065 3815	Front Middle Channel	1
24	B065 3820	Positioning Plate - Transfer Unit	1
25	B065 3831	Release Positioning Plate	1
26	B065 3833	Decal - Transfer Unit Lever	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0453 4008B	Tapping Bind Screw - M4x8	
103	1105 0487	Harness Clamp	
104	0720 0040E	Retaining Ring - M4	
105	0360 4008B	Screw - M3x8	
106	0451 3006B	Tapping Screw - M3x6	
107	1105 0522	Edge Saddle - LES0510	

64.UPPER FRAME 3 (B064/B065)




64.UPPER FRAME 3 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA12 0067	Anti Static Brush	1
2	B065 4319	Upper Exit Guide Plate	1
3	B065 4300	Exhaust Cover	1
4	B065 4306	Front Exhaust Side Plate	1
5	AA07 0061	Leftslide Rail	1
6	B065 4304	Left Plate Guide	1
7	B065 4263	Lock Lever Shaft Bracket	1
8	B065 1197	Magnet Catch Bracket	1
9	AG07 1011	Magnet Catch	1
10	B065 4835	Rail	1
11	A300 2134	Guide Roller - B	2
12	6754 2866	Roller - Positioning Guide	2
13	B065 1092	Bracket	4
14	5447 2681	Snap Ring	1
15	B065 4179	Stripper Pawls Plate	1
16	B065 4168	Fusing Positioning Plate	1
17	B065 4591	Right Duplex Rail	1
18	B065 1198	Duplex Fan Harness	1
19	AX64 0136	Cooling Fan - 24V	1
20	B065 1195	Duplex Fan Bracket	1
21	B065 4830	Holder Bracket	1
22	B065 1075	Base Cover	1
23	B065 1078	Left Stay	1
24	B065 4307	Rear Exhaust Side Plate	1
25	B065 4499	Exit Detection Harness	1
26	AA16 1104	Cushion - Motor	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008B	Philips Tapping Screw - M4x8	
102	0951 4010B	Philips Screw With Washer - M4x10	
103	1105 0511	Harness Clamp - LWS-0306ZC	
104	1102 6245	Relay Connector - 2P	
105	0451 4010B	Tapping Screw - 4x10	
106	0720 0040E	Retaining Ring - M4	
107	0434 0080B	Pan Head Self - Tapping Screw - M4x8	
108	0451 3006B	Tapping Screw - M3x6	
109	1105 0328	Harness Clamp - ES-0505	
110	1105 0283	Clamp	
111	0354 0300B	Screw - M3x30	
112	0707 4050B	Bushing - 4x5	

65.LOWER FRAME 1 (B064/B065)




65.LOWER FRAME 1 (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 6776	Tandem Tray Stay	1
2	AA06 0592	Lock Spring - Tandem Tray	1
3	B065 6235	Left Rail Bracket	1
4	B065 6792	Slide Rail Base - Tandem	1
5	B065 6135	Lock Arm - Tandem Tray	1
6	B065 6265	Left Tandem Slide Rail	1
7	B065 6116	Upper Heat Sink	1
8	AX40 0150	Heater - 115V 18W	1
8	AX40 0151	Heater - 240V 18W	1
9	A248 6103	Guide Plate - Upper Heat Sink	1
10	AA07 0044	Slide Rail - Tandem Tray	1
11	B065 6774	Slidebracket	1
12	B065 6264	Guide Stay	1
13	B065 6266	Right Tandem Slide Rail	1
14	B065 6777	Supporting Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040E	Retaining Ring - M4	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	0313 0040B	Philips Pan Head Screw - M3x4	
104	0314 0040B	Philips Pan Head Screw - M4x4	
105	0360 4006B	Hexagonal Head Screw - M4x6	
106	1105 0516	Clamp	

66.LOWER FRAME 2 (B064/B065)



66.LOWER FRAME 2 (B064/B065)

Rev. 02/04/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	B065 6076	Support Plate	1
2	AA06 0534	Tray Lock Spring - 19mm	2
3	B065 6136	Tray Lock Arm	2
4	B065 6241	Left Rail - Paper Feed	2
5	B065 6783	Slide Rail Base	2
6	B065 6260	Right Slide Rail	2
7	AH01 2015	Caster - 1470N	4
8	5301 1662	Hexagon Bolt	12
9	AA14 3749	Stand - Hexagonal Bolt M12x35	4
10	A096 6693	Paper Guide Sheet	1
11	B065 6191	Side Plate - Paper Tray	1
12	B065 6166	Rear Support Plate	2
13	AX40 0156	Heater - 115V 18W	1
13	AX40 0157	Heater - 240V 18W	1
14	B065 6221	Lower Heat Sink	1
15	B065 6174	Paper Tray Positioning Bracket	2
16	B065 6075	Side Plate Stay - Lower Rear	1
17	5201 1796	Stepped Screw - M4	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0453 3006B	Tapping Screw - M3x6	
103	0720 0040E	Retaining Ring - M4	
104	0451 4008B	Philips Tapping Screw - M4x8	
105	1105 0516	Clamp	

67.BCU BOARD (B064/B065)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C101	236	C111	236	C121	243	C131	242	C141	179	C151	238	C161	244
C102	236	C112	236	C122	179	C132	244	C142	244	C152	188	C162	179
C103	236	C113	236	----	----	C133	244	C143	244	C153	242	C163	244
C104	236	C114	236	C124	179	C134	239	C144	242	C154	244	C164	233
C105	236	C115	236	C125	243	C135	244	C145	179	C155	238	C165	244
C106	236	C116	236	C126	244	C136	179	C146	244	C156	242	C166	233
C107	236	C117	236	C127	178	C137	179	C147	179	----	----	C167	235
C108	236	C118	236	C128	243	C138	244	C148	244	C158	242	C168	244
C109	236	C119	236	C129	244	C139	179	C149	244	C159	244	C169	242
C110	236	C120	244	C130	244	C140	244	C150	244	C160	233	C170	242

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C171	242	C181	179	C191	244	C201	244	C211	237	C221	187	C231	179
C172	179	C182	244	C192	244	C202	242	C212	244	C222	187	C232	244
C173	244	C183	244	C193	179	C203	179	C213	179	C223	244	C233	179
C174	242	C184	179	C194	177	C204	237	C214	237	C224	242	C234	179
C175	244	C185	244	C195	244	C205	179	C215	189	C225	232	C235	244
C176	242	C186	244	C196	244	C206	237	C216	244	C226	244	C236	244
C177	244	C187	244	C197	244	C207	177	C217	244	C227	242	C237	244
C178	179	C188	244	C198	244	C208	179	C218	190	C228	179	C238	236
C179	234	C189	244	C199	242	C209	237	C219	244	C229	179	C239	179
C180	234	C190	244	C200	242	C210	179	C220	187	C230	179	C240	236

67.BCU BOARD (B064/B065)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C241	236	C251	244	C261	244	C271	244	C281	244	C291	242	C301	244
C242	179	C252	242	C262	242	C272	244	C282	242	C292	244	C302	242
C243	236	C253	242	C263	244	C273	244	C283	179	C293	241	C303	242
C244	244	C254	242	C264	244	C274	242	C284	244	C294	242	C304	244
C245	236	C255	242	C265	242	C275	179	C285	244	C295	242	C305	179
C246	236	C256	244	C266	179	C276	179	C286	244	C296	179	C306	244
C247	236	C257	242	C267	242	C277	244	C287	244	C296	242	C307	179
C248	236	C258	242	C268	244	C278	244	C288	244	C297	241	C308	179
C249	232	C259	232	C269	179	C279	244	C289	244	C299	242	C309	179
C250	241	C260	244	C270	242	C280	179	C290	244	C300	179	C310	244

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C311	179	C321	244	C331	242	C341	244	C351	242	C361	179	C371	179
C312	179	C322	242	C332	244	C342	242	C352	242	C362	179	C372	240
C313	179	C323	244	C333	179	C343	244	C353	244	C363	179	C373	240
C314	179	C324	244	C334	179	C344	244	C354	242	C364	179	C374	240
C315	244	C325	179	C335	242	C345	244	C355	179	C365	179	C375	240
C316	244	C326	242	C336	179	C346	244	C356	244	C366	179	C376	240
C317	244	C327	179	C337	244	C347	242	C357	242	C367	179	C377	240
C318	179	C328	242	C338	244	C348	242	C358	191	C368	179	C378	240
C319	179	C329	244	C339	179	C349	242	C359	179	C369	179	C379	240
C320	244	C330	244	C340	179	C350	242	C360	179	C370	179	C380	240

67.BCU BOARD (B064/B065)

CAPACITOR

SYMBOL NO.	INDEX NO.
C381	240
C382	240
C383	240
C384	179
C385	179
C386	179

CAPACITOR

SYMBOL NO.	INDEX NO.
CN201	103
CN202	109
CN203	111
CN204	112
CN205	115
CN206	116
CN207	121
CN208	122
CN209	109
CN210	120

SYMBOL NO.	INDEX NO.
CN211	119
CN212	114
CN213	105
CN214	118
CN215	113
CN216	106
CN217	117
CN218	123
CN219	112
CN220	108

SYMBOL NO.	INDEX NO.
CN221	107
CN222	114
CN223	110
CN224	118

DIODE

SYMBOL NO.	INDEX NO.
D101	134
D102	134
D103	132
D104	132
D105	132
D106	132
D107	132
D108	134
D109	134
D110	134

SYMBOL NO.	INDEX NO.
D111	134
D112	134

DA

SYMBOL NO.	INDEX NO.
DA101	133
DA102	133
DA103	133
DA104	131

FILTER

SYMBOL NO.	INDEX NO.
FIL101	182
FIL102	180
FIL103	181
FIL104	182
FIL105	183

FUSE

SYMBOL NO.	INDEX NO.
FU101	124

CAPACITOR

SYMBOL NO.	INDEX NO.
IC101	142
IC102	162
IC103	147
IC104	147
IC105	147
IC106	150
IC107	245
IC108	154
IC109	245
IC110	142

SYMBOL NO.	INDEX NO.
IC111	148
IC112	160
IC113	145
IC114	156
IC115	155
IC116	151
IC117	146
IC118	160
IC119	2
IC120	149

SYMBOL NO.	INDEX NO.
IC121	143
IC122	155
IC123	160
IC124	142
IC125	152
IC126	142
IC127	142
IC128	1
IC129	3
IC130	145

SYMBOL NO.	INDEX NO.
IC131	153
IC132	151
IC133	142
IC134	142
IC135	142
IC136	142
IC137	142
IC138	142
IC139	142
IC140	155

SYMBOL NO.	INDEX NO.
IC141	152
IC142	152
IC143	157
IC144	158
IC145	159

JP

SYMBOL NO.	INDEX NO.
JP101	186

OSC

SYMBOL NO.	INDEX NO.
OSC101	163
OSC102	165
OSC103	164

LED

SYMBOL NO.	INDEX NO.
LED102	138
LED202	140

PC

SYMBOL NO.	INDEX NO.
PC101	139

67.BCU BOARD (B064/B065)

Q

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
Q101	141	Q111	127	Q121	144	R101	197	R111	196	R121	204
Q102	141	Q112	127			R102	195	R112	197	R122	204
Q103	129	Q113	130			R103	197	R113	195	R123	204
Q104	126	Q114	130			R104	195	R114	195	R124	204
Q105	128	Q115	141			R105	202	R115	204	R125	204
Q106	141	Q116	141			---	---	R116	204	R126	204
Q107	161	Q117	127			R107	202	R117	204	R127	204
Q108	141	Q118	126			R108	196	R118	204	R128	204
Q109	126	Q119	126			R109	196	R119	204	R129	204
Q110	126	Q120	141			R110	196	R120	204	R130	204
										R131	204
										R132	204
										R133	202
										R134	202
										R135	202
										R136	202
										R137	197
										R138	195
										R139	197
										R140	197

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R141	195	R151	196	R161	197	R171	196	R181	196	R191	215
R142	202	R152	196	---	---	R172	197	R182	204	R192	209
R143	202	R153	196	R163	196	R173	197	R183	209	R193	197
R144	202	R154	196	R164	196	R174	197	R184	209	R194	200
R145	202	R155	196	R165	211	R175	196	R185	209	R195	166
R146	195	R156	196	R166	196	R176	196	R186	209	R196	200
R147	197	R157	196	R167	197	R177	196	R187	200	R197	204
R148	196	R158	196	R168	195	R178	197	R188	192	R198	193
R149	225	R159	196	R169	196	R179	204	R189	196	R199	231
R150	218	R160	211	R170	197	R180	197	R190	193	R200	196
										R201	209
										R202	193
										R203	209
										R204	185
										R205	193
										R206	230
										R207	193
										R208	197
										R209	195
										R210	197

67.BCU BOARD (B064/B065)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R211	195	R221	200	R231	197	R241	196	R251	197	R261	196	R271	227
R212	216	R222	196	R232	195	R242	195	R252	199	R262	196	R272	194
R213	196	R223	196	R233	197	R243	197	R253	184	R263	197	R273	222
R214	196	R224	209	R234	197	R244	196	R254	184	R264	197	R274	197
R215	213	R225	209	R235	197	R245	197	---	---	R265	197	R275	194
R216	213	R226	195	R236	195	R246	197	R256	199	R266	197	R276	194
R217	209	R227	197	R237	197	R247	197	R257	208	R267	197	R277	195
R218	209	R228	197	R238	195	R248	216	R258	197	R268	205	R278	194
R219	200	R229	196	R239	197	R249	196	R259	197	R269	205	R279	194
R220	209	R230	197	R240	197	R250	197	R260	196	R270	196	R280	197

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R281	195	R291	197	R301	195	R311	206	R321	197	R331	196	R341	196
R282	197	R292	201	R302	206	R312	197	R322	196	R332	196	R342	213
R283	214	R293	201	R303	197	R313	195	R323	197	R333	196	R343	213
R284	194	R294	197	R304	197	R314	206	R324	228	R334	196	R344	196
R285	194	R295	195	R305	208	R315	197	R325	196	R335	196	R345	196
R286	194	R296	206	R306	201	R316	195	R326	224	R336	196	R346	196
R287	197	R297	197	R307	195	R316	196	R327	210	R337	197	R346	213
R288	195	R298	195	R308	206	R317	202	R328	210	R338	196	R347	228
R289	197	R299	197	R309	197	R319	197	R329	224	R339	196	R349	213
R290	197	R300	197	R310	195	R320	196	R330	196	R340	196	R350	229

67.BCU BOARD (B064/B065)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R351	196	R361	197	R371	197	R381	196	R391	215	R401	196	R411	208
R352	196	R362	197	R372	197	R382	196	R392	215	R402	196	R412	195
R353	196	R363	215	R373	197	R383	196	R393	196	R403	196	R413	197
R354	196	R364	197	R374	197	R384	219	R394	196	R404	197	R414	197
R355	196	R365	197	R375	208	R385	219	R395	197	R405	208	R415	197
R356	215	R366	197	R376	208	R386	197	R396	197	R406	197	R416	197
R357	226	R367	197	R377	196	R387	215	R397	196	R407	196	R417	195
R358	196	R368	196	R378	209	R388	197	R398	197	R408	196	R418	197
R359	213	R369	197	R379	196	R389	197	R399	197	R409	196	R419	197
R360	219	R370	197	R380	209	R390	215	R400	208	R410	196	R420	197

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R421	197	R431	197	R441	197	R451	196	R461	202	R471	202	R481	197
R422	197	R432	197			R452	212	R462	207	R472	198	R482	196
R423	197	R433	223	R443	196	R453	196	R463	202	R473	196	R483	208
R424	197	R434	197	R444	212	R454	221	R464	207	R474	195		
R425	197	R435	197	R445	208	R455	195	R465	203	R475	197		
R426	197	R436	220	R446	197	R456	217	R466	201	R476	197		
R427	197	R437	197	R447	196	R457	197	R467	202	R477	197		
R428	197	R438	220	R448	196	R458	196	R468	207	R478	196		
R429	197	R439	223	R449	197	R459	197	R469	202	R479	197		
R430	197	R440	196	R450	196	R460	197	R470	207	R480	202		

67.BCU BOARD (B064/B065)

RN

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
RN101	168	RN111	171	RN121	168	RN131	172	RN141	167	RN151	169	RN161	173
RN102	168	RN112	176	RN122	168	RN132	172	RN142	167	RN152	169	RN162	169
RN103	174	RN113	168	RN123	168	RN133	172	RN143	167	RN153	169	RN163	173
RN104	174	RN114	168	RN124	168	RN134	172	RN144	168	RN154	175	RN164	173
RN105	170	RN115	170	RN125	168	RN135	168	RN145	170	RN155	175	RN165	176
RN106	168	RN116	168	RN126	167	RN136	167	RN146	168	RN156	175	RN166	176
RN107	168	RN117	168	RN127	168	RN137	170	RN147	168	RN157	175	RN167	169
RN108	171	RN118	176	RN128	168	RN138	168	RN148	173	RN158	173	RN168	173
RN109	171	RN119	170	RN129	170	RN139	168	RN149	173	RN159	173	RN169	173
RN110	171	RN120	168	RN130	176	RN140	167	RN150	169	RN160	173		

SWITCH

SYMBOL NO.	INDEX NO.
SW101	125

TB

SYMBOL NO.	INDEX NO.
TB101	104
TB102	102

TP

SYMBOL NO.	INDEX NO.
TP189	101
TP192	101
TP193	101
TP201	101
TP207	101
TP209	101
TP213	101
TP217	101
TP218	101
TP219	101

SYMBOL NO.	INDEX NO.
TP222	101
TP223	101

ZD

SYMBOL NO.	INDEX NO.
ZD101	137
ZD102	137
ZD103	137
ZD104	137
ZD105	136
ZD106	137
ZD107	135

67.BCU BOARD (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B065 5120	BCU Board	1
1	A232 5355	IC - GATEX	1
2	B004 5120	IC - HG71C114FL	1
3	B065 5128	IC - GASTM	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1100 1474	Test Pin	
102	1102 3597	Pin Header - 4P	
103	1102 5304	Connector - 5P	
104	1102 5943	Connector - 2P	
105	1102 6295	Connector - 2P	
106	1102 6296	Connector - 3P	
107	1102 6297	Connector - 4P	
108	1102 6325	Connector - 4P	
109	1102 6393	Connector - 10P	
110	1102 6395	Connector - 1P	
111	1102 6396	Connector - 1P	
112	1102 6397	Box Header	
113	1102 6399	Connector - 22P	
114	1102 6401	Connector - 26P	
115	1102 6403	Connector - 30P	
116	1102 6515	Connector - 34P	
117	1102 8210	Connector - 2P	
118	1102 8472	Connector - 55447-0810	
119	1102 8476	Connector - 55447-1210	
120	1102 8480	Connector - 55447-1610	
121	1102 8553	Connector - 3-353308-6	
122	1102 9937	Connector - WR-50P-VF-1	
123	1103 1317	Connector	
124	1109 0007	IC - MINISMDC100-02	
125	1204 1537	DIP Switch	
126	1400 0619	Transistor - DTA143EKA	
127	1400 0728	Transistor - 2SD2170	
128	1400 0731	Transistor - 2SD1766	
129	1400 0775	Transistor - 2SC4081	
130	1401 0972	Transistor - 2SB1260	
131	1402 1041	Diode - DA204U	
132	1402 1112	Diode - ERA83-004	
133	1402 1142	Diode Array - DAN217	
134	1402 1336	Diode - 1SS355	
135	1402 1432	Diode - HZS18-1	

Index No.	Part No.	Description	Q'ty Per Assembly
136	1402 1447	Diode - PTZ5.1B	
137	1402 1663	Diode - ZTP12B	
138	1403 0907	Diode - SML-310LT	
139	1403 0944	Photocoupler - PC817X1	
140	1403 0978	LED - SML-310DT	
141	1407 1535	IC - TD62308AP	
142	1407 2187	TTLIC - SN74LS07NS	
143	1407 2218	TTLIC - SN74LS06NS	
144	1407 2219	IC - TD62003AP	
145	1407 3357	Comparator - BA10393F	
146	1407 4649	IC - TC7S32FU	
147	1407 4947	IC - 74LCX244	
148	1407 4948	IC - 74LCX245 TSSOP	
149	1407 4959	IC - MC68334GCFC20	
150	1407 4963	IC - MBM29F800TA-70PFTN	
151	1407 5344	IC - SN74LV02APW	
152	1407 5351	IC - SN74LV14APW	
153	1407 5369	IC - SN74AHCT32PW	
154	1407 5374	IC - SN74LV4052APW	
155	1407 5398	IC - CD4066BNS	
156	1407 5427	IC - 74ACH1G32DCK	
157	1408 0810	IC - BA10358F	
158	1408 0826	IC - TA8428K	
159	1408 0827	IC - TA8429H	
160	1408 0942	IC - BA4558F	
161	1408 1206	Transistor-Array - TD62M4700F	
162	1408 1730	IC - MM1096BF	
163	1503 0460	Oscillator - 32.768KHz	
164	1503 0946	Crystal Oscillator - 9.8304MHz	
165	1503 1004	Oscillator - 19.6608MHz	
166	1601 5319	Resistor-3.9 Ω \pm 5% 2W	
167	1601 7751	Resistor - 4.7K Ω \pm 5%	
168	1601 7752	Resistor Array - 10K Ω \pm 5%	
169	1601 7757	Resistor 0 Ω	
170	1601 7781	Resistor - 10 Ω \pm 5%	

Index No.	Part No.	Description	Q'ty Per Assembly
171	1601 7814	Resistor - 3.3K Ω \pm 5%	
172	1601 7866	Resistor Array - 150 Ω \pm 5%	
173	1601 7867	Resistor - 33 Ω \pm 5% 1/16W	
174	1601 7871	Resistor - 68 Ω \pm 5% 1/16W	
175	1601 7879	Resistor - 22 Ω \pm 5% 1/16W	
176	1601 7899	Resistor Array - 56 Ω \pm 5% 1/16W	
177	1604 4553	Capacitor - 220 μ F \pm 20% 35V	
178	1605 1135	Capacitor - 0.47 μ F \pm 1% 10V	
179	1605 1137	Capacitor - 470pF \pm 10% 50V	
180	1607 0732	Noise Filter - AEF321825-470	
181	1607 0758	Filter - DSS710D223A12-22	
182	1607 0852	Filter - BLM41P750SPB	
183	1607 1021	Filter - MM1608D800B	
184	1610 1374	Resistor - 2.2K Ω \pm 5% 1/2W	
185	1610 1638	Resistor - 10M Ω \pm 1%10W	
186	1631 0000	Resistor - 0 Ω 1/4W	
187	1640 2330	Capacitor - 33UF+80%-20%25V	
188	1640 2470	Capacitor - 47 μ F \pm 20% 25V	
189	1640 3101	Capacitor - 100 μ F \pm 20% 35V	
190	1640 5330	Capacitor - 33 μ F \pm 20% 50V	
191	1640 5470	Capacitor - 47 μ F \pm 20% 50V	
192	1650 2901	Resistor - 100 Ω \pm 5% 1/4W	
193	1650 2951	Resistor - 150 Ω \pm 5% 1/4W	
194	1650 3221	Resistor - 220 Ω \pm 5%1/8W	
195	1650 4100	Resistor - 10 Ω \pm 5% 1/10W	
196	1650 4102	Resistor - 1K Ω \pm 5% 1/10W	
197	1650 4103	Resistor - 10K Ω \pm 5% 1/10W	
198	1650 4112	Resistor - 1.1k Ω \pm 5% 1/10w 1608	
199	1650 4132	Resistor - 1.3K Ω \pm 5% 1/10W 1608	
200	1650 4151	Resistor - 150 Ω \pm 5%1/10W	
201	1650 4154	Resistor 150K Ω \pm 5% 1/10W	
202	1650 4222	Resistor - 2.2K Ω \pm 5%1/10W	
203	1650 4223	Resistor - 22K Ω \pm 5%1/10W	
204	1650 4330	Chip Resistor - 33 Ω \pm 5% 1/10W	
205	1650 4332	Resistor - 3.3K Ω \pm 5%1/10W	

Index No.	Part No.	Description	Q'ty Per Assembly
206	1650 4362	Resistor - 3.6K Ω ±5% 1/10W	
207	1650 4392	Chip Resistor - 3.9k Ω ±5% 1/10W	
208	1650 4472	Resistor - 4.7K Ω ±5% 1/10W	
209	1650 4560	Chip Resistor - 56 Ω ±5% 1/10W	
210	1650 4562	Resistor - 5.6K Ω ±5% 1/10W	
211	1650 4751	Resistor - 750 Ω ±5% 1/10W	
212	1650 4910	Resistor - 91 Ω ±5% 1/10W	
213	1654 1001	Resistor - 1K Ω ±1% 1/10W	
214	1654 1002	Resistor - 10K Ω ±5% 1/10W	
215	1654 1003	Resistor - 100K Ω ±1% 1/10W	
216	1654 1004	Chip Resistor - 1m Ω ±1% 1/10W	
217	1654 1102	Resistor - 11K Ω ±1% 1/10W	
218	1654 1303	Resistor - 130K Ω ±1% 1/10W 1608	
219	1654 1401	Resistor - 1.4K Ω ±1% 1/10W 1608	
220	1654 1501	Resistor - 1.5K Ω ±1% 1/10W 1608	
221	1654 1542	Resistor - 15.4K Ω ±1% 1/10W 1608	
222	1654 1911	Resistor - 1.91K Ω ±1% 1/10W 1608	
223	1654 3601	Resistor - 3.6K Ω ±1% 1/10W	
224	1654 3602	Resistor - 36K Ω ±1% 1/10W 1608	
225	1654 3903	Resistor - 390K Ω ±1% 1/10W	
226	1654 4702	Chip Resistor - 47k Ω ±1% 1/10W	
227	1654 4990	Resistor - 499 Ω ±1% 1/10W	
228	1654 5231	Resistor - 5.23K Ω ±1% 1/10W	
229	1654 5360	Resistor - 536 Ω ±1% 1/10W 1608	
230	1654 8203	Resistor - 820K Ω ±1% 1/10W 1608	
231	1654 9109	Resistor - 91 Ω ±1% 1/10W	
232	1660 2101	Capacitor - 100pF - ±10% - 50V	
233	1660 2150	Capacitor - 15pF ±5% 50V	
234	1660 2220	Capacitor - 22pF ±20% 35V	
235	1660 2270	Capacitor - 27pF ±20% 35V	
236	1660 2330	Capacitor - 33pF - ±5% - 50V	
237	1660 2391	Capacitor - 390pF ±5% 50V	
238	1660 2470	Capacitor - 47pF ±5% 50V	
239	1660 4102	Capacitor - 1000pF ±10% 50V	
240	1660 4222	Capacitor - 2200pF - ±10% - 50V	

Index No.	Part No.	Description	Q'ty Per Assembly
241	1660 4472	Capacitor - 4700pF±10% 50V	
242	1660 6103	Capacitor - 10000pF - +80%-20%50V	
243	1660 6473	Capacitor - 47000pF +80,-20% 50V	
244	1660 8104	Capacitor - 0.1 μ F+80-20% 25V	
245	1902 0042	RAM-1M X8 70NS TSOP G2	

68.IPU BOARD (B064/B065)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C100	211	C110	210	C120	162	C130	209	C140	210	C150	211	C160	210
C101	209	C111	211	C121	210	C131	210	C141	205	C151	210	C161	211
C102	168	C112	205	C122	205	C132	205	C142	211	C152	205	C162	211
C103	167	C113	164	C123	211	C133	211	C143	211	C153	205	C163	205
C104	211	C114	211	C124	210	C134	164	C144	205	C154	210	C164	205
C105	211	C115	205	C125	205	C135	205	C145	210	C155	211	C165	211
C106	205	C116	210	C126	211	C136	211	C146	162	C156	205	C166	211
C107	210	C117	211	C127	167	C137	211	C147	211	C157	210	C167	211
C108	211	C118	205	C128	211	C138	205	C148	205	C158	211	C168	211
C109	205	C119	164	C129	168	C139	164	C149	211	C159	205	C169	211

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C170	211	C180	210	C211	210	C221	164	C231	210	C241	205	C251	208
C171	211	C181	211	C212	205	C222	205	C232	205	C242	211	C252	166
C172	211	C182	211	C213	211	C223	211	C233	211	C243	210	C253	211
C173	205	C183	211	C214	167	C224	211	C234	211	C244	210	C254	205
C174	205	C184	211	C215	211	C225	205	C235	205	C245	211	C255	211
C175	211	C185	211	C216	168	C226	210	C236	211	C246	211	C256	211
C176	205	C186	211	C217	209	C227	162	C237	211	C247	211	C257	160
C177	210	C187	211	C218	210	C228	211	C238	210	C248	211	C258	204
C178	211	----	----	C219	205	C229	205	C239	205	C249	205	C259	204
C179	205	C190	----	C220	211	C230	164	C240	205	C250	211	C260	204

68.IPU BOARD (B064/B065)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C261	199	C271	162	C281	205	C291	164	C301	164	C311	205	C321	211
C262	211	C272	211	C282	211	C292	210	C302	211	C312	164	C322	205
C263	205	C273	210	C283	164	C293	205	C303	----	C313	210	C323	164
C264	205	C274	205	C284	205	C294	211	C304	211	C314	211	C324	211
C265	211	C275	211	C285	211	C295	167	C305	160	C315	211	C325	205
C266	211	C276	167	C286	211	C296	211	C306	211	C316	205	C326	----
C267	211	C277	211	C287	205	C297	----	C307	211	C317	164	C327	211
C268	205	C278	168	C288	210	C298	----	C308	205	C318	211	C328	211
C269	210	C279	209	C289	211	C299	211	C309	164	C319	205	C329	200
C270	211	C280	210	C290	205	C300	205	C310	211	C320	----	C330	200

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C331	211	C341	211	C351	211	C361	211	C371	202	C381	202	C391	202
C332	200	C342	211	C352	205	C362	161	C372	202	C382	202	C392	202
C333	200	C343	200	C353	211	C363	205	C373	202	C383	202	C393	202
C334	200	C344	210	C354	----	C364	211	C374	202	C384	202	C394	202
C335	----	C345	211	C355	211	C365	205	C375	202	C385	202	C395	202
C336	----	C346	205	C356	210	C366	211	C376	202	C386	202	C396	211
C337	211	C347	211	C357	161	C367	205	C377	202	C387	202	C397	211
C338	211	C348	205	C358	161	C368	211	C378	202	C388	202	C398	165
C339	211	C349	211	C359	207	C369	205	C379	202	C389	202	-----	-----
C340	211	C350	205	C360	161	C370	211	C380	202	C390	202	-----	-----

68.IPU BOARD (B064/B065)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
----	----	C421	168	C431	203	C441	210	C451	210	C461	210	C471	211
----	----	----	----	C432	203	C442	205	C452	205	----	----	C472	210
----	----	C423	211	C433	203	C443	205	C453	210	----	----	C473	210
----	----	C424	210	C434	203	C444	210	C454	205	C464	211	C474	210
----	----	C425	205	C435	205	C445	210	C455	210	C465	210	C475	210
C416	169	C426	205	C436	210	C446	210	C456	211	C466	205	C476	210
C417	210	C427	206	C437	205	C447	205	C457	210	C467	205	C477	210
----	----	C428	206	C438	205	C448	205	C458	210	C468	211	C478	210
----	----	C429	206	C439	210	C449	210	C459	205	C469	164	C479	205
C420	201	C430	206	C440	210	C450	205	C460	205	C470	164	C480	205

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C481	205	C491	211	C501	205	C511	205	C521	205	C531	162	C541	205
C482	211	C492	205	C502	211	C512	211	C522	211	C532	211	----	----
C483	205	C493	205	C503	211	C513	211	C523	211	C533	162	C543	211
C484	211	C494	211	C504	205	C514	205	C524	205	C534	211	C544	210
C485	211	C495	211	C505	205	C515	205	C525	205	C535	163	C545	205
C486	205	C496	205	C506	211	C516	211	C526	211	C536	210		
C487	211	C497	211	C507	205	C517	205	C527	211	C537	205		
C488	211	C498	211	C508	205	C518	205	C528	211	C538	210		
C489	205	C499	205	C509	211	C519	211	C529	211	C539	205		
C490	205	C500	211	C510	211	C520	211	C530	211	C540	210		

68.IPU BOARD (B064/B065)

CONNECTOR

SYMBOL NO.	INDEX NO.
CN340	120
CN341	116
CN342	119
CN343	118
CN344	117
CN345	121
CN346	112
CN347	113
CN348	111
CN349	115

DIODE

SYMBOL NO.	INDEX NO.
CN351	115
CN352	115
CN353	115
CN355	114
CN356	115
CN357	115

SYMBOL NO.	INDEX NO.
D100	126

SYMBOL NO.	INDEX NO.
DB100	127

FILTER

SYMBOL NO.	INDEX NO.
FIL100	170
FIL101	170
FIL102	170
FIL103	170
FIL104	170

SYMBOL NO.	INDEX NO.
FIL105	170
FIL106	----
FIL107	170
FIL108	----
FIL109	170

SYMBOL NO.	INDEX NO.
FIL110	170
FIL111	170
FIL112	170
FIL113	----
FIL114	170

SYMBOL NO.	INDEX NO.
FIL115	170
FIL116	170
FIL117	170
FIL118	170
FIL119	----

SYMBOL NO.	INDEX NO.
----	----
FIL121	170
FIL122	170
FIL123	170
FIL124	170

SYMBOL NO.	INDEX NO.
FIL125	170
FIL126	170
FIL127	170
FIL128	170
FIL129	170

SYMBOL NO.	INDEX NO.
FIL130	170
FIL131	171
FIL132	170
FIL133	170
FIL134	170

SYMBOL NO.	INDEX NO.
FIL135	170
FIL136	170
FIL137	170
FIL138	170
FIL139	170

FILTER

SYMBOL NO.	INDEX NO.
FIL140	170
FIL141	170
FIL142	170
FIL143	170
FIL144	170
FIL145	170
FIL146	170
FIL147	170

IC

SYMBOL NO.	INDEX NO.
IC101	3
IC102	130
IC103	2
IC104	1
IC105	142
IC106	142
IC107	142
----	----
IC109	142
IC110	212

SYMBOL NO.	INDEX NO.
IC111	212
IC112	212
IC113	212
IC114	212
IC115	212
IC116	212
IC117	212
IC118	136
IC119	131
----	----

SYMBOL NO.	INDEX NO.
IC121	143
----	----
IC123	138
----	----
IC125	135
IC126	135
IC127	139
----	----
IC129	132
IC130	139

SYMBOL NO.	INDEX NO.
IC131	145
IC132	132
IC133	134
IC134	137
IC135	140
IC136	133
IC137	141

JP

SYMBOL NO.	INDEX NO.
JP101	193
JP102	193
JP103	172
----	----
JP105	193
JP106	193
JP107	193
JP108	193
JP109	193
JP110	193

SYMBOL NO.	INDEX NO.
JP111	193
JP112	193
JP113	193
JP114	193
JP115	193
JP116	193
JP117	193
JP118	193
JP119	193
JP120	193

68.IPU BOARD (B064/B065)

JP

SYMBOL NO.	INDEX NO.
JP121	193
JP122	193
JP123	193
JP124	193
JP125	193
JP126	193
JP127	193
JP128	193
JP129	----
JP130	----

SYMBOL NO.	INDEX NO.
JP131	----
JP132	193
JP133	173
JP134	193
JP135	193
JP136	193
JP137	----
JP138	----
JP139	----
JP140	----

SYMBOL NO.	INDEX NO.
JP141	----
JP142	----
JP143	----
JP144	----
JP145	193

LED

SYMBOL NO.	INDEX NO.
LED101	128
LED102	129
LED103	129
LED104	128

OSC

SYMBOL NO.	INDEX NO.
OSC100	149
OSC101	148
OSC102	147

RESISTOR

SYMBOL NO.	INDEX NO.
----	----
----	----
----	----
R104	191
R105	182
----	----
----	----
R108	177
R109	177
R110	177

SYMBOL NO.	INDEX NO.
R111	177
R112	176
R113	176
----	----
R115	177
R116	177
R117	177
R118	177
R119	182
R120	191

Q

SYMBOL NO.	INDEX NO.
Q1	125

RESISTOR

SYMBOL NO.	INDEX NO.
R121	176
R122	176
R123	176
R124	177
R125	185
R126	187
R127	187
R128	174
R129	174
R130	187

IC

SYMBOL NO.	INDEX NO.
R131	187
R132	174
R133	174
R134	177
R135	177
R136	178
R137	188
R138	188
R139	180
R140	178

SYMBOL NO.	INDEX NO.
R141	188
R142	188
R143	180
R144	178
R145	188
R146	188
R147	180
R148	178
R149	188
R150	188

SYMBOL NO.	INDEX NO.
R151	180
R152	178
R153	188
R154	188
R155	180
R156	178
R157	188
R158	188
R159	180
----	----

SYMBOL NO.	INDEX NO.
----	----
----	----
----	----
----	----
R170	182
R171	191
R172	176
R173	176
R174	177
R175	176

SYMBOL NO.	INDEX NO.
R176	177
R177	187
R178	187
R179	185
R180	187
R181	174
R182	174
R183	178
R184	188
R185	188

SYMBOL NO.	INDEX NO.
R186	180
R187	178
R188	188
R189	188
R190	180
R191	178
R192	188
R193	188
R194	180
R195	178

68.IPU BOARD (B064/B065)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R196	188	R206	185	R216	190	R226	176	R236	191	----	----	R256	175
R197	188	R207	185	R217	189	R227	177	----	----	R247	191	R257	183
R198	180	R208	177	R218	189	R228	177	----	----	R248	191	R258	183
R199	198	R209	176	R219	190	R229	177	R239	----	R249	191	R259	176
R200	194	R210	174	R220	176	R230	191	R240	185	R250	191	R260	185
R201	184	R211	174	R221	176	R231	191	R241	185	R251	191	R261	187
R202	189	R212	176	R222	177	R232	191	R242	191	R252	181	R262	185
R203	177	R213	174	R223	182	R233	191	R243	191	R253	182	R263	177
R204	177	R214	187	R224	191	R234	191	R244	185	R254	183	----	----
R205	185	----	----	R225	176	----	----	R245	185	R255	183	R265	176

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R266	187	R276	187	R286	196	R296	185	R306	185	R316	185	R341	177
R267	187	R277	187	R287	176	R297	185	R307	185	R317	185	R342	177
R268	185	----	----	R288	195	R298	185	R308	185	R318	185	----	----
R269	185	R279	176	R289	197	R299	185	R309	185	R319	185	R344	176
R270	183	R280	185	R290	194	R300	185	R310	185	R320	176	R345	187
R271	176	R281	176	R291	187	R301	185	R311	185	R321	176	----	----
----	----	R282	176	R292	178	R302	185	R312	185	R322	191	R347	177
----	----	----	----	R293	179	R303	185	R313	185	R323	186	R348	----
R274	176	R284	178	R294	176	R304	185	R314	185	----	----	R349	177
R275	176	----	----	R295	185	R305	185	R315	185	R325	186	----	----

68.IPU BOARD (B064/B065)

RESISTOR

SYMBOL NO.	INDEX NO.
----	----
----	----
R352	177
R353	176
R354	176
----	----
----	----
R356	185
----	----
----	----
----	----

SYMBOL NO.	INDEX NO.
R360	191
R361	191
----	----
R363	191
----	----
R365	177
R366	177
R367	180
R368	180
R369	191

SYMBOL NO.	INDEX NO.
R370	177
R371	177
R372	177
R373	185
R374	191
----	----
R375	177
R376	191
R377	186
R378	185
R379	191

SYMBOL NO.	INDEX NO.
R380	174
R381	174
R382	174
R383	191
R384	186
----	----
R385	185
R386	191
R387	191
R388	191
R389	191

SYMBOL NO.	INDEX NO.
R390	174
R391	191
R392	191
R393	191
R394	191
----	----
R395	191
R396	191
R397	191
R398	192
R399	192

SYMBOL NO.	INDEX NO.
R400	176
R401	177
R402	174

REG

SYMBOL NO.	INDEX NO.
REG100	146
REG101	144

RN

SYMBOL NO.	INDEX NO.
RN100	151
RN101	151
RN102	157
RN103	157
RN104	157
----	----
RN105	151
RN106	151
RN107	155
RN108	155
RN109	155

RN

SYMBOL NO.	INDEX NO.
RN110	155
RN111	155
RN112	152
RN113	152
RN114	152
----	----
RN115	152
RN116	152
RN117	151
RN118	151
RN119	151

SYMBOL NO.	INDEX NO.
RN120	151
RN121	151
RN122	151
RN123	151
RN124	151
----	----
RN125	151
RN126	151
RN127	151
RN128	157
RN129	157

SYMBOL NO.	INDEX NO.
RN130	157
RN131	152
RN132	152
RN133	152
RN134	152
----	----
RN135	152
RN136	151
RN137	151
RN138	150
RN139	152

SYMBOL NO.	INDEX NO.
RN140	152
RN141	152
RN142	152
RN143	152
----	----
----	----
RN152	152
RN153	152
RN154	152
RN155	152

SYMBOL NO.	INDEX NO.
RN156	152
RN157	151
RN158	157
RN159	157
RN160	157
----	----
RN161	157
RN162	157
RN163	151
RN164	151
RN165	151

SYMBOL NO.	INDEX NO.
RN166	151
RN167	151
RN168	151
RN169	151
RN170	157
----	----
RN171	157
RN172	157
RN173	151
RN174	151
RN175	151

SYMBOL NO.	INDEX NO.
RN176	151
RN177	151
----	----
RN179	151
RN180	151
----	----
RN181	151
RN182	151
RN183	151
RN184	151
RN185	151

68.IPU BOARD (B064/B065)

RN

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
RN186	151	RN196	156	RN206	150	RN216	154	RN226	156	RN236	156	RN246	156
RN187	151	RN197	152	RN207	154	RN217	154	RN227	156	RN237	156	RN247	156
RN188	151	RN198	156	RN208	154	RN218	157	RN228	156	RN238	156	RN248	156
RN189	151	RN199	156	RN209	154	RN219	151	RN229	156	RN239	156	RN249	156
RN190	157	RN200	155	RN210	154	RN220	156	RN230	156	RN240	156	RN250	156
RN191	157	RN201	156	RN211	154	RN221	156	RN231	156	RN241	156	RN251	156
RN192	157	RN202	156	RN212	154	RN222	156	RN232	156	RN242	156	RN252	159
RN193	156	RN203	----	RN213	154	RN223	156	RN233	156	RN243	156	RN253	159
RN194	156	RN204	156	RN214	154	RN224	156	RN234	156	RN244	156	RN254	159
RN195	156	RN205	152	RN215	154	RN225	156	RN235	156	RN245	156	RN255	159

RN

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
RN256	159	RN266	152	RN276	153	RN286	----	RN296	157	SW100	124	TP1	110
RN257	159	RN267	152	RN277	153	RN287	----	RN297	157	SW102	122	TP2	110
RN258	159	RN268	152	RN278	153	RN288	----	RN298	157	SW103	123	TP3	110
RN259	159	RN269	----	RN279	153	RN289	153	RN299	152			TP4	110
RN260	159	RN270	153	RN280	158	RN290	153	RN300	152			TP5	110
RN261	159	RN271	153	RN281	158	RN291	153	RN301	152			TP6	110
RN262	159	RN272	153	RN282	158	RN292	153	RN302	151			TP7	110
RN263	159	RN273	153	RN283	158	RN293	157	RN303	151			TP9	110
RN264	152	RN274	153	RN284	----	RN294	157						
RN265	152	RN275	153	RN285	----	RN295	157						

SW

TP

68.IPU BOARD (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
*	B065 5144	IPU Board	1
1	B065 5147	IC - CDIC3	1
2	B065 5158	IC - RF5C608	1
3	B065 5169	IC - GARAC	1
102	B065 5147	IC - CDIC3	1
103	B065 5158	IC - RF5C608	1
104	B065 5169	IC - GARAC	1
106	0313 0100B	Philips Pan Head Screw - M3x10	
107	0710 0030B	Hexagon Nut - M3	
108	1005 0955	Heat Sink	

Index No.	Part No.	Description	Q'ty Per Assembly
109	1005 0978	SP513K	
110	1100 1649	Testpin - HK-3-S	
111	1102 6600	Connector - 8P	
112	1102 7626	Connector - TX25-80P-LT-N1	
113	1102 8553	Connector - 3-353308-6	
114	1102 8725	Connector - FFC/FPC-FH12-10S-0.5SH	
115	1102 8727	Connector - FFC/FPC-FH12-28S-0.5SH	
116	1102 8774	Connector - 55456-2030	
117	1102 8775	Connector - 55456-1830	
118	1102 8776	Connector - 55456-1330	
119	1102 8777	Connector - 55456-1230	
120	1102 8779	Connector - 1-353530-0	
121	1102 9066	Connector - 55456-0430	
122	1204 1542	DIP Switch	
123	1204 2373	Key Board Switch - SKQDPA	
124	1204 2507	Switch SSSS810700	
125	1401 1202	Fet - HAT1023R	
126	1402 1503	Diode - 1SS400	
127	1402 1578	Diode - YG802C04R	
128	1403 0907	Diode - SML-310LT	
129	1403 0953	LED - SML-310MT	
130	1407 5990	IC - DS90CF364MTD	
131	1407 5287	Clock Generator - W180-03G	
132	1407 5334	IC - CMOS LOGIC 74LVC244A TSSOP	
133	1407 5347	IC - SN74LV08APW	
134	1407 5351	IC - SN74LV14APW	
135	1407 5353	IC - SN74LV244APW	
136	1407 5361	IC - 74LVC157A TSSOP	
137	1407 5364	IC - SN74AHCT244PW	
138	1407 5469	IC - SN74LV07APW	
139	1407 5705	IC - SN74LVC06APW	
140	1407 5709	IC - MK1705A	
141	1407 5742	IC - ICS553MI	
142	1407 5743	IC - RF5V860	
143	1408 1095	IC - BA10324AF	

Index No.	Part No.	Description	Q'ty Per Assembly
144	1408 1508	Series Regulator - PQ07VZ012Z	
145	1408 1746	IC - PST623XW	
146	1408 1747	Regulator - PQ5EV7L	
147	1503 1089	Oscillator - 85.2MHz	
148	1503 1090	Oscillator - 21.176MHz	
149	1503 1091	Oscillator - 10MHz	
150	1601 7877	Resistor Array 4.7k Ω \pm 5% 1/32W	
151	1601 7887	Resistor Array - 10K Ω \pm 5% 1/32W	
152	1601 7898	Resistor Array	
153	1601 7900	Resistor Array - 0 Ω \pm 5%	
154	1601 7913	Resistor 22 Ω \pm 5% 1/32W	
155	1601 7914	Resistor Array - 47 Ω \pm 5%	
156	1601 7943	Resistor Array - 68 Ω \pm 5% 1/32W	
157	1601 7959	Resistor	
158	1601 7960	Resistor Array - 100 Ω \pm 5% 1/16W	
159	1601 7981	Resistor Array - 100K Ω \pm 5% 1/16W	
160	1604 4306	Capacitor	
161	1604 4848	Capacitor - 100 μ F \pm 20% 10V	
162	1604 4987	Capacitor - 330 μ F \pm 20% 6.3V	
163	1604 5082	Capacitor - 330 μ F \pm 20% 10V	
164	1605 0976	Capacitor - 1 μ F+80% -20% 10V	
165	1605 1161	Capacitor - 0.33 μ F \pm 10% 10V	
166	1605 1167	Capacitor - 0.22 μ F \pm 10% 10V	
167	1605 1181	Capacitor - 10 μ F+80-20% 10V	
168	1605 1187	Ceramic Capacitor 0.047 μ F \pm 10% 50V	
169	1605 1224	Capacitor 4.7 μ F \pm 10% 6.3V	
170	1607 0861	Filter - BK2125HS101	
171	1607 1061	Filter - BLM11P300SPB	
172	1610 1218	Resistor	
173	1633 0000	Resistor - 0 Ω 1/10W	
174	1650 4100	Resistor - 10 Ω \pm 5% 1/10W	
175	1650 4101	Resistor - 100 Ω \pm 5% 1/10W	
176	1650 4102	Resistor - 1K Ω \pm 5% 1/10W	
177	1650 4103	Resistor - 10K Ω \pm 5% 1/10W	
178	1650 4104	Resistor - 100K Ω \pm 5% 1/10W	

Index No.	Part No.	Description	Q'ty Per Assembly
179	1650 4114	Resistor - 110K Ω \pm 5% 1/10W 1608	
180	1650 4150	Resistor - 15 Ω \pm 5% 1/10W	
181	1650 4200	Resistor - 20 Ω \pm 5% 1/10W	
182	1650 4202	Resistor - 2K Ω \pm 5% 1/10W	
183	1650 4220	Chip Resistor - 22 Ω \pm 5% 1/10W	
184	1650 4242	Resistor - 2.4K Ω \pm 5% 1/10W 1608	
185	1650 4330	Chip Resistor - 33 Ω \pm 5% 1/10W	
186	1650 4470	Resistor - 47 Ω \pm 5% 1/10W	
187	1650 4472	Resistor - 4.7K Ω \pm 5% 1/10W	
188	1650 4510	Resistor - 51 Ω \pm 5% 1/10W	
189	1650 4511	Resistor - 510 Ω \pm 5% 1/10W	
190	1650 4621	Resistor - 620 Ω \pm 5% 1/10W 1608	
191	1650 4680	Resistor - 68 Ω \pm 5% 1/10W	
192	1650 4750	Resistor - 75 Ω \pm 5% 1/10W	
193	1654 0000	Resistor - 0 Ω 1608	
194	1654 1001	Resistor - 1K Ω \pm 1% 1/10W	
195	1654 1201	Resistor - 1.2K Ω \pm 1% 1/10W	
196	1654 2201	Resistor - 2.2K Ω \pm 1% 1/10W 1608	
197	1654 4420	Resistor 442 Ω \pm 1% 1/10W 1608	
198	1654 4990	Resistor - 499 Ω \pm 1% 1/10W	
199	1660 0100	Capacitor - 10PF \pm 0.5pF 50V	
200	1660 2101	Capacitor - 100pF - \pm 10% - 50V	
201	1660 2221	Capacitor - 220pF +80-20% 50V	
202	1660 2330	Capacitor - 33pF - \pm 5% - 50V	
203	1660 2331	Capacitor - 330pF \pm 5% 50V	
204	1660 2470	Capacitor - 47pF \pm 5% 50V	
205	1660 2471	Capacitor - 470pF - \pm 5% - 50V	
206	1660 4102	Capacitor - 1000pF \pm 10% 50V	
207	1660 4103	Capacitor - 10000pF - \pm 10% - 50V	
208	1660 4222	Capacitor - 2200pF - \pm 10% - 50V	
209	1660 4472	Capacitor - 4700pF \pm 10% 50V	
210	1660 6103	Capacitor - 10000pF - +80%-20% 50V	
211	1660 8104	Capacitor - 0.1 μ F+80-20% 25V	
212	1907 0015	SDRAM - 256MB 4MX16X4 100MHz	

69.GW BOARD (B064/B065)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C1	161	C11	166	C21	164	C31	166	C41	166	C51	166	C61	166
C2	161	---	---	C22	166	C32	164	C42	154	C52	164	C62	152
C3	161	---	---	C23	166	C33	166	C43	166	C53	164	C63	166
C4	164	C14	164	C24	153	C34	166	C44	154	C54	166	C64	164
C5	166	C15	165	C25	157	C35	164	C45	166	C55	166	C65	166
C6	164	C16	152	C26	166	C36	164	C46	164	C56	164	C66	164
C7	166	C17	166	C27	166	C37	166	C47	166	C57	164	C67	164
C8	164	C18	166	C28	166	C38	166	C48	152	C58	166	C68	166
C9	166	C19	164	C29	153	C39	164	C49	154	C59	166	C69	164
C10	164	C20	166	C30	164	C40	154	C50	166	C60	164	C70	166

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C71	164	C81	154	C91	162	C101	168	C111	159	---	---	C131	166
C72	166	C82	153	C92	162	C102	166	C112	159	---	---	C132	166
C73	166	C83	166	C93	164	C103	166	---	---	---	---	C133	166
C74	164	C84	153	C94	162	C104	166	---	---	---	---	C134	166
C75	166	C85	164	C95	162	C105	166	---	---	C125	167	C135	166
C76	164	C86	166	C96	164	C106	166	C116	197	C126	201	C136	153
C77	153	C87	153	C97	166	C107	166	C117	201	C127	197	C137	166
C78	163	C88	153	C98	153	C108	153	C118	167	---	---	C138	164
C79	199	C89	164	C99	168	C109	166	---	---	---	---	C139	152
C80	166	C90	152	C100	168	C110	164	---	---	---	---	C140	166

69.GW BOARD (B064/B065)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C141	166	C151	156	C161	156	C171	202	C181	156	C191	200	C201	200
C142	166	C152	168	C162	166	C172	202	C182	202	C192	197	C202	197
C143	168	C153	163	C163	164	C173	161	C183	200	C193	197	C203	200
C144	168	C154	166	C164	166	C174	197	C184	197	C194	200	C204	202
C145	168	C155	163	C165	166	C175	200	C185	197	C195	202	C205	156
C146	166	C156	168	C166	156	C176	202	C186	200	C196	156	C206	202
C147	156	C157	156	C167	202	C177	156	C187	202	C197	202	C207	202
C148	168	C158	166	C168	200	C178	202	C188	156	C198	202	C208	202
C149	163	C159	163	C169	197	C179	202	C189	156	C199	157	C209	202
C150	166	C160	168	C170	202	C180	202	C190	202	C200	202	C210	156

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C211	202	C221	202	C231	200	C241	197	C251	155	C261	164	C271	166
C212	200	C222	155	C232	201	C242	197	C252	202	C262	164	C272	164
C213	197	C223	201	C233	155	C243	200	C253	202	C263	164	C273	166
C214	155	C224	200	C234	155	C244	201	C254	202	C264	164	----	----
C215	201	C225	197	C235	201	C245	155	C255	202	C265	164	----	----
C216	200	C226	202	C236	200	C246	202	C256	202	C266	164	C276	158
C217	197	C227	202	C237	197	C247	202	C257	197	C267	164	C277	162
C218	202	C228	202	C238	155	C248	197	C258	200	C268	164	C278	198
C219	202	C229	202	C239	201	C249	200	C259	201	C269	166	C279	165
C220	202	C230	197	C240	200	C250	201	C260	155	C270	164	C280	168

69.GW BOARD (B064/B065)

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C281	166	C291	201	C301	201	C311	201	C321	166	---	---	C341	166
C282	166	C292	201	C302	201	C312	199	C322	164	C332	158	C342	166
C283	166	C293	201	C303	199	C313	201	C323	166	---	---	C343	166
C284	166	C294	199	C304	201	C314	199	C324	158	C334	158	C344	166
C285	166	C295	199	C305	199	C315	201	C325	158	C335	160	C345	166
C286	166	C296	199	C306	201	C316	201	C326	158	C336	158	C346	166
C287	201	C297	201	C307	199	C317	201	---	---	C337	158	C347	166
C288	199	C298	199	C308	201	C318	199	---	---	C338	158	C348	166
C289	201	C298	201	C309	199	C319	164	---	---	---	---	C349	166
C290	199	C300	199	C310	201	C320	164	C330	158	C340	166	C350	166

CAPACITOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
C351	166	C361	164	C371	166	CN300	111	CN310	109	D2	118	FIL1	170
C352	166	C362	166	C372	166	CN301	111	CN311	112	D3	120	FIL2	170
C353	166	C363	166	C373	166	CN302	108	CN312	106	D4	121	FIL3	170
C354	166	C364	166	C374	166	CN303	108	CN313	101	D5	119	FIL4	172
C355	166	C365	166	C375	166	CN304	110	CN314	103	D6	119	FIL5	170
C356	166	C366	166	C376	166	CN305	105	CN315	104			FIL6	170
C357	166	C367	166	C377	201	CN306	102					FIL7	172
C358	166	C368	166	C378	200	CN307	107					FIL8	169
C359	166	C369	166	C379	199	CN308	107					----	----
C360	166	C370	166	----	----	CN309	107					FIL10	169

CONNECTOR

DIODE

FILTER

69.GW BOARD (B064/B065)

FILTER

SYMBOL NO.	INDEX NO.
----	----
FIL12	170
FIL13	170
FIL14	170
FIL15	170
FIL16	170
FIL17	170
FIL18	170
FIL19	170
FIL20	170

SYMBOL NO.	INDEX NO.
FIL21	170
FIL22	170
FIL23	170
FIL24	170
FIL25	170
FIL26	170
FIL27	170
FIL28	170
FIL29	170
FIL30	170

SYMBOL NO.	INDEX NO.
FIL31	170
----	----
SYMBOL NO.	INDEX NO.
FU1	114

IC

SYMBOL NO.	INDEX NO.
IC1	203
IC2	203
IC3	203
IC4	203
IC6	130
IC7	113
IC8	123
IC9	129
IC10	129

SYMBOL NO.	INDEX NO.
IC11	125
IC12	127
IC13	131
IC14	130
IC15	125
IC16	126
IC17	128
IC18	128
IC19	125
IC20	133

SYMBOL NO.	INDEX NO.
IC21	134
IC22	1
IC23	137
IC24	136
IC25	141
IC26	135
IC27	135
IC28	143
IC29	136
IC30	137

SYMBOL NO.	INDEX NO.
IC31	124
IC32	129
IC33	128
IC34	128
IC36	132
IC37	130
----	----
----	----
----	----

JP

SYMBOL NO.	INDEX NO.
JP2	174
JP3	174
JP4	173
JP5	174
JP6	174
JP7	174
JP10	173
JP12	174
JP14	174
JP16	174

SYMBOL NO.	INDEX NO.
JP17	174
JP18	174
JP19	174
JP20	174
JP25	174
JP26	174
JP37	174
JP42	174

L

SYMBOL NO.	INDEX NO.
L1	171

LED

SYMBOL NO.	INDEX NO.
LED1	122
LED2	122

OSC

SYMBOL NO.	INDEX NO.
OSC1	144
OSC2	145

Q

SYMBOL NO.	INDEX NO.
Q1	116
Q2	117

RESISTOR

SYMBOL NO.	INDEX NO.
----	----
----	----
R3	185
R4	185
R5	185
R6	177
R7	177
R8	177
R9	187
R10	187

SYMBOL NO.	INDEX NO.
----	----
----	----
----	----
R14	177
R15	185
R16	185
R17	178
R18	187
R19	187
R20	187

SYMBOL NO.	INDEX NO.
R21	187
R22	178
R23	187
R24	187
R25	187
R26	187
----	----
----	----
R29	177
R30	177

69.GW BOARD (B064/B065)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R31	177	R41	193	R51	185	R61	177	R71	183	R81	178	----	----
R32	177	R42	194	R52	185	R62	183	R72	183	R82	187	----	----
R33	177	R43	176	R53	184	R63	183	R73	183	R83	187	----	----
R34	177	----	----	R54	188	R64	183	R74	183	R84	187	R94	187
R35	177	----	----	R55	189	R65	183	R75	183	R85	187	R95	177
R36	177	R46	187	R56	176	R66	183	R76	178	R86	187	----	----
R37	177	R47	187	R57	189	R67	183	R77	178	----	----	----	----
----	----	R48	187	R58	189	R68	183	R78	187	----	----	R98	183
----	----	R49	185	R59	177	R69	183	R79	187	----	----	R99	183
R40	185	R50	185	R60	177	R70	183	R80	187	----	----	R100	183

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R101	183	R111	183	R121	183	R131	177	R141	186	R151	186	R161	183
R102	183	R112	183	R122	183	R132	177	R142	186	R152	186	R162	183
R103	183	R113	183	R123	183	R133	177	R143	186	R153	186	R163	183
R104	183	R114	183	R124	183	R134	177	R144	186	R154	190	R164	183
R105	183	R115	183	----	----	R135	177	R145	187	R155	190	R165	183
R106	183	R116	183	----	----	R136	177	R146	187	R156	190	R166	183
R107	183	R117	183	R127	146	R137	177	R147	186	R157	183	R167	183
R108	183	R118	183	R128	177	R138	177	R148	189	R158	183	R168	183
R109	183	R119	183	R129	196	R139	185	R149	186	R159	183	R169	183
R110	183	R120	183	R130	195	R140	187	R150	186	R160	183	R170	183

69.GW BOARD (B064/B065)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R171	183	R181	187	R191	177	R201	187	R211	194	R221	181	----	----
R172	183	R182	187	R192	185	R202	187	R212	193	----	----	----	----
R173	183	R183	187	R193	185	R203	187	----	----	----	----	----	----
R174	183	R184	176	R194	185	R204	187	----	----	----	----	R234	177
R175	183	----	----	R195	176	R205	187	R215	177	----	----	R235	177
R176	183	R186	177	R196	185	R206	187	----	----	R226	177	R236	177
R177	183	R187	176	R197	185	R207	187	R217	181	R227	177	R237	180
R178	183	R188	176	R198	187	R208	187	R218	181	----	----	R238	183
R179	183	R189	185	R199	187	R209	187	R219	181	----	----	R239	180
R180	183	R190	175	R200	187	R210	187	R220	181	----	----	R240	183

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R241	183	R251	191	R261	191	R271	191	R281	191	R291	177	R301	177
R242	183	R252	191	R262	191	R272	191	R282	191	R292	177	R302	187
R243	183	R253	191	R263	191	R273	191	R283	191	R293	177	R303	185
R244	187	R254	191	R264	191	R274	191	R284	191	R294	187	----	----
----	----	R255	191	R265	191	R275	191	R285	191	R295	187	R305	187
----	----	R256	191	R266	191	R276	191	R286	191	R296	177	R306	177
R247	191	R257	191	R267	191	R277	191	R287	191	R297	177	R307	177
R248	191	R258	191	R268	191	R278	191	R288	191	R298	177	R308	177
R249	191	R259	191	R269	191	R279	191	R289	191	R299	177	----	----
R250	191	R260	191	R270	191	R280	191	R290	191	R300	177	R310	179

69.GW BOARD (B064/B065)

RESISTOR

SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.	SYMBOL NO.	INDEX NO.
R311	179	R321	185	R331	187	R341	182	R351	189	----	----	R371	177
R312	177	R322	185	R332	185	R342	186	R352	189	R362	183	R372	177
R313	177	R323	185	R333	185	R343	187	R353	177	R363	183	R373	180
R314	192	R324	185	R334	185	----	----	R354	189	R364	183	R374	177
R315	192	R325	187	R335	177	R345	186	R355	189	R365	187	R375	183
R316	176	R326	187	R336	177	----	----	R356	189	R367	177	R376	176
R317	185	R327	185	R337	187	R347	187	R357	189	----	----	R377	183
R318	185	R328	187	R338	185	R348	189	R358	189	R368	177	R378	177
R319	185	R329	185	R339	185	R349	177	R359	183	R369	177	R379	183
R320	185	R330	185	R340	182	R350	177	R360	177	----	----	R380	176

RESISTOR

SYMBOL NO.	INDEX NO.
R381	177
R382	183
R383	183
R384	183
----	----
R386	186
R387	176
R389	177

REG

SYMBOL NO.	INDEX NO.
REG1	139
REG2	140
REG3	142
REG4	138

RN

SYMBOL NO.	INDEX NO.
RN1	150
RN2	150
RN3	147
RN4	147
RN5	147
RN6	147
RN7	147
RN8	147
RN9	150
RN10	150

SYMBOL NO.	INDEX NO.
RN11	147
RN12	147
RN13	148
RN14	148
RN15	148
RN16	148
RN17	148
RN18	149
RN19	149
RN20	149

SYMBOL NO.	INDEX NO.
RN21	149
RN22	149
RN23	149
RN24	149
RN25	149
RN26	149
RN27	151
RN28	151
RN29	151
RN30	151

SYMBOL NO.	INDEX NO.
RN31	151
RN32	151
RN33	151
RN34	151
RN35	151
RN36	151
RN37	151
RN38	151
RN39	151
RN40	151

SYMBOL NO.	INDEX NO.
RN41	151
RN42	151
RN43	151
RN44	151

SW

SYMBOL NO.	INDEX NO.
SW2	115

69.GW BOARD (B064/B065)

Rev. 02/05/2003

Index No.	Part No.	Description	Q'ty Per Assembly
*	B065 5111	Controller Board	1
1	B065 5113	IC - ASIC MARIMBA3	1


Index No.	Part No.	Description	Q'ty Per Assembly
101	1102 3566	Connector - S8B-XH-A(8PIN)	
102	1102 5303	Connector - 4P	
103	1102 6295	Connector - 2P	
104	1102 6328	Connector - 2P	
105	1102 8091	Connector - 53505-4010	
106	1102 8153	Connector - FCN-568P068-G/05A-V4	
107	1102 8357	Connector - 52777-0809	
108	1102 9349	Connector DIMM	
109	1102 8631	Connector	
110	1102 8656	Connector - TX25-120P-LT-H1	
111	1102 8832	Connector - DM-3D4-B3210	
112	1102 8988	Connector	
113	1104 0589	DIP Socket - 32P	
114	1107 0555	Fuse - 4A	
115	1204 2571	DIP Switch - 2.54P	
116	1401 1136	Fet - HAT1020R	
117	1401 1175	Fet - HAT1043M	
118	1402 1265	Diode - RB411D	
119	1402 1342	Diode - 1SR154-400	
120	1402 1343	Diode - RB106L-40	
121	1402 1546	Diode - RB081	
122	1403 0987	LED SML-211UT	
123	1407 2187	TTLIC - SN74LS07NS	
124	1407 2218	TTLIC - SN74LS06NS	
125	1407 5275	CMOS Logic - 74LVCHR16245A TSSOP	
126	1407 5300	CMOS Logic - 74LVC16244A TSSOP	
127	1407 5321	CMOS Logic - 74LVCH16374A TSSOP	
128	1407 5334	IC - CMOS LOGIC 74LVC244A TSSOP	
129	1407 5364	IC - SN74AHCT244PW	
130	1407 5366	IC - 74LVC08A TSSOP	
131	1407 5485	IC - SN74VC574APW	
132	1407 5517	IC - 74AHCT14PW	
133	1407 5523	ROM - I2C SOP 3V	
134	1407 5694	CPU RM7000A-400T-REV1.34	
135	1407 5717	IC - ICS960001AF	




Index No.	Part No.	Description	Q'ty Per Assembly
136	1408 1273	IC - RN5VD28A	
137	1408 1398	Detector - RN5VD42A	
138	1408 1507	Regulator - PQ05VY3H3Z	
139	1408 1528	Regulator - PQ05VY053Z	
140	1408 1529	DC Converter - ITC1622CSB	
141	1408 1596	IC - RN5VD15A	
142	1408 1640	Series Regulator - PQ070XH02Z	
143	1408 1657	IC - RN5VD20A	
144	1503 0842	Oscillator - 14.31818MHz	
145	1503 1045	Oscillator - 24MHz	
146	1600 1880	Resistor - 25M $\Omega \pm 1\%$ 1W	
147	1601 7915	Resistor Array - 33 $\Omega \pm 5\%$ 1/16W	
148	1601 7918	Resistor - 22 $\Omega \pm 5\%$ 1/16W	
149	1601 7926	Resistor - 68 $\Omega \pm 5\%$ 1/16W 8	
150	1601 7929	Resistor Array - 100K $\Omega \pm 5\%$ 1/16W	
151	1601 7987	Resistor Array - 82 $\Omega \pm 5\%$ 1/16W	
152	1604 4728	Capacitor - 100 μ F $\pm 20\%$ 16V	
153	1604 4994	Capacitor - 100 μ F $\pm 20\%$ 6.3V	
154	1605 1081	Capacitor - 10 μ F+80-20% 25V	
155	1605 1124	Capacitor - 4.7 μ F+80 -20% 10V	
156	1605 1132	Capacitor - 2.2 μ F+80-20% 16V	
157	1605 1181	Capacitor - 10 μ F+80-20% 10V	
158	1605 1200	Capacitor - 10PF ± 0.5 pF 50V	
159	1605 1201	Capacitor - 12pF $\pm 5\%$ 50V	
160	1605 1202	Capacitor - 15pF $\pm 5\%$ 50V	
161	1605 1205	Capacitor - 33pF $\pm 5\%$ 50V	
162	1605 1207	Capacitor - 68pF $\pm 5\%$ 50V	
163	1605 1211	Capacitor - 220pF $\pm 10\%$ 50V	
164	1605 1214	Capacitor - 1000pF $\pm 10\%$ 50V	
165	1605 1216	Capacitor - 2200pF $\pm 10\%$ 50V	
166	1605 1221	Capacitor - 0.1 UF+80-20%16V	
167	1605 1224	Capacitor 4.7 μ F $\pm 10\%$ 6.3v	
168	1605 1252	Capacitor - 0.01 μ F+80-20% 50V	
169	1607 1061	Filter - BLM11P300SPB	
170	1607 1206	Filter - ACC2012L-250	

Index No.	Part No.	Description	Q'ty Per Assembly
171	1607 1212	Inductor - CDRH6D38-5R0NC	
172	1607 1225	Filter - ACC4516L-700	
173	1632 0000	Resistor - 0 Ω 1/8W	
174	1634 0000	Resistor - 0 Ω 1/16W	
175	1650 4101	Resistor - 100 $\Omega \pm 5\%$ 1/10W	
176	1650 4102	Resistor - 1K $\Omega \pm 5\%$ 1/10W	
177	1650 4103	Resistor - 10K $\Omega \pm 5\%$ 1/10W	
178	1650 4104	Resistor - 100K $\Omega \pm 5\%$ 1/10W	
179	1650 4109	Resistor - 1 $\Omega \pm 5\%$ 1/10W	
180	1650 4120	Resistor - 12 $\Omega \pm 5\%$ 1/10W	
181	1650 4150	Resistor - 15 $\Omega \pm 5\%$ 1/10W	
182	1650 4182	Resistor - 1.8K $\Omega \pm 5\%$ 1/10W	
183	1650 4220	Chip Resistor - 22 $\Omega \pm 5\%$ 1/10W	
184	1650 4222	Resistor - 2.2K $\Omega \pm 5\%$ 1/10W	
185	1650 4330	Chip Resistor - 33 $\Omega \pm 5\%$ 1/10W	
186	1650 4470	Resistor - 47 $\Omega \pm 5\%$ 1/10W	
187	1650 4472	Resistor - 4.7K $\Omega \pm 5\%$ 1/10W	
188	1650 4562	Resistor - 5.6K $\Omega \pm 5\%$ 1/10W	
189	1650 4680	Resistor - 68 $\Omega \pm 5\%$ 1/10W	
190	1650 4820	Resistor - 82 $\Omega \pm 5\%$ 1/10W	
191	1650 5680	Resistor - 68 $\Omega \pm 5\%$ 1/16W	
192	1654 1801	Resistor - 1K $\Omega \pm 1\%$ 1/10W	
193	1654 1801	Resistor - 1.2K $\Omega \pm 1\%$ 1/10W	
194	1654 2001	Chip Resistor - 2k $\Omega \pm 1\%$ 1/10W	
195	1654 7502	Resistor - 75K $\Omega \pm 1\%$ 1/10W	
196	1654 9532	Resistor - 98.3K $\Omega \pm 1\%$ 1/10W 1608	
197	1660 2221	Capacitor - 220pF +80-20% 50V	
198	1660 2331	Capacitor - 330pF $\pm 5\%$ 50V	
199	1660 2471	Capacitor - 470pF - $\pm 5\%$ - 50V	
200	1660 4102	Capacitor - 1000pF $\pm 10\%$ 50V	
201	1660 6103	Capacitor - 10000pF - +80%-20%50V	
202	1660 8104	Capacitor - 0.1 μ F+80-20% 25V	
203	1906 0017	Flash Memory - LH28F320BJ-PBTL70	


70.DECAL AND DOCUMENTS (B064/B065)




70.DECAL AND DOCUMENTS (B064/B065)
















70.DECAL AND DOCUMENTS (B064/B065)

Rev. 02/28/2003

Index No.	Part No.	Description	Q'ty Per Assembly
1	A029 2984	Decal - Grip	1
2	A096 6677	Decal - Right Paper Set	1
3	A096 6678	Decal - Left Paper Set	1
4	A294 1378	Decal - Total Counter	1
5	AA00 0059	Caution Decal - English	1
6	AA00 1213	Decal - B2	1
7	AA00 1394	Decal - Toner Supply	1
8	AA00 2010	Decal - Paper Level	1
9	AA00 2246	Decal - Caution	1
10	AA00 2258	Decal - Paper Size LT	1
10	AA00 2259	Decal - Paper Size - A4	1
11	AA00 2261	Decal - Universal Tray	1
12	B065 1361	Decal - Misfeed Removal	1
13	B065 1363	Decal - Main Switch	1
13	B065 1364	Decal - Main Switch	1
14	B065 1366	Decal - Toner Supply	1
15	B065 1367	Decal - Front Door	1
16	B065 1779	Decal - Scale (LT)	1
16	B065 1778	Decal - Scale (A4)	1
17	B065 2746	Decal - Paper Set	1
18	B065 3699	Decal - Release Lever	1
19	B065 4167	Decal - Fusing Knob	1
20	B065 4274	Decal - Misfeed Removal	1
21	B065 4480	Decal - Cover	1
22	B065 4481	Decal - Exit	1
23	B065 4798	Caution Decal - Duplex	1
24	B065 4867	Decal - Guide Plate Lever	1
25	B065 6545	Decal - Positioning	1
26	B065 6635	Decal - Paper Tray 1	1
27	B065 6636	Decal - Paper Tray 2	1
28	B065 6637	Decal - Paper Tray 3	1
29	B065 6846	Decal - Paper Set - Left	1
30	B065 6877	Decal - Paper Set - Right	1
31	B065 8490	Decal Sheet - Paper Size	1
32	B477 4311	Decal - Original Base	1

Index No.	Part No.	Description	Q'ty Per Assembly
33	B477 4331	Decal - Original Size	1
34	B477 4352	Decal - Misfeed Removal	1
35	B477 4362	Decal - Misfeed Removal - Exit	1
36	B477 4381	Caution Decal - CIS	1
37	B477 4391	Decal - Exposure Glass Cleaning	1
38	B477 4431	Decal - Original Table	1
39	G029 1982	LD - Decal	1
40	G564 6076	Decal - Exposure Glass	1
41	B065 1369	Decal - Cleaning	1
42	B070 1307	Caution Decal - Paper Set	1
43	B064 6607	Operating Instructions - Copy NA English	1
43	B064 7207	Operating Instructions - Main NA English	1
44	B065 3833	Decal - Transfer Unit Lever	1
45	B065 3342	Decal - Toner Supply	1

71.SPECIAL TOOLS (B064/B065)

1	2	3	4
			
5	6	7	
			

71.SPECIAL TOOLS (B064/B065)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A006 9104	Adjusting Scanner Pin (4pcs/set)	1
2	A292 9500	Test Chart - S5S (10 Pcs/set)	1
3	N803 6701	Flash Memory Card-4MB	1
4	N803 1000	Case - Flash Memory Card	1
5	A257 9300	Grease - Barrierta S552R	1
6	5203 9502	Grease 501	1
7	A029 9387	Digital Multimeter - Fluke87	1

Index No.	Part No.	Description	Q'ty Per Assembly






B064/B065 PARTS INDEX

KASUN
Best Solution





This section instructs you as the numbers and names of parts on this machine.



PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.
EXTERIOR 2 (B064/B065)	AA01 0114	Ozone Filter (TOP)	Front Ozone Filter	1	17- 23
DF ORIGINAL FEED 2 (B064/B065)	A806 1321	Pick-up Roller	Pickup Roller	1	25- 6
	A806 1295	Paper Feed Belt	Feed Belt	1	25- 22
DF ORIGINAL TRANSFER 4 (B064/B065)	A859 2241	Separation Roller	Reverse Roller	1	33- 10
PAPER FEED UNIT 1 (B064/B065)	AF03 1065	Feed Roller	Pare Feed Roller	1	63- 3
	AF03 0051	Pick-up Roller	Pick-up Roller	1	63- 1
PAPER FEED UNIT 2 (B064/B065)	AF03 2050	Separation Roller	Separation Roller	1	65- 36
PAPER REGISTRATION 1 (B064/B065)	AF03 1066	Paper Feed Rollers	Paper Feed Roller (By-pass)	1	69- 11
	AF03 0050	Pick-up Roller	Pick-up Roller (By-pass)	1	69- 17
PAPER REGISTRATION 2 (B064/B065)	AF03 2050	Separation Roller	Separation Roller	1	71- 15
TONER SUPPLY UNIT (B064/B065)	B065 3131	Toner Separation Case	Toner Separation Case	1	77- 1
DEVELOPMENT UNIT 1 (B064/B065)	AA01 2060	Development Filter	Development Filter	1	79- 17
PCU 1 (B064/B065)	A096 2063	Charge Wire Cleaning Pad	Corona Wire Cleaner	1	83- 7
	AD02 0053	Charge Corona Wire	Charge Corona Wire	1	83- 19
	A096 2057	Charge Corona Grid	Charge Corona Grid	1	83- 28
PCU 2 (B064/B065)	AA01 2060	Development Filter	Development Filter	1	85- 9
PCU 3 (B064/B065)	B065 2347	Cleaning Brush	Cleaning Brush	1	87- 7
PCU 4 (B064/B065)	AD04 1083	Cleaning Blade	Cleaning Blade	1	89- 8
TRANSFER BELT UNIT 1 (B064/B065)	A293 3899	Transfer Belt	Transfer Belt - Mojito Service	1	91- 5
	B065 3947	Discharge Plate	Anti-static Plate	1	91- 21
TRANSFER BELT UNIT 2 (B064/B065)	AD04 1076	Cleaning Roller Cleaning Blade	Cleaning Roller Cleaning Blade	1	93- 1
FUSING UNIT 1 (B064/B065)	AE03 1026	Bushing - Oil Supply Roller	Bushing - Oil Supply Roller	1	95- 9
	AE04 0038	Cleaning Web Pressure Roller	Cleaning Web Pressure Roller	1	95- 14
	AE04 5046	Cleaning Web	Cleaning Web	1	95- 16
FUSING UNIT 2 (B064/B065)	AE04 4043	Hot Roller Strippers	Hot Roller Stripper	5	97- 27
FUSING UNIT 3 (B064/B065)	AE03 0017	Hot Roller Bearing	Ball Bearing - 35x50x10	2	99- 2
	AE01 1069	Hot Roller	Hot Roller	1	99- 23
	AE03 0018	Pressure Roller Bearing	Ball Bearing - 12x28x8	2	99- 26
	AE02 0112	Pressure Roller	Pressure Roller	1	99- 27
FUSING UNIT 4 (B064/B065)	AE03 1024	Pressure Cleaning Roller Bearings	Bushing - M4x7	2	101- 9
	AE04 2052	Pressure Cleaning Roller	Cleaning Roller	1	101- 10

Parts Index

Part No.	Description	Page and Index No.
B064 5855	PCB Cover	125 - 4
B064 6607	Operating Instructions - Copy NA English	175 - 43
B064 7012	Model Name Plate (B064 RIC)	15 - 12
B064 7018	Model Name Plate (B064 LAN)	15 - 12
B064 7019	Model Name Plate (B064 INF)	15 - 12
B064 7207	Operating Instructions - Main NA English	175 - 43
B064 9099	Total Counter	127 - 33
B064 9510	Drum	85 - 25
B065 1070	Upper Front Stay	43 - 15
B065 1075	Base Cover	141 - 22
B065 1077	Right Stay	137 - 19
B065 1078	Left Stay	141 - 23
B065 1084	Positioning Plate	121 - 20
B065 1091	Left Duct - PCU	139 - 19
B065 1092	Bracket	141 - 13
B065 1093	ADF Bracket	43 - 14
B065 1094	Duct Clip	139 - 18
B065 1095	Heat Insulation	139 - 20
B065 1096	Front Transfer Stay	139 - 3
B065 1098	Left Rail	139 - 22
B065 1110	Main Motor	121 - 19
B065 1122	Tightener Bracket	121 - 18
B065 1131	Joint	121 - 28
B065 1134	Partition Plate	121 - 11
B065 1137	Bracket	121 - 8
B065 1140	Drum Shaft	121 - 9
B065 1145	Boss	121 - 12
B065 1147	Transfer Drive Bracket	121 - 25
B065 1149	Transfer Drive Joint	121 - 26
B065 1154	Electrode Plate	121 - 6
B065 1157	Toner Recycling Bracket	119 - 15
B065 1160	Toner Recycling Tightener	119 - 17
B065 1162	Fusing Motor Bracket	119 - 22
B065 1164	Tightener	119 - 20
B065 1166	Duplex Drive Shaft	119 - 26

Part No.	Description	Page and Index No.
B065 1167	Duplex Drive Joint	119 - 27
B065 1168	Fusing Drive Bracket	119 - 11
B065 1171	Development Fan Bracket	45 - 9
B065 1172	Development Fan Harness	45 - 18
B065 1173	Ips Duct	137 - 24
B065 1175	Entrance IPS Duct	129 - 4
B065 1177	Upper Ips Duct	129 - 7
B065 1178	Fan Bracket - IPS	129 - 2
B065 1180	PCU Duct	131 - 11
B065 1183	Fan Bracket	131 - 2
B065 1184	Entrance PCU Duct	131 - 3
B065 1185	Duct - Charge	137 - 10
B065 1188	Duct - Fusing	137 - 7
B065 1192	Upper Exhaust Duct	129 - 9
B065 1193	Lower Exhaust Duct	129 - 10
B065 1194	Exhaust Bracket	129 - 8
B065 1195	Duplex Fan Bracket	141 - 20
B065 1197	Magnet Catch Bracket	141 - 8
B065 1198	Duplex Fan Harness	141 - 18
B065 1223	Lower Hinge	15 - 9
B065 1237	Exhaust Cover Duct	17 - 25
B065 1241	Operation Panel Inner Cover	17 - 20
B065 1244	Upper Left Cover	17 - 27
B065 1301	Front Door	15 - 6
B065 1302	Upper Right Cover	17 - 28
B065 1303	LCT Cover	17 - 30
B065 1304	Upper Left Cover	17 - 9
B065 1305	Upper Rear Cover	17 - 21
B065 1306	Lower Right Cover	17 - 32
B065 1307	Lower Left Cover	17 - 6
B065 1308	Lower Rear Cover	17 - 26
B065 1309	Upper Rear Cover	17 - 16
B065 1310	Upper Right Cover	17 - 31
B065 1311	Upper Left Cover	17 - 10
B065 1312	Operation Inner Cover	17 - 13

Part No.	Description	Page and Index No.
B065 1313	PCU Inner Cover	15 - 17
B065 1314	Lower Right Inner Cover	15 - 23
B065 1315	Inner Cover - Main Switch	15 - 14
B065 1316	Fusing Inner Cover	15 - 15
B065 1318	PCU Duct Inner Cover	15 - 19
B065 1320	Receiving Tray - Operation Panel	137 - 4
B065 1323	Guide Plate Lever	15 - 10
B065 1325	Main Switch Cover	15 - 8
B065 1326	Micro Switch Lever	15 - 11
B065 1327	Door Catch	15 - 7
B065 1328	Upper Hinge Guide Plate	137 - 16
B065 1329	Upper Right Door Seal	15 - 3
B065 1332	Louver	17 - 19
B065 1341	Connector Cap	17 - 33
B065 1342	Coupling Cap	17 - 34
B065 1343	NCU Cap	17 - 29
B065 1344	G4 Cap	17 - 8
B065 1345	Fan Bracket	17 - 15
B065 1361	Decal - Misfeed Removal	175 - 12
B065 1361	Decal - Misfeed Removal	15 - 2
B065 1363	Decal - Main Switch (NA/ASIA/KOR)	15 - 13
B065 1363	Decal - Main Switch	175 - 13
B065 1364	Decal - Main Switch	175 - 13
B065 1364	Decal - Main Switch (EU/CHN/TWN)	15 - 13
B065 1366	Decal - Toner Supply	15 - 5
B065 1366	Decal - Toner Supply	175 - 14
B065 1367	Decal - Front Door	15 - 22
B065 1367	Decal - Front Door	175 - 15
B065 1369	Decal - Cleaning	15 - 32
B065 1369	Decal - Cleaning	175 - 41
B065 1404	Operation Panel Ass'y - A4	19 - 1
B065 1406	Operation Panel Ass'y - LT	19 - 1
B065 1408	Operation Panel Ass'y (TWN)	19 - 1
B065 1414	Operation Panel Ass'y (ASIA)	19 - 1
B065 1416	Operation Panel Ass'y (CHN9	19 - 1

Part No.	Description	Page and Index No.
B065 1418	Operation Panel Ass'y (KOR)	19 - 1
B065 1422	Right Operation PCB Ass'y	19 - 12
B065 1423	Left Operation PCB	19 - 5
B065 1425	Operation Panel Case - LT	19 - 26
B065 1427	Operation Panel Case - A4	19 - 26
B065 1429	LCD	19 - 8
B065 1439	Keytop - Reset Switch	19 - 16
B065 1440	Keytop - 10key	19 - 4
B065 1441	Keytop - Start	19 - 21
B065 1442	Keytop - Clear/Stop	19 - 22
B065 1443	Keytop - Sample Print	19 - 20
B065 1444	Keytop - Power Source	19 - 18
B065 1446	Keytop - Function	19 - 17
B065 1447	Keytop - Counter	19 - 15
B065 1448	Cap - Application	19 - 2
B065 1451	Lens - Application	19 - 25
B065 1454	Sheet - Right Operation	19 - 11
B065 1455	Sheet - Power Source	19 - 19
B065 1456	Sheet - Left Operation	19 - 3
B065 1457	Sheet - Touch Panel	19 - 14
B065 1458	LCD Long Sheet	19 - 10
B065 1459	LCD Short Sheet	19 - 9
B065 1460	Keytop - Application - LT	19 - 23
B065 1461	Keytop - Display - LT	19 - 24
B065 1462	Keytop - Application - A4	19 - 23
B065 1463	Keytop - Display - A4	19 - 24
B065 1470	LCDC Bracket	19 - 7
B065 1682	Front Frame	49 - 27
B065 1685	Rear Frame	49 - 8
B065 1688	Lens Holder Block	49 - 23
B065 1691	Polygon Motor Cover	45 - 1
B065 1698	Development Cooling Duct	45 - 11
B065 1706	Bracket - Scanner Motor	49 - 14
B065 1708	Stepper Motor	49 - 16
B065 1711	Drive Shaft	49 - 24

Part No.	Description	Page and Index No.
B065 1712	Front Wire Tension Bracket	49 - 26
B065 1713	Rear Wire Tension Bracket	49 - 6
B065 1715	Scanner Wire	49 - 5
B065 1717	Timing Belt	49 - 20
B065 1718	Screw - M4X8	49 - 19
B065 1721	Image Scanning Board	45 - 6
B065 1731	1st Scanner Unit	47 - 25
B065 1732	1st Scanner Frame	47 - 19
B065 1733	1st Scanner Front Side Plate	47 - 14
B065 1734	1st Scanner Rear Side Plate	47 - 17
B065 1735	Reflector	47 - 11
B065 1736	Invertor Cover	47 - 12
B065 1737	Clamp	47 - 15
B065 1738	Spring Plate	47 - 20
B065 1740	Harness Plate	47 - 16
B065 1741	Harness Guide	47 - 13
B065 1742	Insulator	47 - 24
B065 1743	1st Mirror	47 - 18
B065 1751	2nd Scanner Unit	47 - 8
B065 1753	Adjusting Plate	47 - 7
B065 1766	Second Mirror	47 - 6
B065 1772	Left Scale	43 - 7
B065 1773	Scale Bracket Seal	43 - 23
B065 1775	Sheet Through Scale (LT)	43 - 10
B065 1776	Sheet Through Scale (A4)	43 - 10
B065 1778	Decal - Scale (A4)	43 - 11
B065 1778	Decal - Scale (A4)	175 - 16
B065 1779	Decal - Scale (LT)	43 - 11
B065 1779	Decal - Scale (LT)	175 - 16
B065 1782	Seal	43 - 4
B065 1783	Exposure Glass	43 - 6
B065 1784	Ground Plate	43 - 5
B065 1785	Right Stay	43 - 16
B065 1787	Scale Bracket	43 - 3
B065 1788	Printing Rear Scale	43 - 19

Part No.	Description	Page and Index No.
B065 1791	Left Scanner Duct	45 - 4
B065 1797	Scanner Duct Filter	45 - 3
B065 1801	Right Scanner Duct	45 - 5
B065 1825	H.P. Sensor Bracket	49 - 11
B065 1830	Scanner Board Guide	49 - 3
B065 1831	Scanner Board Bracket	49 - 4
B065 1833	Harness Bracket	45 - 10
B065 1834	Insulating Sheet	45 - 19
B065 1841	Inner Cover	43 - 17
B065 1843	Grounding Plate	43 - 22
B065 1844	Grounding Plate	137 - 26
B065 1845	Grounding Plate	137 - 25
B065 1859	LD Unit	51 - 6
B065 1912	Lens Holder - L0	51 - 8
B065 1915	1st Mirror Holder	51 - 11
B065 1925	Lens Holder - L2 Right	51 - 17
B065 1926	Lens Holder - L2 Left	51 - 18
B065 1930	2nd Mirror Holder	51 - 20
B065 1932	Middle Mirror Holder	51 - 21
B065 1940	Shield Glass Rail	51 - 27
B065 1944	Shield Glass Holder	51 - 25
B065 1945	Seal - Shield Glass	51 - 26
B065 1946	Seal - Shield Glass Holder	51 - 24
B065 1950	Seal - 1	51 - 7
B065 1951	Seal - 2	51 - 3
B065 1952	Seal - 3	51 - 15
B065 1953	Seal - 4	51 - 23
B065 1955	Seal - Lens L1	51 - 14
B065 1957	Shield Glass Cover	85 - 26
B065 2270	Upper PCU Ass'y	85 - 8
B065 2300	Lower PCU Casing	87 - 15
B065 2314	Blade Bracket	89 - 12
B065 2316	Front Blade Seal	89 - 11
B065 2317	Rear Blade Seal	89 - 13
B065 2337	Pick-off Pawl Holder	89 - 6

Part No.	Description	Page and Index No.
B065 2342	Pick-off Pawl Shaft	89 - 17
B065 2344	Pick-off Pawl Bracket	89 - 26
B065 2347	Cleaning Brush	87 - 7
B065 2353	Blade Bracket	87 - 16
B065 2358	Bracket Grounding Bracket	89 - 32
B065 2361	Entrance Seal Holder	89 - 23
B065 2362	Cleaning Entrance Seal	89 - 24
B065 2364	Pick-off Pawl Positioning Plate	89 - 22
B065 2366	Front Shaft	87 - 8
B065 2369	Grounding Plate - Entrance Seal	89 - 29
B065 2371	Drum Stay	85 - 16
B065 2377	Toner Recycling Connecting Shaft	85 - 14
B065 2381	Grounding Plate	89 - 25
B065 2386	Middle PCU Casing	89 - 15
B065 2389	Shaft Bracket	89 - 16
B065 2391	Upper PCU Casing	85 - 2
B065 2392	Receptacle	85 - 7
B065 2399	Joint - Toner Separation	85 - 22
B065 2400	Toner Recycling Joint	85 - 20
B065 2401	Toner Recycling Pipe	85 - 21
B065 2406	Toner Separation Shutter	85 - 23
B065 2410	Drum Shaft Knob	83 - 1
B065 2413	Entrance Transfer Stay	87 - 19
B065 2421	Agitator Shaft	87 - 2
B065 2422	Agitator Cleaning	87 - 23
B065 2423	Release Cam - Cleaning Blade	85 - 27
B065 2424	Cam Spring	85 - 28
B065 2425	Brush Roller Gear	87 - 5
B065 2426	Pressure Release Lever	85 - 10
B065 2427	Cam - Blade	87 - 22
B065 2428	Agitator Gear	87 - 4
B065 2481	Grid Receptacle Terminal	121 - 2
B065 2482	Charge Receptacle Terminal	121 - 3
B065 2494	Upper PCU Harness	85 - 3
B065 2495	Lower PCU Harness	89 - 20

Part No.	Description	Page and Index No.
B065 2496	PCU Connecting Harness	139 - 21
B065 2600	Rear Paper Feed Side Plate	73 - 35
B065 2605	Front Paper Feed Side Plate	73 - 34
B065 2607	Front Support Plate	73 - 33
B065 2608	Development Connector Bracket	69 - 6
B065 2613	Upper Registration Roller	71 - 6
B065 2614	Front Upper Guide Plate	69 - 7
B065 2617	Lower Registration Roller	71 - 5
B065 2620	Paper Dust Removal Case	69 - 4
B065 2621	Sensor Bracket	69 - 3
B065 2647	Registration Guide Plate	73 - 9
B065 2655	Guide Plate Solenoid	73 - 30
B065 2660	Paper Feed Cover	61 - 5
B065 2662	Magnet Catch Bracket	61 - 6
B065 2665	Relay Guide Plate	73 - 20
B065 2671	Duplex Exit Guide Plate	73 - 15
B065 2673	Upper Exit Guide Plate	73 - 26
B065 2675	LCT Guide Plate	73 - 23
B065 2682	Paper Feed Stay	69 - 9
B065 2688	Pick-up Roller Arm	69 - 15
B065 2690	Pick-up Roller Solenoid	69 - 20
B065 2699	Separation Roller Stay	71 - 18
B065 2701	Lower Guide Plate - By-pass	71 - 8
B065 2703	Bracket - Brake Peen	71 - 31
B065 2707	Paper End Sensor Bracket	71 - 24
B065 2708	Middle Sensor Bracket	71 - 23
B065 2709	Reverse Pressure Lever	71 - 27
B065 2713	Drive Reverse Shaft	71 - 12
B065 2714	Separation Roller Shaft	71 - 17
B065 2721	Paper Feed Guide Plate - By-pass	61 - 4
B065 2729	Paper End Feeler	61 - 3
B065 2730	By-pass Table	61 - 8
B065 2732	Manual Feed Table	61 - 13
B065 2733	By-pass Table Cover	61 - 19
B065 2735	Rear Side Fence - By-pass	61 - 12

Part No.	Description	Page and Index No.
B065 2737	Front Side Fence - By-pass	61 - 10
B065 2738	Front Support Stay - By-pass	61 - 14
B065 2740	Rear Support Stay - By-pass	61 - 15
B065 2741	Sensor Bracket	61 - 16
B065 2743	Front Shaft - By-pass	61 - 1
B065 2746	Decal - Paper Set	175 - 17
B065 2746	Decal - Paper Set	61 - 9
B065 2752	Motor Bracket	71 - 28
B065 2754	Tightener Bracket	73 - 31
B065 2761	By-pass Harness	73 - 27
B065 2762	Relay Paper Feed Harness	73 - 21
B065 2762	Relay Paper Feed Harness	117 - 2
B065 2762	Relay Paper Feed Harness	123 - 32
B065 2763	Relay Registration Harness	69 - 1
B065 3050	Development Unit	79 - 1
B065 3060	Lower Development Casing	81 - 7
B065 3062	Development Roller	81 - 1
B065 3065	Toner Sensor Guide	79 - 5
B065 3069	Bushing - 8mm	81 - 3
B065 3071	Development Knob	79 - 7
B065 3073	Gear - 31Z	79 - 12
B065 3076	Gear - 41Z	79 - 8
B065 3077	Development Roller Adjuster	81 - 4
B065 3079	Ball Bearing Bracket	79 - 16
B065 3080	Ball Bearing - 12x21x5	81 - 2
B065 3081	Gear - 21Z	79 - 15
B065 3082	Development Bias Plate	79 - 5
B065 3091	Entrance Seal	79 - 4
B065 3095	Development Guide Rail	79 - 2
B065 3096	Gear - 20Z	79 - 14
B065 3098	Gear - 17Z	79 - 11
B065 3099	Front Drum Seal	79 - 3
B065 3100	Rear Drum Seal	79 - 6
B065 3110	Toner Supply Unit	77 - 18
B065 3120	Right Upper Case Seal	77 - 6

Part No.	Description	Page and Index No.
B065 3121	Left Upper Case Seal	77 - 29
B065 3122	Toner Separation Joint Seal	77 - 2
B065 3123	Rear Toner Separation Joint Seal	77 - 3
B065 3125	Toner Separation Drive Shaft	77 - 4
B065 3138	Idle Gear	77 - 9
B065 3139	Toner Collection Gear	77 - 10
B065 3140	Upper Cover	77 - 19
B065 3141	Exit Toner Pile	77 - 20
B065 3142	Toner Separation Shutter	77 - 22
B065 3143	Toner Separation Spring	77 - 21
B065 3146	Nut	77 - 14
B065 3151	Lower Right Case Seal	77 - 17
B065 3152	Lower Front Case Seal - Rear	77 - 15
B065 3153	Lower Filter Case Filter	77 - 16
B065 3161	Toner Separation Case	77 - 1
B065 3251	Development Unit Rail	139 - 5
B065 3252	Right Rail - Drum Unit	139 - 9
B065 3253	Upper Development Drum Stay	139 - 4
B065 3258	Development Drum Stay	83 - 2
B065 3262	Electrode Plate	121 - 7
B065 3266	Toner Bottle Cam	137 - 15
B065 3267	Inner Back Cam	137 - 14
B065 3271	Lower Stay	75 - 31
B065 3273	Upper Stay	75 - 28
B065 3301	Drive Bottle	75 - 39
B065 3304	Bottle Holder	75 - 14
B065 3307	Toner Bottle Gear	75 - 16
B065 3309	Toner Bottle Drive Bracket	75 - 2
B065 3311	Toner Bottle Turn Bracket	75 - 6
B065 3316	Hinge Bracket	75 - 29
B065 3551	Toner Collection Ass'y - Transfer	123 - 37
B065 3552	Toner Outlet Sub-Unit: Transfer:Ass'y	123 - 23
B065 3557	Toner Catchpan	123 - 6
B065 3559	Base	123 - 21
B065 3561	Spring	123 - 13

Part No.	Description	Page and Index No.
B065 3565	Toner Collection Case	123 - 3
B065 3566	Toner Receiving Spring	123 - 5
B065 3568	Case Cap	123 - 1
B065 3570	Toner Transport Coil	123 - 16
B065 3573	Toner Collection Agitator	123 - 2
B065 3581	Bushing	123 - 15
B065 3583	Spring Guide	123 - 17
B065 3585	Screw Gear	123 - 11
B065 3586	Screw Gear	123 - 18
B065 3587	Toner Collection Gear	123 - 14
B065 3588	Toner Collection Idle Gear	123 - 8
B065 3590	Toner Collection Shaft	123 - 9
B065 3593	Toner Collection Discharge Harness	123 - 22
B065 3601	Toner Collection Pipe	123 - 26
B065 3604	Toner Separation Shaft	123 - 38
B065 3609	Toner Separation Shaft - Long	123 - 7
B065 3610	Toner Collection Shaft	123 - 35
B065 3629	Toner Separation Case	123 - 39
B065 3636	Toner Collection Seal	123 - 40
B065 3637	Seal - 40x68	123 - 42
B065 3638	Transport Screw	123 - 33
B065 3645	Toner Collection Seal	123 - 41
B065 3649	Toner Collection Case - Transport	123 - 29
B065 3650	Toner Collection Joint	123 - 30
B065 3652	Shield Plate	123 - 28
B065 3654	Toner Collection Cap	123 - 25
B065 3656	Toner Collection Seal - Transport	123 - 24
B065 3660	Pulley	123 - 27
B065 3681	Toner Collection Bottle	17 - 3
B065 3689	Toner Collection Bottle Bracket	17 - 1
B065 3695	Bottle Guide	133 - 9
B065 3699	Decal - Release Lever	175 - 18
B065 3699	Decal - Release Lever	15 - 16
B065 3710	Toner Collection Coil - Exit	77 - 7
B065 3811	Transfer Unit Stay	139 - 15

Part No.	Description	Page and Index No.
B065 3812	Transfer Rely Harness	139 - 16
B065 3815	Front Middle Channel	139 - 23
B065 3818	Transfer Unit Guide Plate	91 - 1
B065 3820	Positioning Plate - Transfer Unit	139 - 24
B065 3827	Handle Stay	139 - 11
B065 3831	Release Positioning Plate	139 - 25
B065 3832	Transfer Unit Lever	139 - 1
B065 3833	Decal - Transfer Unit Lever	139 - 26
B065 3833	Decal - Transfer Unit Lever	175 - 44
B065 3837	Heater Holder	139 - 13
B065 3838	Heat Insulation Heater	139 - 14
B065 3850	Transfer Unit	91 - *
B065 3865	Transfer Belt Frame	91 - 14
B065 3866	Drive Roller	91 - 6
B065 3868	Pressure Arm	91 - 12
B065 3870	Bias Roller	91 - 9
B065 3872	Transfer Unit Joint	91 - 8
B065 3873	Toner Collection Gear	91 - 2
B065 3874	Electrode Plate	91 - 11
B065 3875	Terminal	91 - 10
B065 3876	Bias Electrode Plate	91 - 15
B065 3879	Bias Terminal	91 - 16
B065 3906	Transfer Unit Casing	93 - 21
B065 3911	Toner Collection Coil - Transfer	93 - 10
B065 3914	Transfer Agitator	93 - 13
B065 3918	Toner Collection Gear Coil	93 - 15
B065 3920	Idle Gear - 1	93 - 19
B065 3921	Idle Gear - 2	93 - 20
B065 3922	Electrode Plate Cover	93 - 18
B065 3928	Cleaning Roller Terminal	93 - 16
B065 3942	Guide Plate	91 - 20
B065 3945	Entrance Seal Holder	91 - 22
B065 3947	Anti-static Plate	91 - 21
B065 3950	Grounding Bracket	91 - 17
B065 3955	Entrance Guide Plate	93 - 25

Part No.	Description	Page and Index No.
B065 3961	Shaft	93 - 6
B065 3962	Spring Plate	93 - 2
B065 3963	Lever	93 - 4
B065 3964	Bushing	93 - 5
B065 3965	Lever Shaft	93 - 3
B065 3966	Solenoid	93 - 28
B065 3976	Transfer Harness	93 - 27
B065 4017	Fusing Unit - 120V	97 - 1
B065 4019	Fusing Unit (TWN)	97 - 1
B065 4027	Fusing Unit - 230V	97 - 1
B065 4101	Front Side Plate	101 - 5
B065 4105	Rear Side Plate	101 - 20
B065 4112	Right Stay	101 - 19
B065 4114	Left Stay	101 - 18
B065 4116	Lower Fusing Cover	97 - 3
B065 4117	Upper Fusing Cover	97 - 7
B065 4121	Thermostat Terminal	99 - 13
B065 4124	Front Heater Holder	99 - 5
B065 4127	Thermostat Housing	99 - 9
B065 4129	Side Plate Sheet	97 - 29
B065 4130	Thermostat Housing - Middle	99 - 7
B065 4131	Rear Thermistor Bracket	99 - 16
B065 4132	Middle Thermistor Cover	99 - 5
B065 4133	Lower Fusing Entrance Plate - 120V	97 - 2
B065 4135	Lower Fusing Entrance Plate - 230V	97 - 2
B065 4138	Side Plate Cover	97 - 4
B065 4139	Switch Holder	101 - 14
B065 4140	Lower Guide Plate - Exit	101 - 17
B065 4141	Spring Plate - Switch	101 - 13
B065 4142	Upper Fusing Stay	99 - 8
B065 4145	Front Release Lever	101 - 2
B065 4147	Rear Release Lever	101 - 24
B065 4150	Front Harness	99 - 12
B065 4151	Rear Harness	99 - 14
B065 4154	Rear Fusing Plate	103 - 31

Part No.	Description	Page and Index No.
B065 4155	Fusing Harness (120V)	99 - 20
B065 4156	Fusing Harness (230V)	99 - 20
B065 4157	Connector Bracket	99 - 19
B065 4159	Harness Holder	99 - 18
B065 4160	Cleaning Roller Guide Plate	101 - 12
B065 4161	Left Support Bracket	101 - 11
B065 4164	Right Support Bracket	101 - 8
B065 4167	Decal - Fusing Knob	175 - 19
B065 4167	Decal - Fusing Knob	95 - 5
B065 4168	Fusing Positioning Plate	141 - 16
B065 4170	Rear Heater Holder	99 - 17
B065 4175	Front Fusing Grip	97 - 5
B065 4176	Grip Sheet	97 - 6
B065 4177	Front Pressure Lever	101 - 3
B065 4178	Rear Pressure Lever	101 - 23
B065 4179	Stripper Pawls Plate	141 - 15
B065 4180	Spacer - 16mm	99 - 25
B065 4184	Stripper Pawls Grip	97 - 17
B065 4185	Exit Plate	97 - 9
B065 4188	Front Lock Pawl	97 - 16
B065 4189	Rear Lock Pawl	97 - 21
B065 4200	Web Unit	95 - 7
B065 4202	Web Bracket	95 - 15
B065 4207	Web Shaft	95 - 8
B065 4211	Pressure Roller Gear	95 - 12
B065 4212	Stopper Bracket	95 - 11
B065 4217	Web Bracket	95 - 13
B065 4219	Web End Feeler	95 - 38
B065 4221	Feeler Spring	95 - 37
B065 4222	Gear - 37Z	95 - 20
B065 4223	Motor Gear	95 - 30
B065 4225	Motor Plate Bracket	95 - 28
B065 4226	Drive Bracket	95 - 25
B065 4231	Web Cover	95 - 26
B065 4232	Feeler Guard Bracket	95 - 23

Part No.	Description	Page and Index No.
B065 4234	Stopper Gear	95 - 35
B065 4235	Web Idle Gear	95 - 33
B065 4238	Gear - 50Z	95 - 32
B065 4239	Web Drive Shaft	95 - 18
B065 4241	Gear	95 - 21
B065 4242	Rolling Drive Gear	95 - 17
B065 4244	Gear - 23Z	95 - 31
B065 4246	Spring Plate	95 - 24
B065 4247	Brake Pad	95 - 22
B065 4248	Web Harness	95 - 34
B065 4249	Right Exit Stay	107 - 12
B065 4251	Positioning Plate - Web Unit	95 - 39
B065 4252	Left Exit Tray	107 - 2
B065 4254	Lower Entrance Guide Plate	105 - 15
B065 4255	Insulator	95 - 1
B065 4258	Fusing Grip	103 - 1
B065 4259	Lock Lever	103 - 4
B065 4260	Lever Shaft	103 - 5
B065 4262	Lock Lever Bracket	103 - 2
B065 4263	Lock Lever Shaft Bracket	141 - 7
B065 4266	Lever Contact Bracket	103 - 6
B065 4268	Fusing Inner Cover	95 - 4
B065 4273	Exit Grip Cover	103 - 8
B065 4274	Decal - Misfeed Removal	95 - 2
B065 4274	Decal - Misfeed Removal	175 - 20
B065 4300	Exhaust Cover	141 - 3
B065 4304	Left Plate Guide	141 - 6
B065 4306	Front Exhaust Side Plate	141 - 4
B065 4307	Rear Exhaust Side Plate	141 - 24
B065 4308	Left Release Guide Plate	107 - 4
B065 4315	Exit Tightener	107 - 19
B065 4317	Idle Pulley - 11mm	107 - 22
B065 4319	Upper Exit Guide Plate	141 - 2
B065 4354	Upper Exhaust Guide Plate	103 - 15
B065 4355	Paper Feed Sensor Bracket	103 - 12

Part No.	Description	Page and Index No.
B065 4359	Grip Supporter	103 - 17
B065 4360	Spring Plate	103 - 27
B065 4361	Grip Shaft	103 - 19
B065 4363	Upper Grip	103 - 16
B065 4373	Upper Exit Guide Plate	103 - 20
B065 4374	Exit Entrance Sensor Bracket	103 - 23
B065 4378	Driven Decura Roller	103 - 28
B065 4381	Contact Point Shaft	103 - 30
B065 4390	Fusing Exitguide Plate	97 - 28
B065 4391	Guide Plate Bracket	97 - 19
B065 4397	Release Slider	97 - 15
B065 4398	Slider Cover	97 - 11
B065 4400	Bracket	107 - 15
B065 4413	Exit Gate Pawl	105 - 11
B065 4415	Gate Pawl Solenoid	105 - 2
B065 4421	Pressure Shaft	107 - 9
B065 4422	Guide Plate Lever	107 - 8
B065 4424	Exit Arm Pad	107 - 7
B065 4429	Exit Front Side Plate	107 - 1
B065 4433	Exit Rear Side Plate	107 - 13
B065 4441	Exit Drum Stay	105 - 4
B065 4451	Middle Exit Guide Plate	103 - 29
B065 4458	Exit Drawer Bracket	107 - 18
B065 4459	Rear Harness Bracket	107 - 11
B065 4460	Front Harness Bracket	107 - 10
B065 4470	Support Bracket	103 - 7
B065 4480	Decal - Cover	17 - 7
B065 4480	Decal - Cover	175 - 21
B065 4481	Decal - Exit	175 - 22
B065 4481	Decal - Exit	95 - 3
B065 4495	Relay Harness - Guide Plate	103 - 24
B065 4496	Relay Harness - Exit	103 - 14
B065 4497	Exit Harness	107 - 17
B065 4499	Exit Detection Harness	141 - 25
B065 4500	Duplex Unit	109 - 15

Part No.	Description	Page and Index No.
B065 4525	Duplex Inner Cover	109 - 1
B065 4531	Guide Plate Lever	109 - 30
B065 4591	Right Duplex Rail	141 - 17
B065 4619	Support Bracket	117 - 25
B065 4620	Rear Side Plate	111 - 18
B065 4627	Front Side Plate	111 - 11
B065 4632	Joint Holder	111 - 19
B065 4640	Upper Entrance Guide Plate	111 - 25
B065 4644	Sensor Bracket	111 - 22
B065 4647	Invertor Lever	111 - 4
B065 4648	Lever Cam	109 - 31
B065 4650	Jogger Motor	113 - 11
B065 4655	Driven Reverse Bracket	113 - 25
B065 4671	Duplex Lock Arm	109 - 5
B065 4672	Release Lever Bracket	109 - 8
B065 4673	Release Lever Shaft	109 - 4
B065 4674	Release Grip	109 - 3
B065 4675	Duplex Release Bracket	109 - 6
B065 4681	Front Jogger Fence	113 - 19
B065 4682	Rear Jogger Fence	113 - 21
B065 4683	Spring Plate - Rear Jogger Fence	113 - 20
B065 4692	Front Jogger Fence Slider	117 - 10
B065 4693	Rear Jogger Fence Slider	117 - 11
B065 4694	Jogger Guide Rod	115 - 13
B065 4696	Jogger Motor Bracket	113 - 10
B065 4699	Jogger H.P. Sensor Bracket	117 - 1
B065 4710	Upper Transport Guide Plate	117 - 18
B065 4715	Exit Reverse Sensor Bracket	117 - 15
B065 4720	Left Duplex Table	113 - 18
B065 4725	Right Duplex Bracket	109 - 16
B065 4726	Right Guide Table	109 - 14
B065 4727	Right Sensor Bracket	109 - 18
B065 4728	Spring Plate - Right Table Guide	109 - 13
B065 4730	Lower Transport Guide Plate	109 - 23
B065 4731	Spring Plate - Driven Roller	109 - 22

Part No.	Description	Page and Index No.
B065 4733	Duplex Gate Pawl	117 - 4
B065 4736	Exit Solenoid	117 - 26
B065 4738	Gate Pawl Cushion	117 - 5
B065 4745	Reverse Solenoid	113 - 5
B065 4780	Reverse Motor	113 - 1
B065 4785	Transport Motor	113 - 6
B065 4789	Transport Motor Bracket	113 - 8
B065 4790	Drawer Bracket - 32P	117 - 23
B065 4791	Drawer Bracket - 12P	117 - 21
B065 4798	Caution Decal - Duplex	175 - 23
B065 4798	Caution Decal - Duplex	109 - 2
B065 4810	Reverse Motor Bracket	113 - 2
B065 4820	Jogger Bracket	117 - 27
B065 4830	Holder Bracket	141 - 21
B065 4835	Rail	141 - 10
B065 4860	Lower Duplex Bracket	117 - 6
B065 4865	Spacer	117 - 7
B065 4866	Reverse Knob	111 - 1
B065 4867	Decal - Guide Plate Lever	109 - 29
B065 4867	Decal - Guide Plate Lever	175 - 24
B065 4933	Guide Plate Lever Hook	109 - 28
B065 4934	Duplex Harness - 32P	117 - 24
B065 4981	Duplex Harness - 12P	117 - 22
B065 4987	Upper Duplex Stay	109 - 10
B065 5041	Safety Switch Lever	137 - 2
B065 5111	Controller Board	171 - *
B065 5111	Controller Board	127 - 9
B065 5112	HDD - 40GB	127 - 13
B065 5113	IC - ASIC MARIMBA3	171 - 1
B065 5115	HDD Harness	127 - 16
B065 5120	BCU Board	125 - 3
B065 5120	BCU Board	153 - *
B065 5128	IC - GASTM	153 - 3
B065 5132	PFC Board	133 - 3
B065 5144	IPU Board	127 - 28

Part No.	Description	Page and Index No.
B065 5144	IPU Board	163 - *
B065 5147	IC - CDIC3	163 - 1
B065 5147	IC - CDIC3	163 -102
B065 5158	IC - RF5C608	163 -103
B065 5158	IC - RF5C608	163 - 2
B065 5169	IC - GARAC	163 - 3
B065 5169	IC - GARAC	163 -104
B065 5173	LCDC Board - LT	19 - 6
B065 5174	LCDC Board - A4	19 - 6
B065 5180	SDRD Board	49 - 13
B065 5185	DRB Board	129 - 21
B065 5195	VIB Board	45 - 15
B065 5200	Mother Board	127 - 23
B065 5220	Relay Board	47 - 22
B065 5230	CNB Board	129 - 18
B065 5239	LCDC Board (TWN/ASIA)	19 - 6
B065 5240	LCDC Board (CHN)	19 - 6
B065 5241	LCDC Board (KOR)	19 - 6
B065 5305	Development Drive Motor	119 - 1
B065 5401	20p Cable - LVDS SBU	45 - 12
B065 5403	12P Cable - LVDS LIDB	51 - 1
B065 5405	LCDC Harness	45 - 14
B065 5416	Upper Harness	125 - 2
B065 5417	Left Harness	125 - 1
B065 5418	Duplex/Exit Harness	131 - 20
B065 5420	CNB Board Harness	129 - 19
B065 5421	Safety Switch Harness	129 - 17
B065 5422	Duplex DRB Harness	131 - 19
B065 5430	LD Switch Harness	137 - 1
B065 5437	LD Control Harness	51 - 5
B065 5445	Finisher CNB Harness	125 - 18
B065 5447	ADF Power Source Harness	125 - 14
B065 5450	IPU/BCU Harness	127 - 29
B065 5453	Relay Polygon Motor Harness	51 - 12
B065 5454	HP Sensor Relay Harness	49 - 9

Part No.	Description	Page and Index No.
B065 5468	Css Relay Harness	129 - 26
B065 5469	FFC/SBU Harness - 15p	45 - 7
B065 5470	FFC/SBU Harness - 40p	45 - 8
B065 5471	Grounding Wire	49 - 29
B065 5477	LD Relay Harness	51 - 4
B065 5483	Safety Switch	133 - 2
B065 5489	Harness (B065)	51 - 2
B065 5500	CNB/PSU Harness	129 - 15
B065 5501	VIB Power Source Harness	45 - 16
B065 5502	PFC/PSU Harness	133 - 8
B065 5503	ADF/CNB Harness	125 - 15
B065 5507	MB/PSU Harness	127 - 26
B065 5508	IPU/PSU Harness	127 - 22
B065 5509	DRB/BCU Power Source Harness	129 - 16
B065 5510	MB2/PSU Harness	127 - 27
B065 5600	AC Harness - 120V	131 - 22
B065 5601	Paper Bank Heater Harness	133 - 10
B065 5610	1st Scanner Harness	47 - 21
B065 5650	Scanner Unit Harness	45 - 13
B065 5651	AC Harness - 240V	131 - 22
B065 5672	Power Supply Cord - 120V	133 - 11
B065 5673	Power Supply Cord - 230V (CHN)	133 - 11
B065 5700	Rear Paper Bank Harness	135 - 10
B065 5701	Front Paper Bank Harness	133 - 1
B065 5752	Control Unit Side Plate	127 - 4
B065 5754	Centronics Cover	127 - 5
B065 5790	Panel Gasket	127 - 8
B065 5791	Fan Motor Gasket	125 - 10
B065 5795	Controller Grounding Bracket	127 - 34
B065 5802	CNB Board Bracket	129 - 20
B065 5803	DRB Board Bracket	129 - 22
B065 5804	Charge Power Pack Bracket	129 - 14
B065 5805	CSS Bracket	129 - 23
B065 5806	ADF Cable Bracket	125 - 16
B065 5807	Finisher Cable Bracket	125 - 17

Part No.	Description	Page and Index No.
B065 5808	LCT Cable Bracket	121 - 1
B065 5811	Safety Switch Bracket	137 - 3
B065 5813	Main Switch Bracket	137 - 6
B065 5814	Harness Guide	131 - 12
B065 5815	Charge Power Pack Bracket	131 - 7
B065 5816	Safety Switch Harness Cover	137 - 5
B065 5817	Slide Rail Cover	131 - 17
B065 5818	Main Switch Harness Guide	131 - 21
B065 5819	Lower Hinge Bracket	131 - 18
B065 5821	Control Unit Base	127 - 21
B065 5826	Lower Hinge Bracket	125 - 7
B065 5827	Upper Hinge	125 - 5
B065 5837	NIB Cover	127 - 2
B065 5838	IEEE1394 Cover	127 - 6
B065 5841	IPU Cover	127 - 30
B065 5844	IPU Connector Cover	127 - 31
B065 5846	Mother Board Cover	127 - 25
B065 5858	HDD Bracket	127 - 17
B065 5860	BCU Board Bracket	125 - 13
B065 5861	HDD Side Plate	127 - 12
B065 5863	IC Card Cover	127 - 3
B065 5865	Fan Cover	125 - 11
B065 5867	Fan Cover	127 - 10
B065 5868	Clamp	127 - 20
B065 5868	Clamp	131 - 14
B065 5869	Base Sheet	127 - 32
B065 5871	PFC Board Bracket	133 - 4
B065 5872	Lower PFC Board Stay	133 - 6
B065 5873	Upper PFC Board Stay	133 - 5
B065 5874	Lower Hinge	125 - 9
B065 5877	Power Supply Board Holder - 240V	133 - 13
B065 5878	Upper PSU Stay	135 - 19
B065 5879	Right PSU Stay	133 - 12
B065 5883	Fan Relay Harness	127 - 24
B065 5890	Upper Hinge Stay	131 - 13

Part No.	Description	Page and Index No.
B065 5892	Power Pack Bracket	131 - 6
B065 5893	Counter Bracket	139 - 8
B065 5898	Power Supply Board Holder - 120V	133 - 13
B065 5899	Bushing	137 - 27
B065 6075	Side Plate Stay - Lower Rear	145 - 16
B065 6076	Support Plate	145 - 1
B065 6078	LCT Stay	67 - 30
B065 6116	Upper Heat Sink	143 - 7
B065 6122	Micro Switch Bracket	67 - 27
B065 6135	Lock Arm - Tandem Tray	143 - 5
B065 6136	Tray Lock Arm	145 - 3
B065 6166	Rear Support Plate	145 - 12
B065 6173	Stopper Bracket	135 - 18
B065 6174	Paper Tray Positioning Bracket	145 - 15
B065 6177	Paper Size Sensor Bracket	135 - 14
B065 6184	Paper Feed Inner Cover	15 - 27
B065 6191	Side Plate - Paper Tray	145 - 11
B065 6200	Paper Feed Unit	67 - 1
B065 6221	Lower Heat Sink	145 - 14
B065 6235	Left Rail Bracket	143 - 3
B065 6241	Left Rail - Paper Feed	145 - 4
B065 6250	Right Slide Rail	145 - 6
B065 6264	Guide Stay	143 - 12
B065 6265	Left Tandem Slide Rail	143 - 6
B065 6266	Right Tandem Slide Rail	143 - 13
B065 6306	Reverse Drive Shaft	65 - 25
B065 6307	Reverse Driven Shaft	65 - 34
B065 6317	Relay Shaft	65 - 9
B065 6318	Pick-up Solenoid	63 - 17
B065 6320	Reverse Roller - Pressure Release	65 - 29
B065 6323	Paper Feed Motor	71 - 29
B065 6323	Paper Feed Motor	67 - 4
B065 6323	Paper Feed Motor	65 - 38
B065 6328	Reverse Bracket	65 - 28
B065 6330	Rear Side Plate - Paper Feed	65 - 12

Part No.	Description	Page and Index No.
B065 6333	Reverse Housing	65 - 30
B065 6334	Heat Sink Base	63 - 31
B065 6336	Front Side Plate - Paper Feed	65 - 32
B065 6337	Heat Sink	63 - 32
B065 6338	Heat Sink Sheet	63 - 33
B065 6339	Feed Guide Plate	63 - 23
B065 6345	Paper End Sensor Bracket	63 - 21
B065 6346	Paper Tray Link	65 - 15
B065 6350	Pick-up Gear Cover	63 - 4
B065 6353	Feed Gear Cover	63 - 26
B065 6357	Pick-up Arm	63 - 6
B065 6358	Paper Feed Sensor Bracket	63 - 12
B065 6361	Relay Guide Plate - Paper Feed	67 - 2
B065 6364	Feed Stay	63 - 14
B065 6366	Drive Bracket	63 - 27
B065 6371	Support Guide Plate	65 - 31
B065 6372	Guide Plate	65 - 1
B065 6375	Paper Feed Unit Stay	63 - 15
B065 6394	Motor Bracket	65 - 39
B065 6399	Torquelimiter	65 - 35
B065 6399	Torquelimiter	71 - 16
B065 6402	Transport Pressure Plate	67 - 25
B065 6403	Front Side Plate - Vertical Transport	67 - 17
B065 6404	Rear Side Plate - Vertical Transport	67 - 19
B065 6405	Guide Plate - Vertical Transport	67 - 18
B065 6407	Transport Pressure Plate	67 - 23
B065 6415	Motor Base	65 - 43
B065 6416	Ball Bearing - 6x12x4.5	65 - 33
B065 6426	Release Lever - Vertical Transport	67 - 13
B065 6427	Release Lever - Vertical Transport	67 - 15
B065 6428	Release Button - Vertical Transport	67 - 14
B065 6429	Release Cover - Vertical Transport	67 - 11
B065 6445	Feed Lever	63 - 10
B065 6452	Tray Link Guide	65 - 14
B065 6453	Transport Roller Lever	65 - 5

Part No.	Description	Page and Index No.
B065 6454	Driven Release Lever	65 - 7
B065 6455	Driven Pressure Lever	65 - 8
B065 6456	Vertical Transport Link	65 - 20
B065 6457	Driven Pressure Lever	63 - 29
B065 6472	Relay Unit Guide Plate	67 - 9
B065 6487	Lower Paper Feed Harness	63 - 20
B065 6488	Upper Paper Feed Harness	63 - 19
B065 6489	Relay Unit Harness	67 - 3
B065 6502	Paper Tray Assembly (LT)	59 - 1
B065 6504	Paper Tray Assembly (A4)	59 - 1
B065 6524	Bottom Plate Lift Shaft	59 - 30
B065 6526	Lift Lever	59 - 31
B065 6533	Front Side Fence Ass'y	59 - 14
B065 6534	Front Side Fence	59 - 11
B065 6538	Positioning Stopper Lever	59 - 13
B065 6540	Rear Side Fence Ass'y	59 - 27
B065 6541	Rear Side Fence	59 - 22
B065 6545	Decal - Positioning	59 - 8
B065 6545	Decal - Positioning	175 - 25
B065 6571	Paper Size Detection	59 - 28
B065 6576	Coupling Link	59 - 2
B065 6584	Paper Tray Holder Stay	59 - 33
B065 6588	Right Support Plate	59 - 36
B065 6589	Left Support Plate	59 - 37
B065 6591	Paper Tray Holder Base	59 - 20
B065 6630	Tandem Cover	53 - 1
B065 6632	Paper Tray Cover - Long (3rd)	59 - 34
B065 6633	Paper Tray Cover - Short (2nd)	59 - 34
B065 6635	Decal - Paper Tray 1	53 - 2
B065 6635	Decal - Paper Tray 1	175 - 26
B065 6636	Decal - Paper Tray 2	59 - 38
B065 6636	Decal - Paper Tray 2	175 - 27
B065 6637	Decal - Paper Tray 3	59 - 38
B065 6637	Decal - Paper Tray 3	175 - 28
B065 6672	Tandem Connecting Guide	55 - 20

Part No.	Description	Page and Index No.
B065 6706	Paper Volume Sensor Bracket	55 - 9
B065 6710	Front Right Side Plate	57 - 35
B065 6717	Paper Volume Shield Plate	57 - 34
B065 6743	Right Connecting Bracket	57 - 22
B065 6744	Right Tandem Harness	57 - 21
B065 6755	Solenoid	135 - 20
B065 6767	Right Connecting Bracket	135 - 9
B065 6769	Lock Arm	135 - 3
B065 6771	Arm Bracket	135 - 1
B065 6774	Slide Bracket	143 - 11
B065 6776	Tandem Tray Stay	143 - 1
B065 6777	Supporting Plate	143 - 14
B065 6783	Slide Rail Base	145 - 5
B065 6792	Slide Rail Base - Tandem	143 - 4
B065 6811	Side Plate - Right Rear	57 - 13
B065 6821	Pulley Bracket	53 - 32
B065 6823	Timing Belt Cover	53 - 19
B065 6826	DC Motor Bracket	53 - 35
B065 6830	Pulley Bracket	53 - 23
B065 6831	Sensor Bracket	53 - 13
B065 6846	Decal - Paper Set - Left	175 - 29
B065 6846	Decal - Paper Set - Left	53 - 5
B065 6851	Right Base - Tandem LCT	57 - 27
B065 6859	Right Stopper	55 - 2
B065 6862	Large Lever	57 - 23
B065 6864	Small Lever	57 - 30
B065 6870	Stay - Right Base	57 - 32
B065 6872	Oil Damper Bracket	57 - 38
B065 6873	Sensor Bracket	55 - 1
B065 6874	Bracket - Paper Volume Sensor	55 - 14
B065 6875	Protection - Inner Cover	55 - 5
B065 6877	Decal - Paper Set - Right	175 - 30
B065 6877	Decal - Paper Set - Right	55 - 6
B065 6881	Detector Bracket	57 - 8
B065 6884	Detector Bracket	57 - 11

Part No.	Description	Page and Index No.
B065 7012	Model Name Plate (B065 RIC)	15 - 12
B065 7018	Model Name Plate (B065 LAN)	15 - 12
B065 7019	Model Name Plate (B065 INF)	15 - 12
B065 8490	Decal Sheet - Paper Size	175 - 31
B065 8490	Decal Sheet - Paper Size	15 - 30
B064 9500	Test Chart for CIS	177 - 9

Part No.	Description	Page and Index No.
A006 9104	Adjusting Scanner Pin (4pcs/set)	177 - 1
A007 3751	Large Cap - Toner Collection Tank	17 - 5
A010 5700	Sensor	57 - 25
A029 2984	Decal - Grip	67 - 12
A029 2984	Decal - Grip	175 - 1
A029 9387	Digital Multimeter - Fluke87	177 - 7
A048 2276	Ring - Transport Bracket	89 - 2
A048 2838	Nylon Rivet	59 - 16
A048 2838	Nylon Rivet	73 - 24
A048 2838	Nylon Rivet	105 - 16
A053 2916	Friction Pad - B	71 - 9
A060 2512	Registration Roller Knob	15 - 20
A069 1883	Shoe - Scanner	47 - 5
A077 4162	Shoulder Screw - M3	105 - 14
A096 1173	Fusing Drive Joint	119 - 14
A096 1355	Hinge Shaft	137 - 18
A096 1679	Development Grounding Plate	139 - 6
A096 1873	Scanner Shoe Pin	47 - 5
A096 2051	Rear Grid Anchor	83 - 18
A096 2052	Front Grid Anchor	83 - 27
A096 2053	Cleaner Motor Cover	83 - 4
A096 2057	Charge Corona Grid	83 - 28
A096 2062	Wire Cleaner Slider	83 - 8
A096 2063	Corona Wire Cleaner	83 - 7
A096 2065	Slider Ring	83 - 9
A096 2301	Grounding Plate	85 - 5
A096 2612	Lower Registration Guide	71 - 7
A096 2622	Front Lower Registration Guide	69 - 8
A096 2633	Front Lock	73 - 10
A096 2780	Feed Guide Gear	61 - 7
A096 3141	Development Filter Case	79 - 18
A096 3175	Bushing 8x14x8	77 - 23
A096 3176	Bushing - 6x12x8.5	77 - 28
A096 3181	Slitter	77 - 12
A096 3224	Bottle Roller	75 - 15

Part No.	Description	Page and Index No.
A096 3712	Latch	17 - 2
A096 3712	Latch	123 - 34
A096 3736	Steel Ball - M11	123 - 43
A096 4319	Exit Roller Holder	97 - 23
A096 4595	Duplex Guide	117 - 12
A096 4928	Guide Plate Band	109 - 24
A096 5320	Quenching Lamp	85 - 4
A096 5335	Paper Size Switch	61 - 18
A096 5416	Paper Size Harness	135 - 15
A096 5528	Micro Switch Sheet	67 - 26
A096 6553	Side Fence Pad	59 - 10
A096 6671	Paper Guide Plate	55 - 7
A096 6677	Decal - Right Paper Set	175 - 2
A096 6677	Decal - Right Paper Set	55 - 12
A096 6678	Decal - Left Paper Set	53 - 12
A096 6678	Decal - Left Paper Set	175 - 3
A096 6693	Paper Guide Sheet	145 - 10
A134 1135	Fly Wheel	121 - 10
A134 1698	Idle Pulley	49 - 18
A134 1724	Cushion - Stepper Motor	49 - 15
A134 2863	Terminal Plate	83 - 26
A134 2975	Spring Plate	59 - 12
A134 3179	Chuck Shaft	75 - 23
A134 3192	Seal - Toner Bottle	75 - 36
A134 3216	Screw	75 - 20
A134 5251	ID Sensor	89 - 21
A176 2054	Grounding Plate	83 - 6
A176 2061	Screw Shaft	83 - 10
A176 6570	Paper Stopper	59 - 26
A176 6695	Misfeed Removal Guide	55 - 19
A176 6695	Misfeed Removal Guide	59 - 32
A222 2724	External Circlip - Mm8	75 - 30
A229 1132	Bracket - Registration Motor	119 - 4
A229 1133	Stepper Motor Base Ass'y	119 - 7
A229 1135	Ring - 55	121 - 23

Part No.	Description	Page and Index No.
A229 1135	Ring - 55	119 - 10
A229 1136	Fusing Drive Shaft	119 - 12
A229 2655	Read Rock	73 - 7
A229 2717	Lock Lever	73 - 3
A229 3154	Case Seal	77 - 8
A229 3217	Retaining Ring Seal	75 - 38
A229 3219	Rubber Bushing - Toner Supply Unit	75 - 13
A229 3232	Chuck Roller	75 - 22
A229 3240	DC Motor	75 - 4
A229 3242	Toner Bottle Joint Gear	75 - 35
A229 3243	Motor Joint Gear	75 - 34
A229 3258	Toner Catchpan	75 - 32
A229 3261	Outer Shutter	75 - 8
A229 3262	Inner Shutter	75 - 9
A229 3263	Outer Shutter Shield	75 - 7
A229 3264	Shutter Lever	75 - 11
A229 3266	Upper Shutter Shield	75 - 10
A229 3285	Shutter Cover	75 - 12
A229 3290	Right Inner Cover	15 - 24
A229 3291	Right Inner Cover	15 - 25
A229 3861	Front Arm	91 - 3
A229 3862	Rear Arm	91 - 7
A229 3865	Transport Driven Roller	91 - 13
A229 3875	Drive Electrode	91 - 4
A229 3910	Front Bushing	93 - 17
A229 3911	Rear Bushing	93 - 23
A229 3934	Tape	93 - 12
A229 4467	Pressure Arm	107 - 6
A229 4477	Reverse Guide Plate	105 - 10
A229 4479	Reverse Guide Plate - Right	105 - 9
A229 4482	Exit Roller Holder	105 - 8
A229 4617	Duplex Discharge Brush	111 - 23
A229 4623	Lower Entrance Guide Plate	111 - 5
A229 4624	Duplex Driven Roller	111 - 8
A229 4727	Guide Plate Pressure Holder	109 - 26

Part No.	Description	Page and Index No.
A229 4740	Drive Joint	111 - 21
A229 4800	Exit Guide Plate	109 - 11
A229 5216	Touch Panel	19 - 13
A229 5442	Duplex Connecting Harness	109 - 19
A229 6556	Tray Bottom Plate	59 - 35
A232 3566	Ball Bearing - 8x16x5	101 - 4
A232 3566	Ball Bearing - 8x16x5	115 - 2
A232 4666	Cushion - Stepper Motor	113 - 7
A232 5355	IC - GATEX	153 - 1
A247 2800	Ball Bearing - 8x12x5	71 - 3
A247 2900	Torque Limiter - 53mnm	33 - 11
A247 4249	Connector - 3P	99 - 21
A247 5428	DC Harness - Left	53 - 26
A248 6103	Guide Plate - Upper Heat Sink	143 - 9
A248 6167	DC Motor - 19.2W	135 - 7
A248 6168	Bracket - Lift Motor	135 - 6
A248 6615	Coupling Lever - Left	53 - 25
A248 6623	Slider - Left Back Fence	53 - 22
A248 6624	Left Back Fence	53 - 18
A248 6639	Tray Bottom Plate - Left Middle	53 - 10
A248 6645	Side Plate - Left	53 - 7
A248 6646	Cover Bracket	53 - 4
A248 6666	Side Plate	55 - 22
A248 6684	Pulley Drive Wire Ass'y	57 - 19
A248 6687	Right Drive Shaft	57 - 18
A248 6694	Wire Ring	57 - 31
A248 6695	Guide - Pulley	57 - 16
A248 6701	Oil Damper	57 - 36
A248 6713	Hook - Tension Spring	57 - 4
A248 6714	DC Solenoid - Front End Fence	57 - 1
A248 6717	Front Release Lever	57 - 2
A248 6727	DC Solenoid - Rear End Fence	57 - 12
A248 6730	Rear Release Lever	57 - 14
A248 6738	Side Fence - Right Rear	55 - 15
A248 6745	Inner Cover - Tandem LCT	55 - 4

Part No.	Description	Page and Index No.
A248 6757	Left Connector Bracket	135 - 13
A248 6758	DC Lock Solenoid	135 - 21
A257 9300	Grease - Barrierta S552R	177 - 5
A265 5154	PCB:CSS	129 - 24
A267 1820	Sheet - Photointerrupter	49 - 12
A267 2857	Spring Plate - Side Fence	59 - 25
A267 2859	Side Fence Stopper	59 - 23
A267 2860	Rear Lever Stopper	59 - 24
A292 9500	Test Chart - S5S (10 Pcs/set)	177 - 2
A293 1095	Sirocco Fan - DC24V	129 - 5
A293 1155	Duplex Drive Bracket	119 - 25
A293 1332	Duct Holder	17 - 24
A293 1343	Upper Hinge	15 - 4
A293 1674	Front Slide Rail	49 - 1
A293 1766	2nd Mirror Plate	47 - 4
A293 2418	Upper Unit Cover	85 - 1
A293 3220	Toner Bottle Stopper	75 - 25
A293 3227	Toner Slider	75 - 15
A293 3230	Toner Bottle Chuck	75 - 18
A293 3231	Shield Holder	75 - 1
A293 3234	Shield Plate - Toner Bottle	75 - 17
A293 3282	Toner Bottle Pawl	75 - 26
A293 3899	Transfer Belt - Mojito Service	91 - 5
A293 3916	Cleaning Roller - Transfer Belt	93 - 8
A293 4611	Reverse Roller	111 - 15
A293 4613	Front Gate Pawl	111 - 14
A293 4614	Rear Gate Pawl	111 - 16
A293 4615	Spacer	111 - 13
A293 5310	Sync Detector Board	51 - 29
A293 5871	CSS Board Bracket	129 - 25
A293 6574	Actuator Guide	59 - 29
A293 6579	Link Guide	59 - 5
A293 6585	Knob - Paper Size Selection	59 - 3
A293 6637	Tray Bottom Plate - Left Middle (KOR)	53 - 10
A293 6640	Tray Bottom Plate - Left Front	53 - 9

Part No.	Description	Page and Index No.
A293 6642	Tray Bottom Plate - Left Rear	53 - 11
A293 6643	Side Fence - Left Front	53 - 8
A293 6644	Side Fence - Left Rear	53 - 15
A293 6646	Rear Cover - Tandem LCT	53 - 16
A293 6647	Support Bracket - End Fence	53 - 6
A293 6649	Rear Cover Cushion - Tandem LCT	53 - 17
A293 6678	Base - Right Tandem LCT (KOR)	55 - 13
A293 6712	End Fence Guide (A4)	57 - 7
A293 6713	Front End Fence	57 - 6
A293 6714	Rear End Fence	57 - 10
A293 6736	Side Fence - Right Front	55 - 8
A293 6739	Inner Cover - Right Rear	55 - 16
A294 1292	Door Switch Bracket	15 - 1
A294 1378	Decal - Total Counter	15 - 21
A294 1378	Decal - Total Counter	175 - 4
A294 1712	Rear Holder - Lamp	47 - 10
A294 2051	Rear Receptacle	121 - 4
A294 2052	Receptacle Pin	121 - 5
A294 2114	Toner Filter	137 - 9
A294 2678	Roller - Duplex Exit	73 - 18
A294 2672	Rear Drum Seal	87 - 18
A294 4659	Cushion	117 - 16
A294 4723	Roller Holder Fixing Plate	117 - 8
A294 4754	Roller Lever	113 - 15
A294 6655	Front Roller - Slide Rail	57 - 39
A294 6670	Base - Right Tandem Tray	55 - 13
A294 6690	Feeler - Paper Height Sensor	57 - 33
A300 2134	Guide Roller - B	141 - 11
A351 4281	Anti-vibration Cushion	41 - 8
A374 2181	Spacer	29 - 6
A376 4599	Side Fence Pad	23 - 2
A413 1670	Antistatic Brush	99 - 4
A418 1158	Spacer - M6.5x1	25 - 20
A422 1063	Seal - 0.7x13x20	29 - 9
A422 1063	Seal - 0.7x13x20	35 - 25

Part No.	Description	Page and Index No.
A422 1078	Bushing - 6x12x4mm	33 - 1
A422 1079	Bushing - 8x16x5mm	29 - 11
A423 4432	Shoulder Screw - M2.5	67 - 29
A423 4433	Spring	67 - 28
A469 2123	Rubber Cushion - 1x10x10mm	73 - 14
A470 1703	Shift Clutch	107 - 26
A470 1704	Spring - Lower Exit Roller	107 - 25
A548 2139	Pulley	37 - 8
A628 1225	Bushing - 8mm	25 - 13
A628 3112	Shielding Sheet	43 - 12
A669 1827	Spacer - 16mm	127 - 35
A680 1171	Harness Holder	39 - 38
A680 1621	Feed-in Unit Stopper	25 - 16
A680 2262	Feeler - Pick-up Roller Cam	37 - 20
A697 1125	Stepped Screw - Lever	39 - 12
A697 2131	Antistatic Brush	35 - 16
A697 2131	Antistatic Brush	31 - 13
A806 1135	Contact Point Shaft	41 - 10
A806 1163	Guide Plate Cushion	25 - 11
A806 1292	Feed Belt Bracket	25 - 24
A806 1293	Feed Belt Drive Roller	25 - 15
A806 1294	Feed Belt Driven Roller	25 - 26
A806 1295	Feed Belt	25 - 22
A806 1298	Transport Belt Roller Shaft	25 - 25
A806 1321	Pickup Roller	25 - 6
A806 1335	Original Table Guide Plate	23 - 15
A806 1351	Original Sensor Feeler	23 - 6
A806 2151	Timing Pulley - T19/Z23 S2M/M0.6	25 - 2
A806 2153	Timing Pulley - T27 S2M	25 - 12
A806 2161	Timing Pulley - T30/Z20 S2M/M0.8	39 - 26
A806 2244	Separation Shaft Stopper	37 - 12
A806 2271	Gear - Z18	25 - 1
A806 2281	Gear - Z47	23 - 19
A806 2283	Gear - Z20/Z47	39 - 25
A806 2285	Gear - Z20/Z47	39 - 23

Part No.	Description	Page and Index No.
A806 2287	Gear - Z20/Z47	39 - 24
A806 2911	Stepper Motor Ass'y - DC 13W	39 - 30
A806 4117	Timing Belt - B40S2M158	39 - 28
A806 4118	Timing Belt - B40S2M148	25 - 8
A806 4261	Spring Belt Guide Roller	25 - 23
A859 2230	Ball Bearing - 6x13x5	37 - 14
A859 2241	Reverse Roller	33 - 10
A859 3225	Discharge Brush	29 - 19
A859 4836	Bushing- Exit Driven Roller	35 - 17
A859 7211	Stepped Screw	21 - 10
B004 5120	IC - HG71C114FL	153 - 2
B004 5853	Bracket Grip	127 - 1
B023 1101	Stand Holder	15 - 29
B027 8521	O/I Holder	15 - 28
B066 5116	Power Source Harness	127 - 15
B066 5300	MLB Board	127 - 36
B066 5501	Spacer - 13mm	127 - 37
B070 1307	Decal - Caution Chart Paper Set	15 - 31
B070 1307	Caution Decal - Paper Set	175 - 42
B301 1136	Spring Plate - 0.4mm	41 - 6
B301 1286	Bushing - 6x10x6	25 - 21
B301 2141	Pulley - 39Z	37 - 31
B351 3835	Discharge Brush - Exit	33 - 18
B351 4135	Magnet Catch - Original Table	61 - 11
B477 1111	Front Side Plate	41 - 1
B477 1121	Rear Side Plate	41 - 2
B477 1131	Front Scanning Bracket	31 - 5
B477 1141	Rear Scanning Bracket	31 - 12
B477 1151	Left Frame Stay	41 - 7
B477 1161	Right Frame Stay	41 - 11
B477 1171	Arm Shaft	41 - 4
B477 1181	Sensor Bracket	41 - 15
B477 1185	Sensor Feeler	41 - 13
B477 1191	Front Left Stopper	31 - 1
B477 1510	Left Hinge	41 - 9

Part No.	Description	Page and Index No.
B477 1520	Right Hinge	41 - 12
B477 1731	Face Original Table	23 - 20
B477 1755	Back Original Table	23 - 27
B477 1761	Original Table Stopper	23 - 26
B477 1765	Spring Plate - Original Table Stop	23 - 25
B477 1775	Paper Feed Cover Bracket	29 - 12
B477 1791	Paper Feed Cover	27 - 13
B477 1821	Paper Feed Cover Grip	27 - 10
B477 1825	Paper Feed Release Lever	27 - 5
B477 1831	Grip Shaft	27 - 7
B477 1841	Front Cover Bracket	27 - 2
B477 1851	Rear Cover Bracket	27 - 4
B477 1861	Exit Cover	21 - 5
B477 1891	Front Cover	21 - 1
B477 1912	Rear Cover	21 - 7
B477 1922	Lower Cover	21 - 3
B477 2111	Pull Out Roller	29 - 14
B477 2121	Drive Relay Roller	29 - 16
B477 2131	Inverter Roller Stay	33 - 13
B477 2141	Lower Paper Feed Guide	29 - 23
B477 2143	Lower Anti-static Brush	29 - 22
B477 2145	Guide Bracket	29 - 2
B477 2151	Separation Cap	29 - 24
B477 2161	Lower Grounding Plate	29 - 25
B477 2172	Front Entrance Guide	25 - 17
B477 2182	Rear Entrance Guide	25 - 10
B477 2191	Separation Shaft	25 - 14
B477 2221	Pick-up Roller Bracket	25 - 3
B477 2231	Pick-up Roller Lever	25 - 9
B477 2262	Original Table Base	23 - 8
B477 2263	Cushion	23 - 9
B477 2264	Base Cushion Sheet	23 - 16
B477 2272	Table Side Fence	23 - 1
B477 2281	Original Sensor Bracket	23 - 11
B477 2286	Original Sensor Feeler Stud	23 - 7

Part No.	Description	Page and Index No.
B477 2291	Original Table Stay	23 - 23
B477 2322	Base Lift Shaft	23 - 13
B477 2323	Base Lift Lever	23 - 12
B477 2332	Motor Bracket	39 - 29
B477 2333	Motor Bracket Cushion	41 - 3
B477 2341	Upper Paper Feed Guide	27 - 26
B477 2351	Driven Pull Out Roller	27 - 21
B477 2361	Pull Out Roller Bracket	27 - 12
B477 2372	Driven Paper Feed Roller	27 - 24
B477 2373	Relay Roller Arm	27 - 23
B477 2382	Paper Size Sensor Bracket	27 - 18
B477 2391	Paper Feed Grounding Plate	27 - 14
B477 2411	Drive Entrance Scanning Roller	29 - 15
B477 2421	Drive Scanning Roller	31 - 11
B477 2425	Front Scanning Roller Arm	31 - 10
B477 2431	Front Scanning Arm	31 - 9
B477 2441	Exit CIS Roller	33 - 15
B477 2451	Rear Lever Shaft - Misfeed Removal	31 - 26
B477 2452	Lever Shaft - Misfeed Removal	31 - 15
B477 2453	Rear Lock Hook - CIS	31 - 14
B477 2455	Front Lock Hook - CIS	31 - 17
B477 2471	Entrance Scanning Guide Plate	29 - 20
B477 2480	Upper Exit Scanning Guide Plate	31 - 27
B477 2481	Entrance Scanning Guide	31 - 21
B477 2487	Upper Exit Scanning Sheet	31 - 22
B477 2491	Anti-static Brush	31 - 20
B477 2495	Paper Feed Sensor Bracket	31 - 18
B477 2511	Scanning Roller	31 - 8
B477 2516	Discharge Brush	31 - 25
B477 2517	Scanning Guide Plate	31 - 6
B477 2521	Scanning Roller Cover	31 - 23
B477 2561	Entrance Scanning Base	29 - 10
B477 2574	Roller Arm	29 - 8
B477 2575	Entrance Scanning Roller Shaft	29 - 7
B477 2577	Driven Entrance Scanning Roller	29 - 4


Part No.	Description	Page and Index No.
B477 2581	Entrance Scanning Guide	29 - 1
B477 2611	Lower Exit	35 - 14
B477 2621	Anti-static Brush	35 - 12
B477 2621	Anti-static Brush	33 - 2
B477 2631	Lower Exit Guide Plate	35 - 4
B477 2636	Driven Exit Scanning Roller	35 - 6
B477 2637	Driven Exit Arm	35 - 8
B477 2641	Long Arm Shaft	35 - 3
B477 2645	Short Arm Shaft	35 - 5
B477 2651	Back Scanning Roller	35 - 11
B477 2653	Bushing - 6mm	35 - 9
B477 2661	Back Scanning Positioning Pin	35 - 2
B477 2665	Registration Sensor Bracket	29 - 18
B477 2682	CIS Sheet Bracket	33 - 8
B477 2683	CIS Sheet	33 - 7
B477 2711	Pressure Plate	21 - 2
B477 2715	Pressure Plate Tape	35 - 13
B477 2715	Pressure Plate Tape	21 - 4
B477 2811	Drive Exit Roller	33 - 16
B477 2820	Upper Exit Guide Plate	33 - 17
B477 2841	Lower Exit Guide	35 - 23
B477 2851	Lower Exit Guide Plate Sheet	35 - 22
B477 2861	Driven Exit Roller	35 - 19
B477 2872	Exit Arm	35 - 20
B477 2875	Exit Shaft	35 - 24
B477 2881	Guide Plate Bracket	35 - 15
B477 3111	Paper Feed Motor Bracket	37 - 3
B477 3115	Paper Feed Motor Stay	37 - 2
B477 3121	Separation Roller Shaft	37 - 10
B477 3123	Gear - 24Z	37 - 11
B477 3131	Reverse Roller Shaft	33 - 12
B477 3141	Gear - 23Z	37 - 22
B477 3143	Gear - 20Z	37 - 24
B477 3145	Pulley	37 - 18
B477 3151	Gear - 31Z	37 - 7

Part No.	Description	Page and Index No.
B477 3161	Gear - 37Z	37 - 6
B477 3163	Gear - 50Z	37 - 5
B477 3171	Pulley	37 - 30
B477 3173	Pulley	37 - 27
B477 3175	Pulley	39 - 33
B477 3177	Pulley	37 - 26
B477 3181	Paper Feed Drive Bracket	37 - 19
B477 3211	Scanning Motor Bracket	39 - 15
B477 3215	Scanning Motor Stay	39 - 14
B477 3217	Pulley	39 - 17
B477 3231	Tightner	39 - 35
B477 3241	Gear - 21Z	35 - 1
B477 3243	Pulley	33 - 5
B477 3245	Pulley	33 - 3
B477 3251	Pick-up Roller Cam	37 - 21
B477 3711	Paper Feed Motor	37 - 1
B477 3721	Scanning Motor	39 - 13
B477 3731	Exit Motor	39 - 11
B477 3811	Timing Belt	37 - 17
B477 3812	Timing Belt	37 - 23
B477 3813	Timing Belt	37 - 29
B477 3814	Timing Belt	39 - 21
B477 3815	Timing Belt	39 - 18
B477 3816	Timing Belt	39 - 22
B477 3817	Timing Belt	31 - 24
B477 3818	Timing Belt	39 - 19
B477 3819	Timing Belt	33 - 4
B477 3820	Timing Belt	37 - 15
B477 3821	Timing Belt	37 - 28
B477 3931	CIS Inverter Bracket	33 - 6
B477 4111	Spring	27 - 20
B477 4113	Spring	27 - 25
B477 4115	Spring	29 - 3
B477 4117	Spring	27 - 6
B477 4121	Spring	31 - 3

Part No.	Description	Page and Index No.
B477 4123	Spring	31 - 4
B477 4125	Spring	31 - 16
B477 4127	Exit Arm Spring	35 - 7
B477 4129	Spring - 12n	35 - 10
B477 4131	Spring	35 - 18
B477 4132	Spring	35 - 21
B477 4141	Spring - 12.6n	39 - 31
B477 4311	Decal - Original Base	23 - 4
B477 4311	Decal - Original Base	175 - 32
B477 4331	Decal - Original Size	27 - 11
B477 4331	Decal - Original Size	175 - 33
B477 4351	Decal - Misfeed Removal	27 - 9
B477 4351	Decal - Misfeed Removal	175 - 34
B477 4361	Decal - Misfeed Removal - Exit	175 - 35
B477 4361	Decal - Misfeed Removal - Exit	21 - 11
B477 4381	Caution Decal - CIS	175 - 36
B477 4381	Caution Decal - CIS	21 - 9
B477 4391	Decal - Exposure Glass Cleaning	175 - 37
B477 4391	Decal - Exposure Glass Cleaning	17 - 11
B477 4431	Decal - Original Table	15 - 33
B477 4431	Decal - Original Table	21 - 8
B477 4431	Decal - Original Table	175 - 38
B477 4911	Rear Cover Sponge	21 - 6
B477 4912	Paper Feed Cover Sponge	27 - 3
B477 4921	Clamp	41 - 16
B477 5515	Main ROM	39 - 37
B477 5561	ADF Main Control Board	39 - 8
B477 5611	Detection Sensor Harness	39 - 4
B477 5621	Original Sensor Harness	39 - 5
B477 5631	Original Table Harness	23 - 29
B477 5641	Paper Size Sensor Harness	39 - 2
B477 5651	Paper Size Relay Harness	27 - 15
B477 5661	Registration Sensor Harness	39 - 3
B477 5671	Registration Relay Harness	27 - 27
B477 5671	Registration Relay Harness	23 - 17

Part No.	Description	Page and Index No.
B477 5681	Registration Sensor Relay Harness	29 - 26
B477 5691	Paper Feed Motor Harness	39 - 9
B477 5711	Pick-up Motor Harness	39 - 7
B477 5721	CIS Harness	39 - 10
B477 5731	ADF-CIS Harness	39 - 6
B477 5741	Original Connecting Harness	43 - 24
B477 5751	Interface Harness	39 - 1
B477 5761	CIS Harness	39 - 36
B477 5820	Contact Image Sensor	33 - 14
B478 3505	Timing Belt - B40S2M84	71 - 32
G011 1058	Snap Ring	71 - 10
G020 3566	Nut - 2.4mm	89 - 1
G029 1982	LD - Decal	175 - 39
G029 1982	LD - Decal	45 - 2
G029 1982	LD - Decal	49 - 28
G331 5700	SDRAM - 128MB	127 - 7
G564 4151	Rail - Side Fence	23 - 3
G564 6076	Decal - Exposure Glass	27 - 8
G564 6076	Decal - Exposure Glass	175 - 40
G570 2827	Supporting Plate	51 - 16
H053 1150	Stepped Screw - Locking	91 - 18
H053 2205	Bushing - M4	123 - 20
H084 1501	Trust Screw	97 - 14
H521 1336	Lock Spring	107 - 20

Part No.	Description	Page and Index No.
N803 1000	Case - Flash Memory Card	177 - 4
N803 6701	Flash Memory Card-4MB	177 - 3



Part No.	Description	Page and Index No.
AA00 0059	Caution Decal - English	175 - 5
AA00 0059	Caution Decal - English	17 - 4
AA00 1213	Decal - B2	73 - 4
AA00 1213	Decal - B2	175 - 6
AA00 1394	Decal - Toner Supply	175 - 7
AA00 1394	Decal - Toner Supply	75 - 37
AA00 2010	Decal - Paper Level	55 - 21
AA00 2010	Decal - Paper Level	53 - 14
AA00 2010	Decal - Paper Level	59 - 21
AA00 2010	Decal - Paper Level	175 - 8
AA00 2246	Decal - Caution	175 - 9
AA00 2246	Decal - Caution	55 - 3
AA00 2258	Decal - Paper Size - LT	59 - 6
AA00 2258	Decal - Paper Size LT	175 - 10
AA00 2259	Decal - Paper Size - A4	59 - 6
AA00 2259	Decal - Paper Size - A4	175 - 10
AA00 2261	Decal - Universal Tray	175 - 11
AA00 2261	Decal - Universal Tray	59 - 7
AA00 3014	Decal - Right Paper Set (KOR)	55 - 12
AA00 3015	Decal - Left Paper Set (KOR)	53 - 12
AA00 0108	Ozone Filter	17 - 22
AA01 0114	Front Ozone Filter	17 - 23
AA01 2060	Development Filter	79 - 17
AA01 2060	Development Filter	85 - 9
AA01 2119	Filter	17 - 18
AA02 1025	Magnet Catch	113 - 12
AA04 0056	Driven Roller	107 - 5
AA04 0056	Driven Roller	105 - 7
AA04 3269	Timing Belt - S2M114	119 - 5
AA04 3271	Timing Belt S3M196T	53 - 24
AA04 3290	Timing Belt	107 - 24
AA04 3291	Timing Belt	113 - 4
AA04 3292	Timing Belt	113 - 9
AA04 3293	Timing Belt	115 - 10
AA04 3294	Timing Belt	117 - 9

Part No.	Description	Page and Index No.
AA04 3575	Timing Belt	67 - 7
AA04 3575	Timing Belt	65 - 18
AA04 3576	Timing Belt	65 - 42
AA04 3944	Timing Belt	71 - 21
AA04 3945	Timing Belt	121 - 22
AA04 3946	Timing Belt	119 - 18
AA04 3948	Timing Belt	121 - 15
AA06 0221	Gripper Solenoid Spring	49 - 7
AA06 0291	Spring	75 - 3
AA06 0291	Spring	77 - 24
AA06 0534	Tray Lock Spring - 19mm	145 - 2
AA06 0539	Stripper Pawl Spring	97 - 12
AA06 0592	Lock Spring - Tandem Tray	143 - 2
AA06 0718	Tension Spring	107 - 21
AA06 0720	Tension Spring - 7.75N	119 - 8
AA06 0728	Tension Spring	111 - 12
AA06 0757	Tension Spring - Long	57 - 5
AA06 0758	Tension Spring - Short	57 - 5
AA06 0759	Tension Spring	53 - 31
AA06 0763	Tension Spring	49 - 17
AA06 0792	Tension Spring	121 - 17
AA06 0806	Spring	113 - 16
AA06 0842	Tension Spring	37 - 4
AA06 0846	Tension Spring	39 - 16
AA06 0887	Spring	69 - 19
AA06 0888	Spring	69 - 14
AA06 0890	Spring	73 - 29
AA06 0891	Spring	85 - 11
AA06 0892	Pick-off Pawl Spring	89 - 3
AA06 0893	Spring	101 - 1
AA06 0894	Spring	97 - 8
AA06 0896	Spring	63 - 30
AA06 0897	Spring	63 - 18
AA06 0898	Spring	63 - 8
AA06 0899	Spring	63 - 11

Part No.	Description	Page and Index No.
AA06 0900	Spring	65 - 21
AA06 0901	Spring	65 - 17
AA06 0902	Spring	105 - 1
AA06 0903	Spring	103 - 5
AA06 0904	Spring	65 - 40
AA06 0911	Spring	71 - 26
AA06 0914	Stripper Pawls Spring	97 - 25
AA06 0916	Slider Spring	97 - 13
AA06 2251	Spring - Large	135 - 5
AA06 2252	Spring - Small	135 - 4
AA06 2284	Pressure Spring	83 - 20
AA06 2318	Spring	111 - 2
AA06 2318	Spring	117 - 19
AA06 2320	Spring	109 - 7
AA06 3052	Turret Spring	137 - 17
AA06 3248	Charge Terminal Spring	83 - 14
AA06 3249	Grid Terminal Spring	83 - 15
AA06 3254	Driven Roller Spring	73 - 2
AA06 3255	Exit Roller Spring	73 - 17
AA06 3268	Connector Spring	135 - 22
AA06 3310	Guide Plate Spring	91 - 19
AA06 3345	Spring - Belt Drive Shaft	25 - 19
AA06 3366	Cruck Spring	75 - 24
AA06 3487	Spring - 10mm	67 - 22
AA06 3490	Spring - 21.6mm	119 - 13
AA06 3575	Toner Bottle Spring	75 - 27
AA06 3576	Spring	89 - 30
AA06 3577	Compression Spring	103 - 10
AA06 3579	Compression Spring	111 - 6
AA06 3581	Compression Spring	109 - 25
AA06 3582	Compression Spring	111 - 20
AA06 3610	Spring - 4060mN	89 - 10
AA06 3654	Spring	121 - 27
AA06 3655	Spring	113 - 23
AA06 3851	Pressure Spring	95 - 36

Part No.	Description	Page and Index No.
AA06 3877	Spring	93 - 7
AA06 3878	Spring	67 - 10
AA06 3879	Spring	103 - 25
AA06 3880	Spring	131 - 15
AA06 3880	Spring	135 - 11
AA06 3886	Spring	95 - 10
AA06 3889	Heat Sink Spring	63 - 34
AA06 6211	Rear Lock Spring	73 - 8
AA06 6309	Torsion Spring	119 - 21
AA06 6352	Spring	97 - 20
AA06 6353	Spring	109 - 12
AA06 6592	Spring	103 - 22
AA06 6651	Spring	119 - 16
AA07 0044	Slide Rail - Tandem LCT	143 - 10
AA07 0058	Right Slide Rail	139 - 17
AA07 0061	Left Slide Rail	141 - 5
AA08 0034	Bushing - 4x5x7	103 - 9
AA08 0034	Bushing - 4x5x7	73 - 16
AA08 0034	Bushing - 4x5x7	113 - 22
AA08 0034	Bushing - 4x5x7	111 - 7
AA08 0037	Bushing - 6mm	27 - 19
AA08 0147	Front Bushing	83 - 5
AA08 0148	Rear Bushing	83 - 12
AA08 0152	Bushing - 4x12x13	81 - 6
AA08 0176	Bushing	85 - 18
AA08 0184	Bushing - Fusing Exit	103 - 18
AA08 0240	Bushing - MM5	103 - 26
AA08 0241	Bushing - M4	67 - 21
AA08 0274	Bushing	97 - 18
AA08 0327	Bushing - M4	65 - 3
AA08 2058	Bushing - 6x10x9mm	93 - 22
AA08 2064	Bushing - 10mm	139 - 2
AA08 2094	Bushing - Brush Roller	87 - 11
AA08 2101	Bushing - 6x10x6	89 - 19
AA08 2101	Bushing - 6x10x6	87 - 10

Part No.	Description	Page and Index No.
AA08 2101	Bushing - 6x10x6	93 - 14
AA08 2116	Bushing - M8	69 - 13
AA08 2116	Bushing - M8	73 - 11
AA08 2116	Bushing - M8	111 - 10
AA08 2117	Bushing - M6	105 - 3
AA08 2118	Bushing - M6	71 - 13
AA08 2118	Bushing - M6	111 - 9
AA08 2118	Bushing - M6	63 - 7
AA08 2118	Bushing - M6	113 - 17
AA08 2118	Bushing - M6	65 - 10
AA08 2118	Bushing - M6	115 - 3
AA08 2119	Roller Bushing	87 - 6
AA08 2120	Bushing	89 - 14
AA08 2121	Toner Collection Coil Bushing	87 - 3
AA08 2121	Toner Collection Coil Bushing	89 - 28
AA08 2122	Bushing	85 - 15
AA08 3019	Bushing	69 - 21
AA10 0006	Nut - M3.6	15 - 26
AA12 0067	Anti Static Brush	141 - 1
AA13 2013	Spacer	25 - 18
AA13 2024	Spacer - M6	75 - 33
AA13 2024	Spacer - M6	85 - 17
AA13 2024	Spacer - M6	93 - 9
AA13 2024	Spacer - M6	89 - 9
AA13 2024	Spacer - M6	87 - 9
AA13 2025	Spacer	121 - 29
AA13 2025	Spacer - 1x8x12	71 - 4
AA13 2152	Spacer - 8x20x1	39 - 27
AA13 2171	Spacer - 6x20x1	25 - 7
AA13 2174	Spacer - M8	47 - 2
AA13 2203	Spacer - 6mm	57 - 24
AA13 2203	Spacer - 6mm	135 - 2
AA13 2208	Spacer - M6	123 - 12
AA13 2208	Spacer - M6	85 - 29
AA14 0486	Lock Shaft	73 - 5

Part No.	Description	Page and Index No.
AA14 0685	Shaft - Back Fence Slider	53 - 21
AA14 0686	Shaft - Timing Pulley	53 - 29
AA14 0819	Feed Roller Shaft	69 - 18
AA14 0823	Pressure Roller Shaft	99 - 28
AA14 0824	Stripper Pawl Release Shaft	97 - 22
AA14 0828	Feed Roller Shaft	63 - 9
AA14 0829	Driven Shaft	65 - 4
AA14 3037	Development Cover Screw	97 - 10
AA14 3037	Development Cover Screw	101 - 16
AA14 3039	Spring Holder	41 - 5
AA14 3074	Stepped Screw - M4x5	29 - 13
AA14 3129	Shoulder Screw - Front Cover	111 - 3
AA14 3183	Stepped Screw	113 - 13
AA14 3307	Stepped Screw - M3	113 - 26
AA14 3307	Stepped Screw - M3	109 - 17
AA14 3402	Screw - Scale	65 - 6
AA14 3416	Stepped Screw - M4x3	17 - 12
AA14 3426	Stopped Screw - M4x17	111 - 26
AA14 3426	Stopped Screw - M4x17	81 - 5
AA14 3432	Stepped Screw - M3	89 - 31
AA14 3499	Stepped Screw	127 - 19
AA14 3520	Shoulder Screw - M3	43 - 8
AA14 3523	Shoulder Screw - M3	89 - 5
AA14 3715	Stepped Screw - M5	67 - 24
AA14 3718	Stepped Screw - M4	65 - 16
AA14 3749	Stand - Hexagonal Bolt M12x35	145 - 9
AA14 3758	Stepped Screw	75 - 21
AA14 3781	Binding Screw - M3x3.5	127 - 14
AA14 5817	Idler Shaft - Toner Bottle	75 - 5
AA14 9746	Stripper Shaft	97 - 26
AA15 0361	Slitter Cover Seal	77 - 13
AA15 0704	Seal - 90x29.5x0.2	43 - 2
AA15 1775	Seal - Fan	129 - 6
AA15 2315	Tank Seal	17 - 35
AA15 2431	Front Drum Seal	87 - 12

Part No.	Description	Page and Index No.
AA15 2441	Case Seal	69 - 5
AA15 2701	Duct Seal	17 - 17
AA15 3063	Seal - 4x10x70	55 - 17
AA15 3085	Inner Case Seal	87 - 13
AA15 3088	Cleaning Entrance Seal - 3x345x2	87 - 14
AA15 3138	Inner Cover Cushion - Right Rear	55 - 18
AA15 3144	Duct Seal - IPS A	137 - 20
AA15 3145	Duct Seal - IPS B	137 - 21
AA15 3146	Duct Seal - IPS C	137 - 22
AA15 3147	Duct Seal - IPS D	137 - 23
AA15 3148	Duct Seal - Charge A	137 - 11
AA15 3149	Duct Seal - Charge B	137 - 12
AA15 3150	Duct Seal - Fusing	137 - 8
AA15 3151	Duct Seal - PCU A	131 - 8
AA15 3152	Duct Seal - PCU B	131 - 9
AA15 3153	Duct Seal - PCU C	131 - 10
AA15 3154	Duct Seal - PCU	131 - 1
AA15 3155	Duct Seal - IPS	129 - 3
AA15 3156	Exhaust Duct Seal	129 - 11
AA15 3157	Joint Seal	85 - 19
AA16 1096	Stopper Cushion	135 - 17
AA16 1104	Cushion - Motor	141 - 26
AA16 1104	Cushion - Motor	129 - 1
AA16 1105	Cleaner Cushion	83 - 11
AA16 1119	Cushion - Wire	83 - 22
AA16 1122	Motor Cushion	119 - 3
AA16 1125	Rubber Cushion	127 - 18
AA16 1129	Cushion - Large	57 - 26
AA16 1130	Cushion - Small	57 - 29
AA16 1137	Cushion - 0.5	43 - 21
AA16 2079	Cushion	73 - 25
AB01 0087	Gear - 20Z	83 - 24
AB01 1391	Driven Reverse Gear - 21Z	65 - 27
AB01 1457	Transport Roller Gear	73 - 13
AB01 1459	Toner Collection Coil Gear	89 - 18

Part No.	Description	Page and Index No.
AB01 1459	Toner Collection Coil Gear	87 - 17
AB01 1460	Idler Gear	89 - 27
AB01 1460	Idler Gear	87 - 21
AB01 1461	Toner Recycling Connecting Gear	85 - 12
AB01 1462	Toner Recycling Gear	85 - 13
AB01 1463	Connecting Gear	115 - 5
AB01 1464	Turn Gear	115 - 1
AB01 1465	Idler Gear	63 - 5
AB01 1466	Gear - 35Z	67 - 6
AB01 1466	Gear - 35Z	63 - 25
AB01 1467	Gear - 38Z	65 - 23
AB01 1468	Gear - 21Z	65 - 24
AB01 1469	Gear - 19Z	65 - 11
AB01 1470	Gear - 18Z	65 - 13
AB01 1471	Reverse Gear	65 - 26
AB01 1478	Gear - 18Z	69 - 12
AB01 1482	Gear - 40Z	121 - 14
AB01 2028	Gear - 19Z	105 - 6
AB01 2031	Gear	107 - 14
AB01 2315	Gear - 156Z	121 - 13
AB01 2316	Fusing Gear	99 - 22
AB01 2317	Fusing Drive Gear	101 - 22
AB01 2318	Idler Gear	101 - 21
AB01 2319	Exit Gear	101 - 7
AB01 3492	Gear - 16Z	61 - 17
AB01 3747	Gear - 16Z	77 - 26
AB01 3748	Joint Gear - 15Z	77 - 25
AB01 3749	Gear - 15Z	77 - 27
AB01 3781	Gear - 30Z	57 - 37
AB01 3790	Gear - 25Z	79 - 13
AB01 3798	Gear - Z18	53 - 36
AB01 3868	Gear - 16Z	59 - 19
AB01 4077	Registration Roller Gear	71 - 20
AB01 4176	Cam Gear - 37z	93 - 24
AB01 7449	Gear - 21Z/24T	119 - 6

Part No.	Description	Page and Index No.
AB01 7606	Gear - 24Z/46Z	71 - 30
AB01 7607	Gear - 22Z/39Z	73 - 32
AB01 7608	Reverse Gear	71 - 11
AB01 7609	Reverse Gear	71 - 19
AB01 7611	Pick-off Pawl Cam	89 - 7
AB01 7612	Gear	87 - 20
AB01 7614	Pulley	115 - 4
AB01 7615	Gear	117 - 17
AB01 7616	Gear	113 - 3
AB01 7617	Gear - 21Z/38Z	63 - 16
AB01 7618	Pulley - 30Z/24Z	65 - 19
AB01 7619	Gear - 24Z/40Z	67 - 8
AB01 7640	Gear - 38Z/59Z	121 - 16
AB01 9197	Exit Gear	107 - 16
AB01 9200	Gear	107 - 23
AB01 9475	Gear - 48T	53 - 30
AB03 0427	Pulley - 81Z	119 - 9
AB03 0458	Pulley - 28Z	121 - 21
AB03 0577	Timing Pulley - 20Z	71 - 34
AB03 0578	Timing Pulley - 18Z	105 - 17
AB03 0578	Timing Pulley - 18Z	71 - 33
AB03 0579	Timing Pulley - 27Z	107 - 27
AB03 0583	Timing Pulley - 24Z	115 - 15
AB03 0722	Pulley - 13mm	73 - 28
AB03 0724	Pulley - 74Z	121 - 24
AB03 0725	Pulley - 89Z	119 - 24
AB03 0727	Pulley - 58Z	49 - 21
AB03 0731	Pulley - 29Z	115 - 7
AB03 0732	Jogger Pulley	117 - 20
AB03 0733	Pulley - 20T	65 - 41
AB03 0734	Pulley - 30Z	65 - 22
AB03 2058	Wire Pulley - M10	57 - 15
AB03 2069	Pulley	49 - 25
AB03 2070	Pulley	49 - 22
AB03 2716	Idle Pulley - M18	119 - 19

Part No.	Description	Page and Index No.
AB03 2717	Pulley - 26Z	49 - 2
AB03 2717	Pulley - 26Z	47 - 1
AB03 2719	Pulley - M10	57 - 17
AB03 3084	Timing Pulley - 15T	53 - 27
AB03 3085	Timing Pulley - 15T	53 - 20
AC01 2067	Exposure Glass	43 - 13
AC01 5037	Shield Glass	51 - 28
AC02 4007	Lens - L0	51 - 9
AC03 0147	1st Mirror	51 - 10
AC03 0148	2nd Mirror	51 - 22
AD00 4091	Charge Corona Unit	83 - 3
AD02 0053	Charge Corona Wire	83 - 19
AD02 2283	Front End Block	83 - 21
AD02 2285	Rear End Block	83 - 16
AD02 2306	Cover - Front End Block	83 - 25
AD02 2307	Cover - Rear End Block	83 - 17
AD02 3106	Charge Corona Casing	83 - 13
AD02 5023	Pick-off Pawl	89 - 4
AD04 1076	Cleaning Roller Cleaning Blade	93 - 1
AD04 1083	Cleaning Blade	89 - 8
AD04 3077	Toner Collection Coil	87 - 1
AD04 3078	Toner Collection Coil	85 - 24
AD04 7025	Exit Seal	93 - 11
AE01 1069	Hot Roller	99 - 23
AE02 0112	Pressure Roller	99 - 27
AE03 0017	Ball Bearing - 35x50x10	99 - 2
AE03 0018	Ball Bearing - 12x28x8	99 - 26
AE03 1024	Bushing - M4x7	101 - 9
AE03 1026	Bushing - Oil Supply Roller	95 - 9
AE03 1036	Bushing - 6mm	95 - 19
AE03 2014	Bushing - 30x35x13.5	99 - 1
AE04 0038	Cleaning Web Pressure Roller	95 - 14
AE04 2052	Cleaning Roller	101 - 10
AE04 4043	Hot Roller Stripper	97 - 27
AE04 5046	Cleaning Web	95 - 16

Part No.	Description	Page and Index No.
AF01 0091	Paper Tray (A4)	59 - 4
AF01 0092	Paper Tray - LT	59 - 4
AF01 1043	Bottom Plate	59 - 18
AF01 3005	Bottom Plate Pad	59 - 17
AF01 6079	Left Rear Side Fence	59 - 9
AF01 7029	Paper End Fence	59 - 15
AF02 0295	Vertical Driven Roller	67 - 20
AF02 0484	Driven Reverse Roller	113 - 24
AF02 0508	Exit Drive Roller	107 - 3
AF02 0562	Transport Roller	63 - 24
AF02 0562	Transport Roller	67 - 5
AF02 0564	Connecting Roller	73 - 12
AF02 0565	Inverter Roller	105 - 5
AF02 0578	Entrance Decura Roller	105 - 13
AF02 0579	Exit Decura Roller	105 - 12
AF02 1074	Entrance Inverter Roller	111 - 17
AF02 1075	Duplex Turn Roller	115 - 8
AF02 1076	Drive Inverter Roller	115 - 11
AF02 1077	Driven Transport Roller	115 - 9
AF02 1078	Left Drive Roller	115 - 12
AF02 1079	Right Drive Roller	115 - 14
AF02 2067	Guide Stopper Roller	109 - 27
AF02 2077	Driven Roller	109 - 21
AF02 2105	Roller - Slide Rail	57 - 28
AF02 2110	Transport Driven Roller	73 - 19
AF02 2126	Exit Roller - Driven	103 - 11
AF02 2149	Transport Roller	65 - 2
AF03 0050	Pick-up Roller (By-pass)	69 - 17
AF03 0051	Pick-up Roller	63 - 1
AF03 1065	Pare Feed Roller	63 - 3
AF03 1066	Paper Feed Roller (By-pass)	69 - 11
AF03 2050	Separation Roller	65 - 36
AF03 2050	Separation Roller	71 - 15
AF04 0055	Fusing Exit Roller	101 - 6
AF04 0561	Fusing Exit Roller - Upper	97 - 24

Part No.	Description	Page and Index No.
AG05 0092	Knob:Fusing	95 - 6
AG07 1011	Magnet Catch	141 - 9
AH01 2016	Caster - G60	145 - 7
AW01 0034	Original Width Sensor	43 - 1
AW01 0049	Photo Reflection Sensor	31 - 19
AW01 0049	Photo Reflection Sensor	27 - 22
AW01 0049	Photo Reflection Sensor	29 - 17
AW01 0058	Photosensor	111 - 24
AW01 0059	Original Sensor - H=1-66	43 - 18
AW01 0087	Photo Sensor - Ass'y	23 - 28
AW01 0098	Photointerruptor	69 - 2
AW01 0098	Photointerruptor	71 - 22
AW01 0098	Photointerruptor	63 - 13
AW02 0008	Photointerruptor	53 - 3
AW02 0056	Photointerruptor - EE-SX4235A-P1	53 - 35
AW02 0056	Photointerruptor - EE-SX4235A-P1	49 - 10
AW02 0056	Photointerruptor - EE-SX4235A-P1	71 - 25
AW02 0056	Photointerruptor - EE-SX4235A-P1	63 - 22
AW02 0056	Photointerruptor - EE-SX4235A-P1	57 - 9
AW02 0075	Photointerruptor	41 - 14
AW02 0075	Photointerruptor	37 - 13
AW02 0075	Photointerruptor	33 - 19
AW02 0086	Photointerruptor	23 - 10
AW02 0095	Photointerruptor	27 - 17
AW02 0104	Photointerruptor	27 - 16
AW02 0120	Photointerruptor - Flat	73 - 22
AW02 0120	Photointerruptor - Flat	55 - 10
AW02 0120	Photointerruptor - Flat	123 - 31
AW02 0120	Photointerruptor - Flat	117 - 3
AW02 0120	Photointerruptor - Flat	95 - 29
AW02 0128	Photointerruptor	117 - 13
AW02 0130	Photointerruptor	117 - 14
AW02 0130	Photointerruptor	109 - 20
AW02 0133	Photointerruptor	103 - 13
AW10 0075	Thermistor	99 - 6

Part No.	Description	Page and Index No.
AW10 0076	Thermistor:inner Back	99 - 15
AW11 0026	Thermostat - 180 β C	99 - 10
AW11 0027	Thermostat - 179 β C	99 - 11
AW20 0005	Reed Switch	101 - 15
AW23 0015	Toner Density Sensor	79 - 10
AW31 0003	Toner End Sensor	77 - 11
AW33 0003	Drum Potential Sensor	85 - 6
AW50 0010	Push Switch	135 - 16
AW50 0023	Push Switch	123 - 4
AX04 0061	Cleaner Motor - DC 0.5W	83 - 23
AX04 0096	Stepping Motor - DC 18W	37 - 25
AX04 0107	DC Motor - 19.2W	53 - 34
AX04 0135	Paper Tray Motor	135 - 8
AX04 0136	Cleaning Motor	95 - 27
AX06 0151	Stepper Motor	119 - 2
AX06 0235	DC Motor	123 - 19
AX06 0250	Polygon Mirror Motor	51 - 13
AX06 0253	Fusing Motor	119 - 23
AX20 0242	Magnetic Clutch	69 - 22
AX20 0243	Magnetic Clutch	115 - 6
AX31 0044	Counter	139 - 7
AX40 0063	Anticondensation Heater - 120V 9W	43 - 9
AX40 0064	Anticondensation Heater - 230V 9W	43 - 9
AX40 0150	Heater - 115V 18W	143 - 8
AX40 0151	Heater - 240V 18W	143 - 8
AX40 0156	Heater - 115V 18W	145 - 13
AX40 0157	Heater - 240V 18W	145 - 13
AX40 0160	Heater - 120V 9W	139 - 12
AX40 0161	Heater - 230V 9W	139 - 12
AX44 0163	Fusing Lamp - 120V 550W	99 - 24
AX44 0164	Fusing Lamp - 230V 550W	99 - 24
AX50 0081	Exposure Lamp	47 - 9
AX64 0098	Fan Motor - DC5V 1.2W	127 - 11
AX64 0110	Axial Fan - Mm40 24V	17 - 14
AX64 0135	Cooling Fan - 24V	45 - 17

Part No.	Description	Page and Index No.
AX64 0136	Cooling Fan - 24V	141 - 19
AX64 0136	Cooling Fan - 24V	131 - 4
AX64 0137	Cooling Fan - 24V	125 - 12
AX64 0137	Cooling Fan - 24V	15 - 18
AX65 0030	Cooling Fan - 24V	129 - 12
AZ00 0070	Power Supply Cord - 230V	133 - 11
AZ24 0073	DC Power Supply Board - 120V	133 - 7
AZ24 0078	DC Power Supply Board - 240V	133 - 7
AZ24 0079	DC Power Supply Board - 240V (R-LIN)	133 - 7
AZ30 0053	Development Power Pack	131 - 5
AZ32 0106	Charge Power Pack	129 - 13
AZ32 0107	Transfer Power Pack	93 - 26
AZ50 0060	Exposure Lamp Inverter	47 - 23
GC02 5010	Lens L2	51 - 19

Part No.	Description	Page and Index No.
0313 0040B	Philips Pan Head Screw - M3x4	143 -103
0313 0050B	Philips Pan Head Screw - M3x5	99 -108
0313 0080B	Philips Pan Head Screw - M3x8	57 -105
0313 0080B	Philips Pan Head Screw - M3x8	53 -103
0313 0080B	Philips Pan Head Screw - M3x8	99 -106
0313 0100B	Philips Pan Head Screw - M3x10	17 -104
0313 0100B	Philips Pan Head Screw - M3x10	163 -106
0313 0120B	Philips Pan Head Screw - M3x12	57 -110
0314 0040B	Philips Pan Head Screw - M4x4	143 -104
0314 0060B	Philips Pan Head Screw - M4x6	77 -107
0314 0060B	Philips Pan Head Screw - M4x6	55 -105
0314 0060B	Philips Pan Head Screw - M4x6	49 -106
0314 0060B	Philips Pan Head Screw - M4x6	53 -105
0314 0060B	Philips Pan Head Screw - M4x6	89 -101
0314 0080B	Philips Pan Head Screw - M4x8	49 -104
0314 0100B	Philips Pan Head Screw - M4x10	99 -107
0314 0120B	Philips Pan Head Screw - M4x12	49 -105
0353 0040B	Screw - M3X4	113 -110
0353 0040B	Screw - M3X4	127 -106
0353 0040B	Screw - M3X4	67 -103
0353 0040B	Screw - M3X4	43 -101
0353 0040B	Screw - M3X4	63 -104
0353 0040B	Screw - M3X4	65 -101
0353 0050B	Philips Truss Head Screw - M3x5	111 -104
0353 0050B	Philips Truss Head Screw - M3x5	113 -104
0353 0050B	Philips Truss Head Screw - M3x5	39 -106
0353 0060B	Philips Pan Head Screw - M3x6	107 -111
0353 0060B	Philips Pan Head Screw - M3x6	95 -106
0353 0060B	Philips Pan Head Screw - M3x6	103 -102
0353 0060B	Philips Pan Head Screw - M3x6	43 -102
0353 0060B	Philips Pan Head Screw - M3x6	49 -103
0353 0060B	Philips Pan Head Screw - M3x6	79 -101
0353 0060B	Philips Pan Head Screw - M3x6	45 -102
0353 0060B	Philips Pan Head Screw - M3x6	51 -105
0353 0080B	Screw - M3X8	51 -101

Part No.	Description	Page and Index No.
0353 0080B	Screw - M3X8	103 -108
0353 0080B	Screw - M3X8	43 -104
0353 0120B	Bind Screw - M3x12	137 -105
0354 0050B	Bind Screw - M4x5	119 -106
0354 0060B	Screw - M4X6	49 -107
0354 0060B	Screw - M4X6	95 -108
0354 0060B	Screw - M4X6	111 -106
0354 0080B	Screw - M4X8	75 -108
0354 0080B	Screw - M4X8	95 -109
0354 0080B	Screw - M4X8	45 -103
0354 0080B	Screw - M4X8	43 -105
0354 0080B	Screw - M4X8	123 -103
0354 0080B	Screw - M4X8	85 -101
0354 0080B	Screw - M4X8	83 -101
0354 0080B	Screw - M4X8	49 -101
0354 0080B	Screw - M4X8	15 -103
0354 0080B	Screw - M4X8	77 -108
0354 0080B	Screw - M4X8	51 -102
0354 0080B	Screw - M4X8	79 -105
0354 0120B	Screw - M4X12	81 -103
0354 0300B	Screw - M3x30	141 -111
0360 3006B	Screw - M3X6	127 -107
0360 4006B	Hexagonal Head Screw - M4x6	97 -101
0360 4006B	Hexagonal Head Screw - M4x6	95 -101
0360 4006B	Hexagonal Head Screw - M4x6	99 -103
0360 4006B	Hexagonal Head Screw - M4x6	143 -105
0360 4006B	Hexagonal Head Screw - M4x6	101 -101
0360 4008B	Screw - M3 X 8	59 -104
0360 4008B	Screw - M3x8	139 -105
0414 0102B	Tapping Screw M4x10	135 -104
0434 0060B	Pan Head Self-tapping Screw - M4x6	53 -104
0434 0060B	Pan Head Self-tapping Screw - M4x6	55 -102
0434 0060B	Pan Head Self- Tapping Screw - M4x6	57 -104
0434 0080B	Pan Head Self - Tapping Screw - M4x8	141 -107
0450 3006B	Tapping Screw - M3x6	23 -102

Part No.	Description	Page and Index No.
0450 3006B	Tapping Screw - M3x6	113 -103
0450 3006B	Tapping Screw - M3x6	75 -107
0450 3008B	Tapping Screw - M3x8	29 -104
0450 3008B	Tapping Screw - M3x8	17 -102
0450 3008B	Tapping Screw - M3x8	91 -101
0450 3008B	Tapping Screw - M3x8	75 -101
0450 3008B	Tapping Screw - M3x8	35 -103
0450 3008B	Tapping Screw - M3x8	113 -108
0450 3008B	Tapping Screw - M3x8	93 -102
0450 3008B	Tapping Screw - M3x8	43 -103
0450 3008B	Tapping Screw - M3x8	61 -101
0450 3008B	Tapping Screw - M3x8	59 -107
0450 3008B	Tapping Screw - M3x8	109 -103
0450 3008B	Tapping Screw - M3x8	121 -105
0450 3008B	Tapping Screw - M3x8	27 -103
0450 3008B	Tapping Screw - M3x8	15 -101
0450 3008B	Tapping Screw - M3x8	23 -101
0450 3008B	Tapping Screw - M3x8	111 -105
0450 4008B	Tapping Screw - 4x8	17 -105
0450 4008B	Tapping Screw - 4x8	129 -104
0450 4008B	Tapping Screw - 4x8	77 -105
0450 4008B	Tapping Screw - 4x8	59 -106
0450 4008B	Tapping Screw - 4x8	131 -102
0450 4008B	Tapping Screw - 4x8	65 -108
0450 4008B	Tapping Screw - 4x8	109 -104
0450 4008B	Tapping Screw - 4x8	121 -109
0450 4010B	Tapping Screw - 4x10	15 -102
0450 4016B	Tapping Screw - 4x16	129 -105
0450 4035B	Philips Tapping Screw - M4x35	131 -103
0451 3006B	Tapping Screw - M3x6	31 -101
0451 3006B	Tapping Screw - M3x6	29 -101
0451 3006B	Tapping Screw - M3x6	27 -105
0451 3006B	Tapping Screw - M3x6	127 -101
0451 3006B	Tapping Screw - M3x6	41 -102
0451 3006B	Tapping Screw - M3x6	125 -109

Part No.	Description	Page and Index No.
0451 3006B	Tapping Screw - M3x6	139 -106
0451 3006B	Tapping Screw - M3x6	35 -104
0451 3006B	Tapping Screw - M3x6	145 -101
0451 3006B	Tapping Screw - M3x6	141 -108
0451 3006B	Tapping Screw - M3x6	37 -102
0451 3006B	Tapping Screw - M3x6	33 -101
0451 3006B	Tapping Screw - M3x6	19 -101
0451 3006B	Tapping Screw - M3x6	39 -101
0451 3006H	Tapping Screw - 3x6	21 -102
0451 3008B	Tapping Screw - M3x8	135 -103
0451 3008B	Tapping Screw - M3x8	131 -105
0451 3008B	Tapping Screw - M3x8	59 -101
0451 3008B	Tapping Screw - M3x8	27 -102
0451 3008B	Tapping Screw - M3x8	125 -101
0451 3008B	Tapping Screw - M3x8	133 -102
0451 3008B	Tapping Screw - M3x8	129 -107
0451 3012H	Tapping Screw - 3x12	17 -102
0451 3014B	Tapping Screw - M3-14	127 -103
0451 4006B	Tapping Screw - 4x6	37 -101
0451 4006B	Tapping Screw - 4x6	113 -109
0451 4006B	Tapping Screw - 4x6	39 -103
0451 4006B	Tapping Screw - 4x6	109 -102
0451 4006B	Tapping Screw - 4x6	117 -101
0451 4008B	Philips Tapping Screw - M4x8	71 -102
0451 4008B	Philips Tapping Screw - M4x8	129 -106
0451 4008B	Philips Tapping Screw - M4x8	121 -101
0451 4008B	Philips Tapping Screw - M4x8	67 -101
0451 4008B	Philips Tapping Screw - M4x8	145 -104
0451 4008B	Philips Tapping Screw - M4x8	59 -102
0451 4008B	Philips Tapping Screw - M4x8	141 -101
0451 4008B	Philips Tapping Screw - M4x8	103 -101
0451 4008B	Philips Tapping Screw - M4x8	107 -105
0451 4008B	Philips Tapping Screw - M4x8	135 -102
0451 4008B	Philips Tapping Screw - M4x8	63 -101
0451 4008B	Philips Tapping Screw - M4x8	123 -101

Part No.	Description	Page and Index No.
0451 4008B	Philips Tapping Screw - M4x8	61 -104
0451 4008B	Philips Tapping Screw - M4x8	137 -102
0451 4008B	Philips Tapping Screw - M4x8	45 -108
0451 4008B	Philips Tapping Screw - M4x8	17 -106
0451 4008B	Philips Tapping Screw - M4x8	65 -104
0451 4008B	Philips Tapping Screw - M4x8	109 -101
0451 4008B	Philips Tapping Screw - M4x8	75 -105
0451 4008B	Philips Tapping Screw - M4x8	139 -101
0451 4008B	Philips Tapping Screw - M4x8	111 -107
0451 4008B	Philips Tapping Screw - M4x8	119 -104
0451 4008B	Philips Tapping Screw - M4x8	117 -106
0451 4008B	Philips Tapping Screw - M4x8	125 -106
0451 4008B	Philips Tapping Screw - M4x8	133 -101
0451 4008B	Philips Tapping Screw - M4x8	105 -101
0451 4008B	Philips Tapping Screw - M4x8	15 -104
0451 4008B	Philips Tapping Screw - M4x8	127 -102
0451 4008B	Philips Tapping Screw - M4x8	85 -104
0451 4008B	Philips Tapping Screw - M4x8	43 -106
0451 4008B	Philips Tapping Screw - M4x8	73 -115
0451 4008B	Philips Tapping Screw - M4x8	55 -103
0451 4008B	Philips Tapping Screw - M4x8	131 -101
0451 4008B	Philips Tapping Screw - M4x8	69 -104
0451 4008B	Philips Tapping Screw - M4x8	143 -102
0451 4010B	Tapping Screw - 4x10	51 -103
0451 4010B	Tapping Screw - 4x10	119 -101
0451 4010B	Tapping Screw - 4x10	141 -105
0451 4010H	Tapping Screw - 4x10	17 -101
0451 4020B	Tapping Screw - M4x20	125 -112
0451 4020B	Tapping Screw - M4x20	45 -105
0452 3006B	Tapping Screw - M3x6	57 -111
0452 3006V	Tapping Screw - M3x6	47 -101
0452 3008B	Tapping Screw - M3x8	85 -102
0452 3008B	Tapping Screw - M3x8	103 -103
0452 3008B	Tapping Screw - M3x8	87 -102
0452 3008B	Tapping Screw - M3x8	89 -102

Part No.	Description	Page and Index No.
0452 3008H	Binding Self-Tapping Screw - 3x8	61 -103
0452 3008W	Binding Self Tapping Screw - M3x8	77 -101
0452 3010B	Tapping Bind Screw - M3x10	79 -103
0452 3010B	Tapping Bind Screw - M3x10	87 -103
0452 3010B	Tapping Bind Screw - M3x10	89 -103
0452 4008B	Binding Self Tapping Screw - M4x8	55 -106
0452 4008B	Binding Self Tapping Screw - M4x8	53 -108
0452 4010B	Tapping Bind Screw - M4x10	53 -109
0453 3006B	Tapping Screw - M3x6	103 -104
0453 3006B	Tapping Screw - M3x6	29 -105
0453 3006B	Tapping Screw - M3x6	47 -102
0453 3006B	Tapping Screw - M3x6	145 -102
0453 3006B	Tapping Screw - M3x6	43 -107
0453 3006B	Tapping Screw - M3x6	73 -110
0453 3006B	Tapping Screw - M3x6	71 -109
0453 3006B	Tapping Screw - M3x6	61 -102
0453 3008B	Bind Tapping Screw - M3x8	107 -110
0453 3008B	Bind Tapping Screw - M3x8	95 -110
0453 3008B	Bind Tapping Screw - M3x8	125 -107
0453 3008B	Bind Tapping Screw - M3x8	121 -102
0453 3008B	Bind Tapping Screw - M3x8	137 -108
0453 3008B	Bind Tapping Screw - M3x8	117 -108
0453 4008B	Tapping Bind Screw - M4x8	139 -102
0453 4008B	Tapping Bind Screw - M4x8	55 -108
0453 4008B	Tapping Bind Screw - M4x8	59 -103
0573 0030E	Hexagon Headless Set Screw - M3x3	65 -102
0623 0120E	Spring Pin - M3x12	91 -102
0623 0140E	Spring Pin - 3x14mm	119 -108
0632 0100G	Pin - 2x10mm	71 -104
0632 0120G	Parallel Pin - 2x12	33 -104
0632 0120G	Parallel Pin - 2x12	37 -103
0632 0140G	Parallel Pin	23 -104
0633 0180G	Parallel Pin - 3x18mm	121 -111
0633 0180G	Parallel Pin - 3x18mm	91 -103
0633 0200G	Pin - M3x20	57 -101

Part No.	Description	Page and Index No.
0707 4050B	Bushing - 4x5	141 -112
0707 4050B	Bushing - 4x5	129 -102
0710 0030B	Hexagon Nut - M3	163 -107
0720 0025B	Retaining Ring - M2.5	83 -102
0720 0030B	Retaining Ring - M3	41 -101
0720 0030E	Retaining Ring - M3	79 -104
0720 0030E	Retaining Ring - M3	95 -104
0720 0030E	Retaining Ring - M3	113 -101
0720 0030E	Retaining Ring - M3	97 -102
0720 0030E	Retaining Ring - M3	35 -102
0720 0030E	Retaining Ring - M3	81 -102
0720 0030E	Retaining Ring - M3	73 -111
0720 0040B	Retaining Ring - M4	27 -104
0720 0040B	Retaining Ring - M4	25 -102
0720 0040B	Retaining Ring - M4	53 -106
0720 0040B	Retaining Ring - M4	73 -109
0720 0040B	Retaining Ring - M4	39 -104
0720 0040B	Retaining Ring - M4	33 -103
0720 0040B	Retaining Ring - M4	57 -102
0720 0040B	Retaining Ring - M4	135 -105
0720 0040B	Retaining Ring - M4	77 -104
0720 0040B	Retaining Ring - M4	23 -105
0720 0040B	Retaining Ring - M4	37 -104
0720 0040B	Retaining Ring - M4	75 -103
0720 0040E	Retaining Ring - M4	71 -101
0720 0040E	Retaining Ring - M4	87 -104
0720 0040E	Retaining Ring - M4	139 -104
0720 0040E	Retaining Ring - M4	73 -113
0720 0040E	Retaining Ring - M4	101 -104
0720 0040E	Retaining Ring - M4	115 -102
0720 0040E	Retaining Ring - M4	107 -109
0720 0040E	Retaining Ring - M4	63 -105
0720 0040E	Retaining Ring - M4	143 -101
0720 0040E	Retaining Ring - M4	117 -107
0720 0040E	Retaining Ring - M4	95 -103

Part No.	Description	Page and Index No.
0720 0040E	Retaining Ring - M4	65 -103
0720 0040E	Retaining Ring - M4	145 -103
0720 0040E	Retaining Ring - M4	137 -101
0720 0040E	Retaining Ring - M4	103 -107
0720 0040E	Retaining Ring - M4	85 -105
0720 0040E	Retaining Ring - M4	121 -107
0720 0040E	Retaining Ring - M4	109 -105
0720 0040E	Retaining Ring - M4	105 -102
0720 0040E	Retaining Ring - M4	113 -102
0720 0040E	Retaining Ring - M4	119 -105
0720 0040E	Retaining Ring - M4	141 -106
0720 0040E	Retaining Ring - M4	111 -103
0720 0060B	Retaining Ring - M6	25 -101
0720 0060B	Retaining Ring - M6	77 -103
0720 0060B	Retaining Ring - M6	119 -102
0720 0060B	Retaining Ring - M6	33 -106
0720 0060B	Retaining Ring - M6	23 -106
0720 0060B	Retaining Ring - M6	49 -102
0720 0060B	Retaining Ring - M6	31 -102
0720 0060B	Retaining Ring - M6	37 -105
0720 0060B	Retaining Ring - M6	29 -102
0720 0060B	Retaining Ring - M6	57 -103
0720 0060B	Retaining Ring - M6	39 -105
0720 0060E	Retaining Ring - M6	111 -102
0720 0060E	Retaining Ring - M6	107 -106
0720 0060E	Retaining Ring - M6	121 -108
0720 0060E	Retaining Ring - M6	69 -106
0720 0060E	Retaining Ring - M6	73 -112
0720 0060E	Retaining Ring - M6	101 -102
0720 0060E	Retaining Ring - M6	71 -103
0720 0060E	Retaining Ring - M6	59 -105
0720 0060E	Retaining Ring - M6	67 -104
0720 0060E	Retaining Ring - M6	47 -106
0720 0060E	Retaining Ring - M6	65 -107
0720 0060E	Retaining Ring - M6	119 -107

Part No.	Description	Page and Index No.
0720 0060E	Retaining Ring - M6	115 -101
0720 0060E	Retaining Ring - M6	81 -101
0720 0060E	Retaining Ring - M6	63 -106
0720 0060E	Retaining Ring - M6	91 -104
0725 0120E	Retaining Ring C - M12	99 -109
0725 0120E	Retaining Ring C - M12	121 -104
0725 0300E	Retaining Ring C - M30	99 -110
0727 0060B	Retaining Ring C - 6	77 -102
0727 0060E	Retaining Ring - M6	77 -106
0727 0080G	Retaining Ring - M8	101 -105
0741 3706	Ball Bearing - 6x10x3	33 -108
0742 3808	Ball Bearing - 8x16x5	63 -107
0742 3808	Ball Bearing - 8x16x5	33 -107
0742 3808	Ball Bearing - 8x16x5	29 -103
0742 3808	Ball Bearing - 8x16x5	31 -103
0742 3808	Ball Bearing - 8x16x5	73 -114
0742 3808	Ball Bearing - 8x16x5	67 -105
0742 3906	Ball Bearing - 6x14x5mm	107 -108
0800 0072	Philips Pan Head Screw - M2.6x4	75 -102
0801 0142	Screw - Spring Washer - M5X8	133 -106
0801 0146	Screw - M4X4	53 -107
0801 0146	Screw - M4X4	55 -101
0802 5276	Tapping Screw - With Washer - M3x6	35 -105
0802 5279	Tapping Screw - With Washer - M3X8	23 -103
0803 0058	Stepped Screw	135 -23
0805 0072	CS Ring	75 -106
0805 0088	Retaining Ring - M6	69 -107
0805 0089	Retaining Ring - M4	33 -105
0805 0089	Retaining Ring - M4	35 -101
0805 0089	Retaining Ring - M4	31 -104
0805 0089	Retaining Ring - M4	27 -101
0805 3145	Ball Bearing - 6x12x4mm	71 -105
0805 3368	Ball Bearing - 8x16x5mm	49 -108
0805 3480	Bushing - 6mm	107 -112
0807 4146	Flat Washer - 6.3x18x1	107 -107

Part No.	Description	Page and Index No.
0807 5056	Washer - 8.1mm	101 -106
0951 3004W	Philips Screw With Flat Washer - M3	93 -104
0951 3005B	Philips Screw With Flat Washer M3x5	99 -105
0951 3006	Philips Screw With Flat Washer M3x6	47 -107
0951 3006B	Philips Screw With Flat Washer - M3x6	85 -103
0951 3006B	Philips Screw With Flat Washer - M3x6	93 -101
0951 3006B	Philips Screw With Flat Washer - M3x6	47 -104
0951 3006B	Philips Screw With Flat Washer - M3x6	89 -104
0951 3006B	Philips Screw With Flat Washer - M3x6	57 -109
0951 3006B	Philips Screw With Flat Washer - M3x6	87 -101
0951 3008B	Philips Screw With Flat Washer - M3x8	91 -105
0951 3008B	Philips Screw With Flat Washer - M3x8	45 -104
0951 3008B	Philips Screw With Flat Washer - M3x8	89 -105
0951 3008B	Philips Screw With Flat Washer - M3x8	87 -105
0951 4005B	Philips Screw With Flat Wash - M4x5	121 -110
0951 4006B	Philips Screw With Washer - M4x6	55 -104
0951 4008B	Philips Screw With Washer - M4x8	53 -111
0951 4008B	Philips Screw With Washer - M4x8	55 -107
0951 4008B	Philips Screw With Washer - M4x8	95 -102
0951 4008B	Philips Screw With Washer - M4x8	79 -102
0951 4008B	Philips Screw With Washer - M4x8	15 -105
0951 4008B	Philips Screw With Washer - M4x8	119 -103
0951 4010B	Philips Screw With Washer - M4x10	129 -101
0951 4010B	Philips Screw With Washer - M4x10	141 -102
0951 4012B	Philips Screw With Flat Washer	15 -106
0951 4014B	Philips Screw With Washer - M4x14	91 -106
0951 5010B	Philips Screw With Washer - M5x10	21 -101
0951 5010B	Philips Screw With Washer - M5x10	121 -106
0954 3006B	Screw - M3X6	99 -102
0954 3008B	Philips Screw - M3x8	47 -105
0954 3010B	Philips Screw - M3x10	99 -104
0954 3012B	Screw - M3X12	99 -101
0954 4008B	Philips Screw - M4x8	47 -103
0954 4008B	Philips Screw - M4x8	95 -105
0965 3008B	Tapping Screw With Washer - M3x8	83 -103

Part No.	Description	Page and Index No.
0965 3008W	Tapping Screw With Flat Washer - M3x8	53 -110
0971 4006A	Philips Polycarbonate Screw - M4x6	83 -104
1005 0955	Heat Sink	163 -108
1005 0978	SP513K	163 -109
1100 1474	Test Pin	153 -101
1100 1649	Testpin - HK-3-S	163 -110
1102 3566	Connector - S8B-XH-A(8PIN)	171 -101
1102 3597	Pin Header - 4P	153 -102
1102 5303	Connector - 4P	171 -102
1102 5304	Connector - 5P	153 -103
1102 5943	Connector - 2P	153 -104
1102 6245	Relay Connector - 2P	141 -104
1102 6245	Relay Connector - 2P	129 -103
1102 6245	Relay Connector - 2P	131 -104
1102 6246	Relay Connector - 4P	73 -101
1102 6247	Connector - 4P	69 -101
1102 6249	Relay Connector - 6P	63 -108
1102 6249	Relay Connector - 6P	67 -106
1102 6251	Connector - 8P	63 -109
1102 6252	Connector - 9P	63 -110
1102 6257	Relay Connector - 14P	73 -102
1102 6258	Relay Connector - 15P	73 -103
1102 6260	Relay Connector - 3P	69 -102
1102 6279	Connector - 3P	69 -103
1102 6295	Connector - 2P	153 -105
1102 6295	Connector - 2P	171 -103
1102 6296	Connector - 3P	153 -106
1102 6297	Connector - 4P	153 -107
1102 6325	Connector - 4P	153 -108
1102 6328	Connector - 2P	171 -104
1102 6393	Connector - 10P	153 -109
1102 6395	Connector - 1P	153 -110
1102 6396	Connector - 1P	153 -111
1102 6397	Box Header	153 -112
1102 6399	Connector - 22P	153 -113

Part No.	Description	Page and Index No.
1102 6401	Connector - 26P	153 -114
1102 6403	Connector - 30P	153 -115
1102 6515	Connector - 34P	153 -116
1102 6600	Connector - 8P	163 -111
1102 7626	Connector - TX25-80P-LT-N1	163 -112
1102 8091	Connector - 53505-4010	171 -105
1102 8153	Connector - FCN-568P068-G/05A-V4	171 -106
1102 8210	Connector - 2P	153 -117
1102 8357	Connector - 52777-0809	171 -107
1102 8472	Connector - 55447-0810	153 -118
1102 8476	Connector - 55447-1210	153 -119
1102 8480	Connector - 55447-1610	153 -120
1102 8502	Connector - 54679-1615	125 -108
1102 8504	Connector	121 -103
1102 8553	Connector - 3-353308-6	163 -113
1102 8553	Connector - 3-353308-6	153 -121
1102 8566	Connector SX1B-72S-0.635SH	171 -108
1102 8631	Connector	171 -109
1102 8656	Connector - TX25-120P-LT-H1	171 -110
1102 8725	Connector - FFC/FPC-FH12-10S-0.5SH	163 -114
1102 8727	Connector - FFC/FPC-FH12-28S-0.5SH	163 -115
1102 8774	Connector - 55456-2030	163 -116
1102 8775	Connector - 55456-1830	163 -117
1102 8776	Connector - 55456-1330	163 -118
1102 8777	Connector - 55456-1230	163 -119
1102 8779	Connector - 1-353530-0	163 -120
1102 8832	Connector - DM-3D4-B3210	171 -111
1102 8988	Connector	171 -112
1102 9037	Connector - WR-50P-VF-1	153 -122
1102 9066	Connector - 55456-0430	163 -121
1103 1317	Connector	153 -123
1104 0589	DIP Socket - 32P	171 -113
1105 0046	Harness Band	123 -102
1105 0159	PCB Stud	33 -102
1105 0229	Clamp	75 -104

Part No.	Description	Page and Index No.
1105 0230	Clamp	53 -101
1105 0267	Harness Clamp - YMC-10-0	57 -106
1105 0283	Clamp	101 -103
1105 0283	Clamp	141 -110
1105 0290	Harness Clamp - HORIZONTAL	107 -101
1105 0290	Harness Clamp - HORIZONTAL	41 -104
1105 0291	Harness Clamp - LWS-3S	57 -107
1105 0306	Metal Clamp - Al-4	51 -104
1105 0306	Metal Clamp - Al-4	45 -106
1105 0310	Harness Clamp - LWS-1S	37 -106
1105 0310	Harness Clamp - LWS-1S	39 -107
1105 0310	Harness Clamp - LWS-1S	41 -103
1105 0310	Harness Clamp - LWS-1S	27 -106
1105 0310	Harness Clamp - LWS-1S	23 -107
1105 0314	Metal Clamp - AL-5	131 -112
1105 0316	Clamp	125 -102
1105 0328	Harness Clamp - ES-0505	107 -102
1105 0328	Harness Clamp - ES-0505	141 -109
1105 0328	Harness Clamp - ES-0505	111 -101
1105 0328	Harness Clamp - ES-0505	117 -102
1105 0328	Harness Clamp - ES-0505	53 -102
1105 0328	Harness Clamp - ES-0505	65 -106
1105 0328	Harness Clamp - ES-0505	73 -104
1105 0328	Harness Clamp - ES-0505	63 -102
1105 0487	Harness Clamp	71 -106
1105 0487	Harness Clamp	139 -103
1105 0487	Harness Clamp	73 -105
1105 0487	Harness Clamp	93 -103
1105 0487	Harness Clamp	49 -109
1105 0487	Harness Clamp	133 -103
1105 0488	Harness Clamp	135 -101
1105 0488	Harness Clamp	129 -108
1105 0488	Harness Clamp	133 -104
1105 0488	Harness Clamp	127 -105
1105 0489	Harness Clamp - LWS 1316	125 -104

Part No.	Description	Page and Index No.
1105 0489	Harness Clamp - LWS 1316	49 -110
1105 0489	Harness Clamp - LWS 1316	121 -113
1105 0489	Harness Clamp - LWS 1316	133 -105
1105 0489	Harness Clamp - LWS 1316	131 -108
1105 0490	Harness Clamp - IWS-2218	121 -112
1105 0490	Harness Clamp - IWS-2218	131 -110
1105 0508	Harness Clamp - LWS-0711	113 -105
1105 0508	Harness Clamp - LWS-0711	117 -105
1105 0511	Harness Clamp - LWS-0306ZC	45 -109
1105 0511	Harness Clamp - LWS-0306ZC	63 -103
1105 0511	Harness Clamp - LWS-0306ZC	125 -110
1105 0511	Harness Clamp - LWS-0306ZC	67 -107
1105 0511	Harness Clamp - LWS-0306ZC	127 -104
1105 0511	Harness Clamp - LWS-0306ZC	27 -107
1105 0511	Harness Clamp - LWS-0306ZC	123 -104
1105 0511	Harness Clamp - LWS-0306ZC	113 -106
1105 0511	Harness Clamp - LWS-0306ZC	107 -104
1105 0511	Harness Clamp - LWS-0306ZC	37 -107
1105 0511	Harness Clamp - LWS-0306ZC	71 -107
1105 0511	Harness Clamp - LWS-0306ZC	95 -107
1105 0511	Harness Clamp - LWS-0306ZC	141 -103
1105 0511	Harness Clamp - LWS-0306ZC	41 -105
1105 0511	Harness Clamp - LWS-0306ZC	103 -106
1105 0511	Harness Clamp - LWS-0306ZC	69 -105
1105 0511	Harness Clamp - LWS-0306ZC	73 -106
1105 0511	Harness Clamp - LWS-0306ZC	31 -105
1105 0511	Harness Clamp - LWS-0306ZC	117 -104
1105 0514	Edge Saddle - EDS-0607I	29 -106
1105 0516	Clamp	45 -107
1105 0516	Clamp	121 -114
1105 0516	Clamp	129 -109
1105 0516	Clamp	45 -101
1105 0516	Clamp	125 -103
1105 0516	Clamp	143 -106
1105 0516	Clamp	145 -105

Part No.	Description	Page and Index No.
1105 0516	Clamp	117 -110
1105 0516	Clamp	131 -109
1105 0518	Edge Saddle - Les-1010	131 -111
1105 0518	Edge Saddle - Les-1010	137 -103
1105 0518	Edge Saddle - Les-1010	117 -109
1105 0518	Edge Saddle - Les-1010	125 -105
1105 0518	Edge Saddle - Les-1010	107 -103
1105 0518	Edge Saddle - LES-1010	73 -107
1105 0521	Clamp - LES-1017	125 -111
1105 0522	Edge Saddle - LES0510	139 -107
1105 0522	Edge Saddle - Les0510	65 -105
1105 0522	Edge Saddle - LES0510	71 -108
1105 0522	Edge Saddle - LES0510	73 -108
1105 0522	Edge Saddle - Les0510	113 -107
1105 0522	Edge Saddle - LES0510	129 -110
1105 0522	Edge Saddle - Les0510	117 -103
1105 0522	Edge Saddle - LES0510	131 -106
1105 0522	Edge Saddle - LES0510	103 -105
1105 0532	Edge Saddle - LES-25I	133 -107
1105 0532	Edge Saddle - LES-25I	131 -107
1105 0534	Clamp	85 -106
1105 0542	Harness Clamp - MSBS-1207	63 -111
1106 0411	Bushing - 11.5mm	57 -108
1107 0555	Fuse - 4A	171 -114
1107 0864	Fuse - 12A (120V)	133 -109
1107 0880	Fuse - 6.3A 250V (240V)	133 -109
1107 0884	Fuse - 5A 250V	39 -108
1107 1022	Fuse	133 -108
1109 0007	IC - MINISMDC100-02	153 -124
1204 1537	DIP Switch	153 -125
1204 1542	DIP Switch	163 -122
1204 2373	Key Board Switch - SKQDPA	163 -123
1204 2390	Interlock Switch - FA8I-AB24	137 -106
1204 2507	Switch SSSS810700	163 -124
1204 2521	Micro Switch	67 -102

Part No.	Description	Page and Index No.
1204 2521	Micro Switch	137 -107
1204 2571	DIP Switch - 2.54P	171 -115
1204 2598	Switch	137 -104
1400 0619	Transistor - DTA143EKA	153 -126
1400 0728	Transistor - 2SD2170	153 -127
1400 0731	Transistor - 2SD1766	153 -128
1400 0775	Transistor - 2SC4081	153 -129
1401 0972	Transistor - 2SB1260	153 -130
1401 1136	Fet - HAT1020R	171 -116
1401 1175	Fet - HAT1043M	171 -117
1401 1202	Fet - HAT1023R	163 -125
1402 1041	Diode - DA204U	153 -131
1402 1112	Diode - ERA83-004	153 -132
1402 1142	Diode Array - DAN217	153 -133
1402 1265	Diode - RB411D	171 -118
1402 1336	Diode - 1SS355	153 -134
1402 1342	Diode - 1SR154-400	171 -119
1402 1343	Diode - RB106L-40	171 -120
1402 1432	Diode - HZS18-1	153 -135
1402 1447	Diode - PTZ5.1B	153 -136
1402 1503	Diode - 1SS400	163 -126
1402 1546	Diode - RB081	171 -121
1402 1578	Diode - YG802C04R	163 -127
1402 1663	Diode - ZTP12B	153 -137
1403 0907	Diode - SML-310LT	163 -128
1403 0907	Diode - SML-310LT	153 -138
1403 0944	Photocoupler - PC817X1	153 -139
1403 0953	LED - SML-310MT	163 -129
1403 0978	LED - SML-310DT	153 -140
1403 0987	LED SML-211UT	171 -122
1407 1535	IC - TD62308AP	153 -141
1407 2187	TTLIC - SN74LS07NS	153 -142
1407 2187	TTLIC - SN74LS07NS	171 -123
1407 2218	TTLIC - SN74LS06NS	153 -143
1407 2218	TTLIC - SN74LS06NS	171 -124

Part No.	Description	Page and Index No.
1407 2219	IC - TD62003AP	153 -144
1407 3357	Comparator - BA10393F	153 -145
1407 4649	IC - TC7S32FU	153 -146
1407 4947	IC - 74LCX244	153 -147
1407 4948	IC - 74LCX245 TSSOP	153 -148
1407 4959	IC - MC68334GCFC20	153 -149
1407 4963	IC - MBM29F800TA-70PFTN	153 -150
1407 5090	IC - DS90CF364MTD	163 -130
1407 5275	CMOS Logic - 74LVCHR16245A TSSOP	171 -125
1407 5287	Clock Generator - W180-03G	163 -131
1407 5300	CMOS Logic - 74LVC16244A TSSOP	171 -126
1407 5321	CMOS Logic - 74LVCH16374A TSSOP	171 -127
1407 5334	IC - CMOS LOGIC 74LVC244A TSSOP	171 -128
1407 5334	IC - CMOS LOGIC 74LVC244A TSSOP	163 -132
1407 5344	IC - SN74LV02APW	153 -151
1407 5347	IC - SN74LV08APW	163 -133
1407 5351	IC - SN74LV14APW	163 -134
1407 5351	IC - SN74LV14APW	153 -152
1407 5353	IC - SN74LV244APW	163 -135
1407 5361	IC - 74LVC157A TSSOP	163 -136
1407 5364	IC - SN74AHCT244PW	163 -137
1407 5364	IC - SN74AHCT244PW	171 -129
1407 5366	IC - 74LVC08A TSSOP	171 -130
1407 5369	IC - SN74AHCT32PW	153 -153
1407 5374	IC - SN74LV4052APW	153 -154
1407 5398	IC - CD4066BNS	153 -155
1407 5427	IC - 74ACH1G32DCK	153 -156
1407 5469	IC - SN74LV07APW	163 -138
1407 5485	IC - SN74VC574APW	171 -131
1407 5517	IC - 74AHCT14PW	171 -132
1407 5523	ROM - I2C SOP 3V	171 -133
1407 5694	CPU RM7000A-400T-REV1.34	171 -134
1407 5705	IC - SN74LVC06APW	163 -139
1407 5709	IC - MK1705A	163 -140
1407 5717	IC - ICS960001AF	171 -135

Part No.	Description	Page and Index No.
1407 5742	IC - ICS553MI	163 -141
1407 5743	IC - RF5V860	163 -142
1408 0810	IC - BA10358F	153 -157
1408 0826	IC - TA8428K	153 -158
1408 0827	IC - TA8429H	153 -159
1408 0942	IC - BA4558F	153 -160
1408 1095	IC - BA10324AF	163 -143
1408 1206	Transistor-array - TD62M4700F	153 -161
1408 1273	IC - RN5VD28A	171 -136
1408 1398	Detector - RN5VD42A	171 -137
1408 1507	Regulator - PQ05VY3H3Z	171 -138
1408 1508	Series Regulator - PQ07VZ012Z	163 -144
1408 1528	Regulator - PQ05VY053Z	171 -139
1408 1529	DC Converter - ITC1622CSB	171 -140
1408 1596	IC - RN5VD15A	171 -141
1408 1640	Series Regulator - PQ070XH02Z	171 -142
1408 1657	IC - RN5VD20A	171 -143
1408 1730	IC - MM1096BF	153 -162
1408 1746	IC - PST623XW	163 -145
1408 1747	Regulator - PQ5EV7L	163 -146
1503 0460	Oscillator - 32.768Khz	153 -163
1503 0842	Oscillator - 14.31818MHz	171 -144
1503 0946	Crystal Oscillator - 9.8304MHz	153 -164
1503 1004	Oscillator - 19.6608MHz	153 -165
1503 1045	Oscillator - 24MHz	171 -145
1503 1089	Oscillator - 85.2MHz	163 -147
1503 1090	Oscillator - 21.176MHz	163 -148
1503 1091	Oscillator - 10MHz	163 -149
1600 1880	Resistor - 25M $\Omega \pm 1\%$ 1W	171 -146
1601 5319	Resistor-3.9 $\Omega \pm 5\%$ 2W	153 -166
1601 7751	Resistor - 4.7K $\Omega \pm 5\%$	153 -167
1601 7752	Resistor Array - 10K $\Omega \pm 5\%$	153 -168
1601 7757	Resistor 0 Ω	153 -169
1601 7781	Resistor - 10 $\Omega \pm 5\%$	153 -170
1601 7814	Resistor - 3.3K $\Omega \pm 5\%$	153 -171

Part No.	Description	Page and Index No.
1601 7866	Resistor Array - 150 $\Omega \pm 5\%$	153 -172
1601 7867	Resistor - 33 $\Omega \pm 5\%$ 1/16W	153 -173
1601 7871	Resistor - 68 $\Omega \pm 5\%$ 1/16W	153 -174
1601 7877	Resistor Array 4.7k $\Omega \pm 5\%$ 1/32W	163 -150
1601 7879	Resistor - 22 $\Omega \pm 5\%$ 1/16W	153 -175
1601 7887	Resistor Array - 10K $\Omega \pm 5\%$ 1/32W	163 -151
1601 7898	Resistor Array	163 -152
1601 7899	Resistor Array - 56 $\Omega \pm 5\%$ 1/16W	153 -176
1601 7900	Resistor Array - 0 $\Omega \pm 5\%$	163 -153
1601 7913	Resistor 22 $\Omega \pm 5\%$ 1/32w	163 -154
1601 7914	Resistor Array - 47 $\Omega \pm 5\%$	163 -155
1601 7915	Resistor Array - 33 $\Omega \pm 5\%$ 1/16W	171 -147
1601 7918	Resistor - 22 $\Omega \pm 5\%$ 1/16W	171 -148
1601 7926	Resistor - 68 $\Omega \pm 5\%$ 1/16W 8	171 -149
1601 7929	Resistor Array - 100K $\Omega \pm 5\%$ 1/16W	171 -150
1601 7943	Resistor Array - 68 $\Omega \pm 5\%$ 1/32W	163 -156
1601 7959	Resistor	163 -157
1601 7960	Resistor Array - 100 $\Omega \pm 5\%$ 1/16W	163 -158
1601 7981	Resistor Array - 100K $\Omega \pm 5\%$ 1/16W	163 -159
1601 7987	Resistor Array - 82 $\Omega \pm 5\%$ 1/16W	171 -151
1604 4806	Capacitor	163 -160
1604 4562	Capacitor - 220 $\mu\text{F} \pm 20\%$ 35V	153 -177
1604 4728	Capacitor - 100 $\mu\text{F} \pm 20\%$ 16V	171 -152
1604 4848	Capacitor - 100 $\mu\text{F} \pm 20\%$ 10V	163 -161
1604 4987	Capacitor - 330 $\mu\text{F} \pm 20\%$ 6.3V	163 -162
1604 4994	Capacitor - 100 $\mu\text{F} \pm 20\%$ 6.3V	171 -153
1604 5082	Capacitor - 330 $\mu\text{F} \pm 20\%$ 10V	163 -163
1605 0976	Capacitor - 1 $\mu\text{F} +80\%$ -20% 10V	163 -164
1605 1081	Capacitor - 10 $\mu\text{F} +80\%$ -20% 25V	171 -154
1605 1124	Capacitor - 4.7 $\mu\text{F} +80\%$ -20% 10V	171 -155
1605 1132	Capacitor - 2.2 $\mu\text{F} +80\%$ -20% 16V	171 -156
1605 1135	Capacitor - 0.47 $\mu\text{F} \pm 1\%$ 10V	153 -178
1605 1137	Capacitor - 470pF $\pm 10\%$ 50V	153 -179
1605 1161	Capacitor - 0.33 $\mu\text{F} \pm 10\%$ 10V	163 -165
1605 1167	Capacitor - 0.22 $\mu\text{F} \pm 10\%$ 10V	163 -166

Part No.	Description	Page and Index No.
1605 1181	Capacitor - 10 μ F +80-20% 10V	171 -157
1605 1181	Capacitor - 10 μ F +80-20% 10V	163 -167
1605 1187	Ceramic Capacitor 0.047 μ F \pm 10% 50V	163 -168
1605 1200	Capacitor - 10PF \pm 0.5pF 50V	171 -158
1605 1201	Capacitor - 12pF \pm 5% 50V	171 -159
1605 1202	Capacitor - 15pF \pm 5% 50V	171 -160
1605 1205	Capacitor - 33pF \pm 5% 50V	171 -161
1605 1207	Capacitor - 68pF \pm 5% 50V	171 -162
1605 1211	Capacitor - 220pF \pm 10% 50V	171 -163
1605 1214	Capacitor - 1000pF \pm 10% 50V	171 -164
1605 1216	Capacitor - 2200PF \pm 10% 50V	171 -165
1605 1221	Capacitor - 0.1 μ F+80-20%10V	171 -166
1605 1224	Capacitor 4.7 μ F \pm 10% 6.3V	163 -169
1605 1224	Capacitor 4.7 μ F \pm 10% 6.3v	171 -167
1605 1252	Capacitor - 0.01 μ F +80-20% 50V	171 -168
1607 0623	Ferrite Core - TFC-16-8-13	39 -102
1607 0732	Noise Filter - AEF321825-470	153 -180
1607 0758	Filter - DSS710D223A12-22	153 -181
1607 0852	Filter - BLM41P750SPB	153 -182
1607 0861	Filter - BK2125HS101	163 -170
1607 1021	Filter - MM1608D800B	153 -183
1607 1061	Filter - BLM11P300SPB	163 -171
1607 1061	Filter - BLM11P300SPB	171 -169
1607 1206	Filter - ACC2012L-250	171 -170
1607 1212	Inductor - CDRH6D38-5R0NC	171 -171
1607 1225	Filter - ACC4516L-700	171 -172
1610 1218	Resistor	163 -172
1610 1374	Resistor - 2.2K Ω \pm 5% 1/2W	153 -184
1610 1638	Resistor - 10M Ω \pm 1%10W	153 -185
1631 0000	Resistor - 0 Ω 1/4W	153 -186
1632 0000	Resistor - 0 Ω 1/8W	171 -173
1633 0000	Resistor - 0 Ω 1/10W	163 -173
1634 0000	Resistor - 0 Ω 1/16W	171 -174
1640 2330	Capacitor - 33 μ F+80%-20%25V	153 -187
1640 2470	Capacitor - 47 μ F \pm 20% 25V	153 -188

Part No.	Description	Page and Index No.
1640 3101	Capacitor - 100 μ F \pm 20% 35V	153 -189
1640 5330	Capacitor - 33 μ F \pm 20% 50V	153 -190
1640 5470	Capacitor - 47 μ F \pm 20% 50V	153 -191
1650 2101	Resistor - 100 Ω \pm 5% 1/4W	153 -192
1650 2151	Resistor - 150 Ω \pm 5% 1/4W	153 -193
1650 3221	Resistor - 220 Ω \pm 5%1/8W	153 -194
1650 4100	Resistor - 10 Ω \pm 5% 1/10W	163 -174
1650 4100	Resistor - 10 Ω \pm 5% 1/10W	153 -195
1650 4101	Resistor - 100 Ω \pm 5%1/10W	163 -175
1650 4101	Resistor - 100 Ω \pm 5%1/10W	171 -175
1650 4102	Resistor - 1K Ω \pm 5% 1/10W	171 -176
1650 4102	Resistor - 1K Ω \pm 5% 1/10W	163 -176
1650 4102	Resistor - 1K Ω \pm 5% 1/10W	153 -196
1650 4103	Resistor - 10K Ω \pm 5% 1/10W	171 -177
1650 4103	Resistor - 10K Ω \pm 5% 1/10W	153 -197
1650 4103	Resistor - 10K Ω \pm 5% 1/10W	163 -177
1650 4104	Resistor - 100K Ω \pm 5%1/10W	163 -178
1650 4104	Resistor - 100K Ω \pm 5%1/10W	171 -178
1650 4109	Resistor - 1 Ω \pm 5% 1/10W	171 -179
1650 4112	Resistor - 1.1k Ω \pm 5% 1/10w 1608	153 -198
1650 4114	Resistor - 110K Ω \pm 5% 1/10W 1608	163 -179
1650 4120	Resistor - 12 Ω \pm 5% 1/10W	171 -180
1650 4132	Resistor - 1.3K Ω \pm 5% 1/10W 1608	153 -199
1650 4150	Resistor - 15 Ω \pm 5% 1/10W	171 -181
1650 4150	Resistor - 15 Ω \pm 5% 1/10W	163 -180
1650 4151	Resistor - 150 Ω \pm 5%1/10W	153 -200
1650 4154	Resistor 150K Ω \pm 5% 1/10W	153 -201
1650 4182	Resistor - 1.8K Ω \pm 5%1/10W	171 -182
1650 4200	Resistor - 20 Ω \pm 5% 1/10W	163 -181
1650 4202	Resistor - 2K Ω \pm 5%1/10W	163 -182
1650 4220	Chip Resistor - 22 Ω \pm 5% 1/10W	171 -183
1650 4220	Chip Resistor - 22 Ω \pm 5% 1/10W	163 -183
1650 4222	Resistor - 2.2K Ω \pm 5%1/10W	171 -184
1650 4222	Resistor - 2.2K Ω \pm 5%1/10W	153 -202
1650 4223	Resistor - 22K Ω \pm 5%1/10W	153 -203

Part No.	Description	Page and Index No.
1650 4242	Resistor - 2.4K Ω \pm 5% 1/10W 1608	163 -184
1650 4330	Chip Resistor - 33 Ω \pm 5% 1/10W	163 -185
1650 4330	Chip Resistor - 33 Ω \pm 5% 1/10W	153 -204
1650 4330	Chip Resistor - 33 Ω \pm 5% 1/10W	171 -185
1650 4332	Resistor - 3.3K Ω \pm 5%1/10W	153 -205
1650 4362	Resistor - 3.6K Ω \pm 5%1/10W	153 -206
1650 4392	Chip Resistor - 3.9k Ω \pm 5%1/10W	153 -207
1650 4470	Resistor - 47 Ω \pm 5%1/10W	163 -186
1650 4470	Resistor - 47 Ω \pm 5%1/10W	171 -186
1650 4472	Resistor - 4.7K Ω \pm 5% 1/10W	163 -187
1650 4472	Resistor - 4.7K Ω \pm 5% 1/10W	153 -208
1650 4472	Resistor - 4.7K Ω \pm 5% 1/10W	171 -187
1650 4510	Resistor - 51 Ω \pm 5%1/10W	163 -188
1650 4511	Resistor - 510 Ω \pm 5%1/10W	163 -189
1650 4560	Chip Resistor - 56 Ω \pm 5% 1/10W	153 -209
1650 4562	Resistor - 5.6K Ω \pm 5% 1/10W	171 -188
1650 4562	Resistor - 5.6K Ω \pm 5% 1/10W	153 -210
1650 4621	Resistor - 620 Ω \pm 5% 1/10W 1608	163 -190
1650 4680	Resistor - 68 Ω \pm 5%1/10W	171 -189
1650 4680	Resistor - 68 Ω \pm 5%1/10W	163 -191
1650 4750	Resistor - 75 Ω \pm 5%1/10W	163 -192
1650 4751	Resistor - 750 Ω \pm 5% 1/10W	153 -211
1650 4820	Resistor - 82 Ω \pm 5% 1/10W	171 -190
1650 4910	Resistor - 91 Ω \pm 5%1/10W	153 -212
1650 5680	Resistor - 68 Ω \pm 5% 1/16W	171 -191
1654 0000	Resistor - 0 Ω 1608	163 -193
1654 1001	Resistor - 1K Ω \pm 1%1/10W	171 -192
1654 1001	Resistor - 1K Ω \pm 1%1/10W	153 -213
1654 1001	Resistor - 1K Ω \pm 1%1/10W	163 -194
1654 1002	Resistor - 10K Ω \pm 5%1/10W	153 -214
1654 1003	Resistor - 100K Ω \pm 1%1/10W	153 -215
1654 1004	Chip Resistor - 1m Ω \pm 1% 1/10W	153 -216
1654 1102	Resistor - 11K Ω \pm 1%1/10W	153 -217
1654 1201	Resistor - 1.2K Ω \pm 1% 1/10W	171 -193
1654 1201	Resistor - 1.2K Ω \pm 1% 1/10W	163 -195

Part No.	Description	Page and Index No.
1654 1303	Resistor - 130K Ω \pm 1% 1/10W 1608	153 -218
1654 1401	Resistor - 1.4K Ω \pm 1% 1/10W 1608	153 -219
1654 1501	Resistor - 1.5K Ω \pm 1% 1/10W 1608	153 -220
1654 1542	Resistor - 15.4K Ω \pm 1% 1/10W 1608	153 -221
1654 1911	Resistor - 1.91K Ω \pm 1% 1/10W 1608	153 -222
1654 2001	Chip Resistor - 2k Ω \pm 1% 1/10W	171 -194
1654 2201	Resistor - 2.2K Ω \pm 1% 1/10W 1608	163 -196
1654 3601	Resistor - 3.6K Ω \pm 1% 1/10W	153 -223
1654 3602	Resistor - 36K Ω \pm 1% 1/10W 1608	153 -224
1654 3903	Resistor - 390K Ω \pm 1% 1/10W	153 -225
1654 4420	Resistor 442 Ω \pm 1% 1/10w 1608	163 -197
1654 4702	Chip Resistor - 47k Ω \pm 1% 1/10W	153 -226
1654 4990	Resistor - 499 Ω \pm 1% 1/10W	163 -198
1654 4990	Resistor - 499 Ω \pm 1% 1/10W	153 -227
1654 5231	Resistor - 5.23K Ω \pm 1%1/10W	153 -228
1654 5360	Resistor - 536 Ω \pm 1% 1/10W 1608	153 -229
1654 7502	Resistor - 75K Ω \pm 1%1/10W	171 -195
1654 8203	Resistor - 820K Ω \pm 1% 1/10W 1608	153 -230
1654 9109	Resistor - 91 Ω \pm 1% 1/10W	153 -231
1654 9532	Resistor - 98.3K Ω \pm 1% 1/10W 1608	171 -196
1660 0100	Capacitor - 10PF \pm 0.5pF 50V	163 -199
1660 2101	Capacitor - 100pF - \pm 10% - 50V	163 -200
1660 2101	Capacitor - 100pF - \pm 10% - 50V	153 -232
1660 2150	Capacitor - 15pF \pm 5% 50V	153 -233
1660 2220	Capacitor - 22pF \pm 20% 35V	153 -234
1660 2221	Capacitor - 220pF +80-20% 50V	171 -197
1660 2221	Capacitor - 220pF +80-20% 50V	163 -201
1660 2270	Capacitor - 27pF \pm 20% 35V	153 -235
1660 2330	Capacitor - 33pF - \pm 5% - 50V	153 -236
1660 2330	Capacitor - 33pF - \pm 5% - 50V	163 -202
1660 2331	Capacitor - 330pF \pm 5% 50V	163 -203
1660 2331	Capacitor - 330pF \pm 5% 50V	171 -198
1660 2391	Capacitor - 390pF \pm 5% 50V	153 -237
1660 2470	Capacitor - 47pF \pm 5% 50V	163 -204
1660 2470	Capacitor - 47pF \pm 5% 50V	153 -238

Part No.	Description	Page and Index No.
1660 2471	Capacitor - 470pF - $\pm 5\%$ - 50V	163 -205
1660 2471	Capacitor - 470pF - $\pm 5\%$ - 50V	171 -199
1660 4102	Capacitor - 1000pF $\pm 10\%$ 50V	153 -239
1660 4102	Capacitor - 1000pF $\pm 10\%$ 50V	171 -200
1660 4102	Capacitor - 1000pF $\pm 10\%$ 50V	163 -206
1660 4103	Capacitor - 10000pF - $\pm 10\%$ - 50V	163 -207
1660 4222	Capacitor - 2200pF - $\pm 10\%$ - 50V	163 -208
1660 4222	Capacitor - 2200pF - $\pm 10\%$ - 50V	153 -240
1660 4472	Capacitor - 4700PF $\pm 10\%$ 50V	163 -209
1660 4472	Capacitor - 4700PF $\pm 10\%$ 50V	153 -241
1660 6103	Capacitor - 10000pF - $\pm 80\%$ -20% 50V	171 -201
1660 6103	Capacitor - 10000pF - $\pm 80\%$ -20% 50V	163 -210
1660 6103	Capacitor - 10000pF - $\pm 80\%$ -20% 50V	153 -242
1660 6473	Capacitor - 47000pF $\pm 80\%$ -20% 50V	153 -243
1660 8104	Capacitor - 0.1 μ F $\pm 80\%$ -20% 25V	163 -211
1660 8104	Capacitor - 0.1 μ F $\pm 80\%$ -20% 25V	153 -244
1660 8104	Capacitor - 0.1 μ F $\pm 80\%$ -20% 25V	171 -202
1902 0042	RAM-1M X8 70NS TSOP G2	153 -245
1906 0017	Flash Memory - LH28F320BJ-PBTL70	171 -203
1907 0015	SDRAM - 256MB 4MX16X4 100MHz	163 -212

Part No.	Description	Page and Index No.
5053 0223	Bushing - 8mm	23 - 18
5053 0223	Bushing - 8mm	57 - 20
5053 0447	Bushing - 6mm	31 - 7
5053 0447	Bushing - 6mm	23 - 14
5053 0447	Bushing - 6mm	123 - 10
5053 0447	Bushing - 6mm	77 - 5
5053 0447	Bushing - 6mm	37 - 16
5053 0447	Bushing - 6mm	25 - 5
5053 0447	Bushing - 6mm	53 - 28
5201 1796	Stepped Screw - M4	145 - 17
5201 1796	Stepped Screw - M4	67 - 16
5201 2858	Friction Pad	55 - 11
5203 9502	Grease 501	177 - 6
5205 2697	Bushing - Upper Registration Roller	73 - 1
5205 2697	Bushing - Upper Registration Roller	71 - 1
5206 2684	Shoulder Screw - M3	29 - 21
5206 2686	Snap Ring	61 - 2
5206 2686	Snap Ring	23 - 5
5215 2621	Snap Ring - M6	23 - 21
5215 2621	Snap Ring - M6	39 - 32
5301 1662	Hexagon Bolt	145 - 8
5324 1662	Bushing- 4x8x4.5mm	29 - 5
5415 4145	Stud	31 - 2
5415 4145	Stud	23 - 24
5419 5714	Stepped Screw - M4	39 - 34
5442 1924	Exposure Glass Cushion	43 - 20
5442 2754	Spring - Registration Roller	71 - 2
5443 2668	Bushing - 4x6x7mm	73 - 6
5446 2824	Screw - Duplex Guide Plate	27 - 1
5446 5832	Connector Guide Pin	135 - 12
5446 5832	Connector Guide Pin	131 - 16
5447 2681	Snap Ring	111 - 27
5447 2681	Snap Ring	141 - 14
5447 2681	Snap Ring	125 - 8
5447 2681	Snap Ring	123 - 36

